



DEVICE:







DEVICE:

FAQ


TWINS







TWINS



r	Q: What kind of charger should we use for the speaker? A: Use the provided USB Y-cable. If unavailable, use any micro USB charger above 5V/0.8A
)	O: What if there is discontinuous sound when playing? A: The speaker can be normally used within 10 meter. If it is over 10 meters, there might be noise or discontinuous sound. O: Why will the speaker shut down automatically when it is working?
	A: When there is no bluetooth pairing for more than 10 minutes, the speaker will shut down automatically to reduce power consumption.
	Q: Why can't the speaker connect to a previously paired device? A: First, remove the speaker's pairing name from the device's bluetooth list and then short press the power button twice quickly to restart pairing mode.
	Service Email: Service@paxcess.com *This speaker supports mobile phones, tablets, PCs, etc.

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.