

HB6339说明书 (Hellobaby)

说明书为折叠式

尺寸: 540*120MM

材质: 100g双胶纸 (彩色)

版本: V1.0

类型: 环保

版本	修改内容	日期
Ver: 1.0	首次发行.	2022/02/21

设计	审核	审批
Tony-W		
2022/02/21		

120.00 mm

HelloBaby®

Ver: 1.0

User Manual

2.4GHz Digital Wireless Video Baby Monitor

Model: HB6339

The pictures are for reference only, please subject to practicality.

www.hellobaby.net.cn
service@hellobaby.net.cn

540.00 mm

Thank you for purchasing the HB6339 Baby Monitor. With our baby monitor, you could see and hear your baby sleeping or playing in their room anytime.

Please retain your original dated sales receipt for your records. For warranty service of your product, you will need to provide a copy of your dated sales receipt to confirm warranty status. Registration is not required for warranty coverage.

Please make sure the following included in your package

Parent unit x 1	Camera unit x 1	Power Adapter x 2
User manual x 1	Wall mounting kit x 1	

1. SAFETY INSTRUCTIONS

CAUTION: Keep the device away from children.

Strangulation Hazard: Children have STRANGLING in cords. Keep this cord out of the reach of children (more than 3ft (0.9m) away). Never use extension cords with AC Adapters. Only use the AC Adapters provided.

Choking hazard: This product contains small parts, please be careful when unpack and assemble the product.

Reading and keep to instructions: All the safety and operating instructions should be read before the video baby monitor is operated. This product cannot replace responsible adult supervision.

Water and moisture: This product is designed for indoor use only. The unit should not be exposed to rain, moisture, dripping or splashing. No objects filled with liquid should be placed on top of, or beside the products, such as glass or vases. This item should not be used near water.

DO NOT: Use the appliance if the cord or plug is damaged. If your baby monitor is not operating properly or has suffered any damage, contact "Videotimes" service center to request inspection and repair of the appliance in order to avoid any possible risk.

DO NOT: Do not attempt to repair or adjust any of the electrical or mechanical functions of the unit. Otherwise, the guarantee will be made void.

Ventilation: This baby monitor should not be used in a bed, sofa, rug or similar surface that may block the ventilation openings, or be placed in an enclosed area such as a bookcase or drawer that may impede air flow.

Keep away from sources of heat: This unit should not be exposed to direct heat sources such as candle, radiator, heat register, stove or other appliance that emits heat. The unit should be left undisturbed and unattended.

Power source: This unit should only be used with the AC power adapters included in this package (2V 1A).

Damage requiring service: This unit should be serviced by qualified personnel only when: Objects have fallen or liquid has been spilled into the product; The units have been exposed to rain;

The units do not appear to operate normally or exhibits a distinct change in performance: The units have been dropped or the enclosure damaged;

3. WARRANTY TERMS

We offer one year warranty from the original purchase date against defects in workmanship and materials. If you have warranty or support issues, please contact our after sales service via email.

3.1. INSTALLATION GUIDELINES

To use your parent unit and camera unit together, you have to establish a radio link between them, and the range will be affected by environmental conditions.

- * Any large metal object, like a refrigerator, a mirror, a filing cabinet, metallic doors or reinforced concrete between the baby and parent unit may block the radio signal.
- * The signal strength may also be reduced by other solid structures, like walls, or by radio or electrical equipment, such as TV, computers, cordless or mobile phones, fluorescent lights or dimmer switches.
- * Use of other 2.4GHz product, such as wireless network (Wi-Fi routers), Bluetooth systems, or microwave ovens, may cause interference with this product. Keep the baby monitor away at least 3ft (1.5m) from such products, or turn them off if they cause interferences.

4. PLACEMENT OF THE BABY MONITOR

The camera can be placed on the desktop or mounted on the wall. Don't place baby monitor on soft surface like beds or in the corner of cupboards, shelves, etc. Keep the baby monitor away from heat sources such as radiators, chimneys, cookers and direct sunlight. Keep the baby unit away from TVs sets, microwave ovens and radios. If starfire interference occurs, move the camera to elsewhere;

* Place the camera within 6 feet (2 meters) of the area being monitored for optimum performance.

5. GETTING STARTED

5.1 TURN ON THE BABY UNIT:

1. Insert the DC plug of the power adapter into the DC jack in the rear of the Baby Unit;
2. Insert the other end of the power adapter into a suitable electrical outlet;
3. Once the adapter is connected, the power LED will light up;

5.2 TURN ON THE PARENT UNIT:

1. Insert the DC plug of the power adapter into the DC jack in the side of the parent unit;
2. Insert the other end of the power adapter into a suitable electrical outlet;
3. Press and hold the power key 3 seconds on the side of the parent unit;
4. Once parent unit is on, the power LED will light up and the image will display on the LCD

5.3 INFRARED NIGHT VISION (AUTOMATIC)

The infrared night vision function allows the camera to pick up images in dark or low light conditions. In this mode, only black and white images will be displayed on the monitor. The optimum image lies within where baby unit is 6ft (2m) away from object. The camera is in night vision mode, the icon will be displayed on the top of screen.

6. PRODUCTION VIEW:

6.1 ICONS OVERVIEW:

	Signal Strength		Volume		Zoom
	Alarm		Brightness		Two-Way Talk
	Lullaby		Night Vision		Battery level
	Camera		VOX Mode		Temperature

6.2 PARENT UNIT OVERVIEW:

6.3 BABY UNIT OVERVIEW:

7. KEY OPERATION

7.1 TURN ON/OFF
Press and hold the power key for 3 seconds to turn on / off the parents unit.

7.2 DOWN KEY
Press once to tilt the camera up by one step. Press and hold to tilt continuously.

7.3 DOWN KEY
Press once to tilt the camera down by one step. Press and hold to tilt continuously.

7.4 LEFT KEY
Press once to pan the camera left by one step. Press and hold to pan continuously.

7.5 RIGHT KEY
Press once to pan the camera right by one step. Press and hold to pan continuously.

7.6 CAMERA VIEW/CAN
Press scan key to view scan camera; during scan mode, the scan icon will be displayed on the top of screen. Each camera's video will be displayed on the LCD around 10 seconds then change to next camera;

7.7 DIGITAL ZOOM
Press and hold the key around 2 seconds to operate zoom in/out;

7.8 Two Way Talk
Press and hold key to enter two way talk mode. A microphone icon will be displayed in the corner of the LCD screen. Release the key to stop.

Note: When you are in the two-way talk mode, the parent unit speaker is muted.

8. MENU OPERATION

8.1 PAIRING THE CAMERA AND PARENT UNITS
The baby unit is pre-paired to your parent unit. You do not need to register it again unless the baby unit loses its link with the parent unit. To re-register your baby unit, or register another

8. MENI OPERATOR

8.1 PAIRING THE CAMERA AND PARENT UNITS
The baby unit is pre-paired to your parent unit. You do not need to register it again unless the baby unit loses its link with the parent unit. To re-register your baby unit, or register another

8.2 PAIRING THE CAMERA AND PARENT UNITS
The baby unit is pre-paired to your parent unit. You do not need to register it again unless the baby unit loses its link with the parent unit. To re-register your baby unit, or register another

8.3 PAIRING THE CAMERA AND PARENT UNITS
The baby unit is pre-paired to your parent unit. You do not need to register it again unless the baby unit loses its link with the parent unit. To re-register your baby unit, or register another

8.4 PAIRING THE CAMERA AND PARENT UNITS
The baby unit is pre-paired to your parent unit. You do not need to register it again unless the baby unit loses its link with the parent unit. To re-register your baby unit, or register another

Note: Camera icon with "*" means it is well registered. You should select and pair with the camera icon without "*" sign.

8.1.1 ADD CANA

1. Press the MENU key then the menu will pop up;
2. Press the key until the camera icon is highlighted, then press key or key to select your desired camera;
3. Press OK key to enter into sub-menu;
4. Press key to select ADD CANA then press OK key;
5. When the icon is displayed on the LCD screen, press the PAIR button on the back of camera;
6. Once paired, appears on the LCD screen.
7. If fails, repeat the above steps.

8.2 DELETE CAMERA

1. Press the MENU key and the menu will pop up;
2. Press the key or key until the camera icon is highlighted, then press key or key to select your desired camera;
3. Press OK key to enter into sub-menu;
4. Press key to select DEL CANA then press OK key;
5. Press key to delete the camera;
6. Press OK key to confirm the option.

8.3 VOLUME

1. Press the key and the menu will pop up;
2. Press the key until the menu will pop up;
3. Press OK key to enter into sub-menu;
4. Press key to select the desired volume level from level 1 ~ 5.
5. Press key to select between "°C" or "°F".
6. Press OK key to confirm.

8.4 TEMPERATURE UNIT SETTING

1. Press the key and the menu will pop up;
2. Press the key until the temperature icon is highlighted;
3. Press key to select the desired volume level from level 1 ~ 5.
4. Press OK key to confirm.

8.5 DISPLAY BRIGHTNESS

1. Press the key and the menu will pop up;
2. Press the key until the menu will pop up;
3. Press key to select the desired brightness level from level 1 ~ 5.
4. Press OK key to confirm.

8.6 VOX SETTING

This mode allows you to control the sound activation of your baby unit. If there is no sound around the baby unit within 30 seconds, it will stop audio transmission and turn off the screen of the parent unit. When the baby unit detects any sounds louder than the sensitivity you set, it will start transmitting the signal to the parent unit and display on the screen of the parent unit. To change the VOX level, please follow the below instructions.

1. Press key and the menu will pop up;
2. Press key until the menu will pop up;
3. Press key to select the desired VOX sensitivity level;
4. Press OK key to confirm setting.

Note: Sensitivity levels and indications:

- Hear everything from your baby. The speaker of the parent unit is continuously on.
- Hear all sounds from soft babbling. If your baby does not make any sound, the speaker of the parent unit is off.
- The speaker of the parent unit only goes on if the baby makes loud sounds (e.g. crying).

9. TECHNICAL DATA

Frequency	2403.5MHz~2475.5MHz
Power Adapter	Parent Unit: Input: 100-240VAC 50/60Hz Output: 5V DC 1A Camera Unit: Input: 100-240VAC 50/60Hz Output: 5V DC 1A
Operating Range	Up to 1000ft (300m) outdoor (line of sight) Up to 165ft (50m) indoor
Display	3.2" High Resolution TFT LCD
Batteries (Parent Unit)	Li-ion 3.7V 500mAh (3.515Wh)
Battery life	Up to 8 hours
Maximum power	< 0.196W
Operation environment	Operation Temperature: +32F ~ +104F (0°C~40°C) Relative Humidity: 10%~90% Relative Humidity: 15%~85%

10. TROUBLE SHOOTING

<p>No reception on the monitor</p> <ul style="list-style-type: none"> * The power sockets may not be properly connected. * Confirm that the camera and monitor are ON. * Camera and monitor may not be properly paired; follow PIRING instructions. 	<p>Interference or poor reception</p> <ul style="list-style-type: none"> * Move the monitor closer to the camera; * The camera or monitor may be placed too close to many metal objects; * Other electronic devices may be interfering with the signal; * The battery power may be too low.
<p>Audio feedback (high pitched beeping)</p> <ul style="list-style-type: none"> * The camera and monitor may be placed too close; * The volume on the monitor may be set too high; 	<p>Frozen Picture on Screen</p> <ul style="list-style-type: none"> * Re-power the baby unit (plug out the adapter, then plug it into a socket again); * Press the RESET key at the back of parent unit;

11. MAINTENANCE

1. Clean your baby monitor with a slightly damp or anti-static cloth.

2. Never use cleaning agents or solvents.

12. DISPOSAL GUIDE FOR BATTERY AND PRODUCT

1. Do not attempt to repair or adjust any of the electrical or mechanical functions of the unit.

2. Remember to dispose of the product in an environmentally responsible way.

3. For proper collection and processing of these products, like them to the collection points designated by local authorities. You can also contact the store where you purchased the product.

Improper or incorrect use of batteries may cause corrosion or battery leakage, which could cause personal injury or damage to property. Use only the types of the batteries which are indicated in this manual.

CAUTION: Risk of Fire and Burns. Do Not Open, Crush, Heat Above 45 Degree C or Incinerate. Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, can result in an explosion.

- Labeled battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.

- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

- The battery shall not be exposed to excessive heat such as sunshine, fire or the like;

FRCC ISDE Statement

This device complies with Part 15 of the FCC Rules and with Industry Canada license exempt RSS (standard 1). Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Cet appareil est conforme à la partie 15 des règles de la FCC et aux normes RSS exemptées de licence d'Industrie Canada. Le fonctionnement est soumis aux deux conditions suivantes: (1) Cet appareil ne doit pas causer d'interférences nuisibles, et (2) cet appareil doit accepter toute interférence reçue, y compris les interférences pouvant entraîner un fonctionnement indésirable.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. The limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to take one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

This equipment complies with Canadian radiation exposure limits set forth for an uncontrolled environment.

Cet appareil est conforme à l'exemption des limites d'évaluation courantes dans la section 2.5 du cr-102 et conforme avec les 102 de l'exposition aux RF. Les utilisateurs peuvent obtenir des données complètes sur l'exposition aux champs RF et la conformité.

This equipment complies with Canadian radiation exposure limits set forth for an uncontrolled environment.

Cet équipement est conforme aux limites d'exposition aux rayonnements du Canada établies pour un environnement non contrôlé.

Radiation Exposure Statement for camera

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre corps.

Specific Absorption Rate (SAR) Information:

This Monitor meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. IS95 RF Exposure Information and Statement the SAR limit of Canada (ICES) is 1.6 W/kg averaged over one gram of tissue. Device types: Monitor has also been tested against this SAR limit. This device was tested for typical body-worn operation with the back of the Monitor kept 5cm from the body. To maintain compliance with IS95 RF exposure requirements, use accessories that maintain an 8mm separation distance between the user's body and the back of the Monitor. The use of fast clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not comply with this requirement may not comply with IS95 RF exposure requirements, and should be avoided.

Information sur le débit d'absorption spécifique (DAS):

Cette Moniteur répond aux exigences du gouvernement en matière d'exposition aux ondes radio. Les lignes directrices sont basées sur des normes élaborées par des organisations scientifiques indépendantes à travers des évaluations périodiques et approfondies de données scientifiques. Les normes comprennent une marge de sécurité substantielle conçue pour assurer la sécurité de toutes les personnes, quel que soit leur âge ou leur état de santé.

Cet équipement est conforme à l'exemption des limites d'évaluation des ondes radio (ICES) est

EU Declaration of Conformity (DCC)

Herby, Videotimes declares that the radio equipment type is in compliance with RED Directive 2014/53/EU.

The full text of the EU Declaration of conformity is available on the website: www.hellobaby.net.cn

Model: HB6339
Responsible Party(US): Startline LLC
Add: 22 Hazelwood Drive, Jericho, NY 11753 Tel: 1-516-681-3729
Authorized UK Representative(UK): Salwater web Ltd
Add: 10 progress road (glen in sea) SS95PX UK Tel: 44(0)20470 570 2999

Shenzhen Videotimes Technology Co., Ltd
701, Building 3, No. 1, Zhenhan Road, Gangkeng Community, Jihu Street Office, Longgang District, Shenzhen

Risk Group 1

WARNING: It is limited from this product. Do not store at operating lamp

Product tested against EN62471

8.7 VOX SETTING

This mode allows you to control the sound activation of your baby unit. If there is no sound around the baby unit within 30 seconds, it will stop audio transmission and turn off the screen of the parent unit. When the baby unit detects any sounds louder than the sensitivity you set, it will start transmitting the signal to the parent unit and display on the screen of the parent unit. To change the VOX level, please follow the below instructions.

1. Press key and the menu will pop up;
2. Press key until the menu will pop up;
3. Press key to select the desired VOX sensitivity level;
4. Press OK key to confirm setting.

8.8 DISPLAY BRIGHTNESS

1. Press the key and the menu will pop up;
2. Press the key until the menu will pop up;
3. Press key to select the desired brightness level from level 1 ~ 5.
4. Press OK key to confirm.

8.9 TEMPERATURE UNIT SETTING

1. Press the key and the menu will pop up;
2. Press the key until the temperature icon is highlighted;
3. Press key to select the desired volume level from level 1 ~ 5.
4. Press OK key to confirm.

8.10 VOX SETTING

This mode allows you to control the sound activation of your baby unit. If there is no sound around the baby unit within 30 seconds, it will stop audio transmission and turn off the screen of the parent unit. When the baby unit detects any sounds louder than the sensitivity you set, it will start transmitting the signal to the parent unit and display on the screen of the parent unit. To change the VOX level, please follow the below instructions.

1. Press key and the menu will pop up;
2. Press key until the menu will pop up;
3. Press key to select the desired VOX sensitivity level;
4. Press OK key to confirm setting.

8.11 VOX SETTING

This mode allows you to control the sound activation of your baby unit. If there is no sound around the baby unit within 30 seconds, it will stop audio transmission and turn off the screen of the parent unit. When the baby unit detects any sounds louder than the sensitivity you set, it will start transmitting the signal to the parent unit and display on the screen of the parent unit. To change the VOX level, please follow the below instructions.

1. Press key and the menu will pop up;
2. Press key until the menu will pop up;
3. Press key to select the desired VOX sensitivity level;
4. Press OK key to confirm setting.

8.12 VOX SETTING

This mode allows you to control the sound activation of your baby unit. If there is no sound around the baby unit within 30 seconds, it will stop audio transmission and turn off the screen of the parent unit. When the baby unit detects any sounds louder than the sensitivity you set, it will start transmitting the signal to the parent unit and display on the screen of the parent unit. To change the VOX level, please follow the below instructions.

1. Press key and the menu will pop up;
2. Press key until the menu will pop up;
3. Press key to select the desired VOX sensitivity level;
4. Press OK key to confirm setting.

8.13 VOX SETTING

This mode allows you to control the sound activation of your baby unit. If there is no sound around the baby unit within 30 seconds, it will stop audio transmission and turn off the screen of the parent unit. When the baby unit detects any sounds louder than the sensitivity you set, it will start transmitting the signal to the parent unit and display on the screen of the parent unit. To change the VOX level, please follow the below instructions.

1. Press key and the menu will pop up;
2. Press key until the menu will pop up;
3. Press key to select the desired VOX sensitivity level;
4. Press OK key to confirm setting.