

# 英语说明书(HB66)

说明书为折叠式  
尺寸: 540\*120MM  
材质: 100g双胶纸 (彩色)  
版本: V1.1  
类型: 环保

1.1 版本	修改内容 (1. Interference or poor reception改为reception; 2. 地址内容: F6, Building B, 改为 FL6, Building B, 3. 修改了FCC内容; )
--------	---

设计	审核	审批
王勇		
2020/04/07		


## HelloBaby®

Focus on Mom & Baby Care!

### User Manual

#### 1.4GHz Digital Wireless Video Baby Monitor

#### 2.4GHz Digital Wireless Video Camera



www.hellobaby.net.cn  
service@hellobaby.net.cn

Thank you for purchasing the HB66 HelloBaby Baby Monitor. With our baby monitor, you could see and hear your baby sleeping or playing in their room anytime.

Please retain your original dated sales receipt for your records. For warranty service of your HelloBaby product, you will need to provide a copy of your dated sales receipt to confirm warranty status. Registration is not required for warranty coverage.

**Please make sure the following included in your package**

Parent unit x 1	Camera unit x 1	Power Adapter x 2
User manual x 1	Wall-mounting kit x 1	

**1. SAFETY INSTRUCTIONS:**  
**CAUTION:** Keep the device away from children.  
**Strangulation Hazard:** Children have STRANGLED in cords. Keep this cord out of the reach of children more than 30 (9m) away. Never use extension cords with AC Adapters. Only use the AC Adapters provided.  
**Choking Hazard:** This product contains small parts, please be careful when unpacked and assemble the product.  
**Read and keep to instructions:** All the safety and operating in instructions should be read before the video baby monitor is operated. This product cannot replace responsible adult supervision.  
**Water and moisture:** This product is designed for indoor use only. The unit should not be exposed to rain, moisture, dripping or splashing. No objects filled with liquid should be placed on top of or beside the product, such as a glass or vase. This item should not be used near water.  
**DO NOT:** Use the appliance if the cord or plug is damaged. If your baby monitor is not operating properly or has suffered any damage, contact "HelloBaby" service center to request inspection and repair of the appliance in order to avoid any possible risk.  
**DO NOT:** Use the tool attempt to repair or adjust any of the electrical or mechanical functions of the unit. Otherwise, the guarantee will be made void.  
**Ventilation:** This baby monitor should be used on a bed, sofa, rug or similar surface that may block the ventilation openings, or be placed in an enclosed area such as a bookcase or drawer that may impede air flow.  
**Keep away from sources of heat:** This unit should be exposed to direct heat sources such as a candle, radiator, heat register, stove or other appliance that emits heat. The unit should not be left to direct sunlight.  
**Power source:** This unit should only be used with the AC power adapters included in this package (not for DC use).  
**Damage requiring service:** This unit should be serviced by qualified personnel only when: Objects have fallen or liquid has been spilled into the product;  
The units have been exposed to rain;

The units do not appear to operate normally or exhibits a distinct change in performance. The units have been dropped or the enclosure damaged.

**2. WARRANTY TERMS**  
We offer one year warranty from the original purchase date against defects in workmanship and materials. If you have warranty or support issues, please contact our after-sales service via email.


**3. INSTALLATION GUIDELINES**  
To use your parent unit and camera unit together, you have to establish a radio link between them, and the range will be affected by environmental conditions.  
\* Any large metal object, like a refrigerator, a mirror, a filling cabinet, metallic doors or reinforced concrete between the baby and parent unit may block the radio signal.  
\* The signal strength may also be reduced by other solid structures, like walls, or by radio or electrical equipment, such as TV, computers, cordless or mobile phones, fluorescent lights or dimmer switches.  
\* Use of other 2.4GHz product, such as wireless networks (Wi-Fi routers), Bluetooth systems, or microwave ovens, may cause interference with this product, so keep the baby monitor away at least 5ft (1.5m) from such products, or turn them off if they cause interference.

**4. PLACEMENT OF THE BABY MONITOR**  
The camera can be placed on the desktop or mounted on the wall. Don't place baby monitor on soft surfaces like blankets or on the corners of cupboards, shelves, etc. Keep the baby monitor away from heat sources such as radiators, chimneys, cookers and direct sunlight. Keep the baby unit away from TV sets, microwave ovens and radio. If interference occurs, move the camera to elsewhere.  
\* Place the camera within 6 feet (2 meters) of the area being monitored for optimum performance.


**5. GETTING STARTED**  
**5.1. TURN ON THE BABY UNIT:**  
1. Insert the DC plug of the power adapter into the DC Jack in the rear of the Baby Unit;  
2. Insert the other end of the power adapter into a suitable electrical outlet;  
3. Once the adapter is connected, the power LED will light up;  
**5.2. TURN ON THE PARENT UNIT:**  
1. Insert the DC plug of the power adapter into the DC Jack in the side of the parent unit;  
2. Insert the other end of the power adapter into a suitable electrical outlet;  
3. Press and hold the power key 3 seconds on the top of the parent unit;  
4. Once parent unit is on, the power LED will light up and the image will display on the LCD

**5.3. INFRARED NIGHT VISION (AUTOMATIC)**  
The infrared night vision function allows the camera to pick up images in dark or low light conditions. In this mode, only black and white images will be displayed on the monitor. The optimum image lies in where baby unit is 6ft (2m) away from object. The camera is in night vision mode, the icon will be displayed on the top of screen.


**6. PRODUCT OVERVIEW**  
**6.1. ICONS OVERVIEW**



**6.2. PARENT UNIT OVERVIEW:**



**6.3. BABY UNIT OVERVIEW:**



**6.4. LEFT KEY**  
Press once to pan the camera left by one step. Press and hold to pan continuously.  
**6.5. RIGHT KEY**  
Press once to pan the camera right by one step. Press and hold to pan continuously.  
**6.6. TWO-WAY TALK**  
Press and hold 2 key to enter two-way talk mode. A microphone icon will be displayed on the top of this LCD screen. Release the key to stop.  
**NOTE:** When you are in the two-way talk mode, the parent unit speaker is muted.

**6.7. DIGITAL ZOOM**  
Press and hold the key around 2 seconds to operate zoom in/out.  
**6.8. TWO-WAY TALK**  
Press and hold 2 key to enter two-way talk mode. A microphone icon will be displayed on the top of this LCD screen. Release the key to stop.  
**NOTE:** When you are in the two-way talk mode, the parent unit speaker is muted.

**6.9. MUTE OPERATION**  
**6.1. TURNING THE CAMERA AND BATTERY UNITS**  
The baby unit is pre-registered to your parent unit. You do not need to register it again unless the baby unit loses its link with the parent unit. To re-register your baby unit, or register a new baby unit, follow the procedure below:  
**NOTE:** Camera icon with means it is well registered. You should select and pair with the camera icon without sign.  
1. Press the MENU key then the menu will pop up.  
2. Press the key until the camera icon is selected by red box.  
3. Press OK key (enter into sub-menu), then press key to select your desired camera.  
4. Press key (enter into sub-menu), Press / key to select. then press key.  
5. When the icon is displayed on the LCD screen, press the P/B button on the back of camera.  
6. Once paired, Successful pairing icon shows on the LCD screen;  
7. If fails, repeat the above steps.  
**6.2. DELETE CAMERA**  
1. Press the MENU key and the menu will pop up.  
2. Press the key until the camera icon is selected by red box.  
3. Press OK key to enter into sub-menu, then press key to select the camera you want to delete.  
4. Press key to enter sub-menu; Press / key to select. then press key.  
5. Press key to select icon to delete the camera;  
6. Press key to confirm the option.  
**6.3. DISPLAY BRIGHTNESS**  
1. Press the MENU key when the menu will pop up;  
2. Press the key until the brightness icon is selected by red box;  
3. Press the key to enter into sub-menu.  
4. Press key to select the desired brightness level from level 1 ~ 5. (The default brightness level setting is level 3.)  
**6.4. TEMPERATURE UNIT SETTING**  
1. Press the MENU key when the menu will pop up;  
2. Press the key until the temperature icon is selected by red box;  
3. Press the key to enter into sub-menu.  
4. Press the key to select the "F" or "C" for setting temperature unit;  
5. Press key to confirm;  
6. Press key to exit.  
**NOTE:** The detected temperature range is 0~50°C.

6.5. REVERSE KEY  
Press and hold the power key for 3 seconds to turn on/off the parent unit.  
**6.6. VOX KEY**  
Press once to tilt the camera up by one step. Press and hold to tilt continuously.  
**6.7. DOWN KEY**  
Press once to tilt the camera down by one step. Press and hold to tilt continuously.  
**6.8. VOLUME**  
1. Press the key when the menu will pop up;  
2. Press the key until the volume icon is selected by red box;  
3. Press the key to enter into sub-menu.  
**6.9. DISPLAY BRIGHTNESS**  
1. Press the MENU key when the menu will pop up;  
2. Press the key until the brightness icon is selected by red box;  
3. Press the key to enter into sub-menu.  
4. Press key to select the desired brightness level from level 1 ~ 5. (The default brightness level setting is level 3.)  
**6.4. TEMPERATURE UNIT SETTING**  
1. Press the MENU key when the menu will pop up;  
2. Press the key until the temperature icon is selected by red box;  
3. Press the key to enter into sub-menu.  
4. Press the key to select the "F" or "C" for setting temperature unit;  
5. Press key to confirm;  
6. Press key to exit.  
**NOTE:** The detected temperature range is 0~50°C.

**6.4.1. TEMPERATURE ALARM SETTING**  
1. Press the key to select.  
2. Press the key to select.  
3. Press the key to select.  
**6.4.2. TEMPERATURE HI/LO ALERT LIMITS**  
1. Press the key to select (for HI/LO limits selected);  
2. Press the key to adjust the HI limit when (red) is selected;  
3. Press the key to adjust the LO limit when (red) is selected;  
**NOTE:** The High temperature alarm range is 32-40°C, and the Low temperature alarm range is 0-19°C. The High temperature alarm default setting is 36°C, and the low temperature alarm default setting is 14°C. When the temperature goes above or below the settings, the temperature icon turns red. It will flash to alert user by audible beep. Press any key on the parent unit to stop beeping and flashing.  
**6.5. LULLABY SETTING**  
You can soothe the baby to sleep by playing a gentle lullaby from the Camera unit.  
1. Press the MENU key and the menu will pop up.  
2. Press the key until the lullaby icon is selected by red box;  
3. Press the key to enter into sub-menu.  
4. Press the key to select one of the 6 available lullabies, you can pick single playback loop (off) lullaby playback 25 or more.  
5. Press key to confirm.  
**NOTE:** This lullaby default setting is OFF.  
**6.6. ALARM SETTING**  
1. Press the MENU key and the menu will pop up.  
2. Press the key until the alarm icon is selected by red box.  
3. Press the key to select.  
4. Press the key to select.  
5. Press the key to select.  
**NOTE 1:** The minimum unit is 0.5 hour. The maximum setting is 5 hours (7 levels).  
**NOTE 2:** Once the alarm is turned on, alarm icon will display on top of the screen.  
**NOTE 3:** The alarm default setting is OFF.  
**NOTE 4:** When the alarm is ringing, press any key on the parent unit to turn the alarm off.  
**NOTE 5:** If you don't turn off the alarm, the alarm will ring for 3 minutes. After three minutes the alarm will ring again for 1 minute. The alarm will ring for three times in total after this the alarm goes off.  
**6.7. VOX SETTING**  
This mode allows you to control the sound activation of your baby unit. When it is sound around the baby unit within 30 seconds, it will stop audio transmission and turn off the

screen of the parent unit. When the baby unit detects any sounds louder than the sensitivity level, it will start transmitting the signal to the parent unit again and turn on the screen of the parent unit. To change the VOX level, please follow the below instructions.  
1. Press the MENU key and the menu will pop up.  
2. Press the key until the VOX icon is selected by red box.  
3. Press key to enter into sub-menu, then press key to select desired level;  
4. Press key to confirm.  
**NOTE:** Low sensitivity level, the baby have to make a lot of sound before the VOX function will be activate;  
**NOTE:** High sensitivity level, the baby don't have a make a lot of sound before the VOX function will be activate;  
**6.8. LANGUAGE SETTING**  
1. Press the MENU key and the menu will pop up.  
2. Press the key until the language icon is selected by red box;  
3. Press key to enter into sub-menu, then press key to select desired level;  
4. Press key to confirm.  
**NOTE:** The default language setting is English.  
**6.9. TECHNICAL DATA**

Frequency	2403.5MHz~2484MHz
Parent Unit-Input	100-240VAC 50/60Hz
Output	5V DC 1A
Camera Unit-Input	100-240VAC 50/60Hz
Output	5V DC 1A
Operating Range	Up to 1000ft (300m) outdoor (line of sight) Up to 300ft (100m) indoor
Display	3.2" Diagonal TFT LCD
Battery (Parent Unit)	Li-ion 3.7V 950mAh (3.155Wh)
Battery Life	Up to 10 hours
Camera	Camera: 18.258cm Monitor: 18.181cm
Maximum power	Operation Temperature: -22°~104° (F°~40°) Battery Charging Temperature: -60°~104° (F°~42°)
Operation environment	Relative Humidity: 15%~95%

**10. TROUBLE SHOOTING**

No reception on the monitor	The power adapter may not be properly connected. Confirm that the camera and monitor are ON. Camera may be far away from the parent unit. Camera and monitor need to be properly paired, follow WARNING instructions. Move the monitor closer to the camera. The camera or monitor may be placed close to many metal objects. Other electronic devices may be interfering with the signal. The battery power may be too low. The camera and monitor may be placed too closed. The volume on the monitor may be set too high. Recharge the battery unit (plug out the adapter, then plug it into the socket again). Press the RESET key at the back of parent unit.
Interference or poor reception	The camera or monitor may be placed close to many metal objects. Other electronic devices may be interfering with the signal. The battery power may be too low. The camera and monitor may be placed too closed. The volume on the monitor may be set too high.
Audio Feedback (high pitched noise)	Recharge the battery unit (plug out the adapter, then plug it into the socket again). Press the RESET key at the back of parent unit.
Freeze Picture on Screen	Press the RESET key at the back of parent unit.

**11. MAINTENANCE**  
\* Clean your baby monitor with a slightly damp anti-static cloth.  
**12. DISPOSAL GUIDE FOR BATTERY AND PRODUCT**  
\* Do not attempt to repair or adjust any of the electrical or mechanical functions of the unit.  
\* Remember to dispose of the product in an environmentally responsible way.  
\* For proper collection and processing of these products, take them to the collection points designated by local authorities. You can also contact the store where you purchased the product.  
**FCC AND REGULATIONS**  
**FCC Part 15**  
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.  
**FCC Caution:**  
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
**FCC Statement:**  
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
—Reorient or relocate the receiving antenna.  
—Increase the separation between the equipment and receiver.  
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
—Consult the dealer or an experienced radio/TV technician for help.  
**Industry Canada**  
This device complies with Industry Canada licence-exempt RSS (Standard).  
Interference is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.  
Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'émission est soumise aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique susceptible d'affecter son fonctionnement.  
This equipment complies with Industry Canada radio equipment limits set forth in an uncontrolled environment.  
Cet équipement est conforme à l'exposition aux rayonnements Industrie Canada limites établies pour un environnement non contrôlé.  
The SAR limit adopted by USA and Canada is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The highest SAR value reported by the Federal Communications Commission (FCC) and the Industry Canada (IC) for this device when it is properly worn on the body is 0.210W/kg.  
The device complies with the RF specifications when the device is used near a distance of 10cm from your body. Ensure that the device accessories such as a device case and a device holster are not composed of metal components. Keep your device 0.1m away from your body to meet the requirement earlier mentioned.  
This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 0.1m must be maintained between the user's body and the handset, including the antenna. The parts like clips, holsters, and similar accessories used by this device should not contain any metallic components.  
To meet these accessories that do not meet these requirements, do not comply with RF exposure requirements and should be avoided. Use only the supplied or approved accessories.  
Le limite SAR adoptée par les États-Unis et le Canada est de 1,6 watts/kg (W/kg) en moyenne sur un gramme de tissu. Le valeur SAR la plus élevée signalée à la Federal Communications Commission (FCC) et à l'Industrie Canada (IC) pour ce type d'appareil lorsqu'il est porté sur le corps est de 0,210 W/kg.  
L'appareil est conforme aux spécifications RF lorsqu'il est utilisé à une distance de 0 mm de votre corps. Assurez-vous que les accessoires de l'appareil, tels qu'un étui ou un étui, ne sont pas composés de composants métalliques. Gardez votre appareil à 0,1 m de votre corps pour répondre aux exigences réglementaires. Pour se conformer aux exigences d'exposition aux RF, une distance de séparation minimale de 0,1 m doit être maintenue entre le corps de l'utilisateur et le combiné, y compris l'antenne. Les clips de ceinture, les étuis et les accessoires similaires utilisés par cet appareil doivent contenir des composants métalliques. Accessories portés sur le corps qui ne répondent pas à ces exigences peuvent ne pas être conformes aux exigences d'exposition aux RF et doivent être évités. Utilisez uniquement l'accessoire fourni ou approuvé.

L'appareil est conforme aux spécifications RF lorsqu'il est utilisé à une distance de 0 mm de votre corps. Assurez-vous que les accessoires de l'appareil, tels qu'un étui ou un étui, ne sont pas composés de composants métalliques. Gardez votre appareil à 0,1 m de votre corps pour répondre aux exigences réglementaires. Pour se conformer aux exigences d'exposition aux RF, une distance de séparation minimale de 0,1 m doit être maintenue entre le corps de l'utilisateur et le combiné, y compris l'antenne. Les clips de ceinture, les étuis et les accessoires similaires utilisés par cet appareil doivent contenir des composants métalliques. Accessories portés sur le corps qui ne répondent pas à ces exigences peuvent ne pas être conformes aux exigences d'exposition aux RF et doivent être évités. Utilisez uniquement l'accessoire fourni ou approuvé.  
**Risk Group 1**  
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator you're body.  
For Camera:  
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre corps.  
For Camera:  
This equipment complies with the EU declaration of conformity is available on the website: www.hellobaby.net.cn  
Trade Name: HelloBaby  
Model: HB66TX(Monitor)/HB66TX(Camera)  
Responsible Party: Startline LLC  
Address: 220 Broadway, Jericho, NY 11753  
Tel.: 516-681-3729  
HWV: HB66  
HWV: HB66TX  
Shenzhen Vioelectromics Technology Co., Ltd  
Room 101, Building H, Changhuihong Technology Building, Shihua Road, Fubao Commune, Wucai Street, Futian District, Shenzhen, China.  
Impressor or incorrect use of batteries may cause corrosion or battery leakage, which could cause personal injury or damage to property. Use only the types of batteries which are indicated in this manual.

**CAUTION: Risk of Fire and Burns. Do Not Open, Crush, Heat Above 45 degree C or Incinerate. Follow Manufacturer's Instructions.**

Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.  
Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.  
A battery subjected to external low or pressure that may result in an explosion or the leakage of flammable liquid or gas.  
The battery shall not be exposed to excessive heat such as sunshine, fire or the like;

**Risk Group 1**  
WARNING IR emitted from this product. Do not stare at operating lamp.  
Product tested against 6267621

**WARNING**

Strangulation Hazard: Children have STRANGLED in cords. Keep this cord out of the reach of children (more than 3 ft (0.9 m) away). Do not remove this tag.

**AVERTISSEMENT**

DANGER D'ÉTRANGLEMENT: Des enfants se sont ÉTRANGLÉS avec des cordons électriques. Gardez le cordon électrique hors de la portée des enfants (à plus de 0,9m/3 pi plus l'enfant). Ne pas enlever cette étiquette.

Impressor or incorrect use of batteries may cause corrosion or battery leakage, which could cause personal injury or damage to property. Use only the types of batteries which are indicated in this manual.

www.hellobaby.net.cn

Ver. 1.1  
Made in China