

**PISEN**

**Portable Wireless Bluetooth Speaker**

SPK-B003

User manual

http://en.pisen.com.cn


Thank you for purchasing the Portable Wireless Bluetooth Speaker supply product of PISEN. Please read this guide carefully to assure safe and satisfactory operation and also keep it properly for future reference.

**Technical specification**


Portable Wireless Bluetooth Speaker	
Product Name	Portable Wireless Bluetooth Speaker
Model	SPK-B003
Input	5V=2A
Power	2.5W*2@THD+N=10%
Bluetooth version	Bluetooth 4.0
Volume	70±2mm*160±2mm
Weight	404±2g
Battery capacity	2500mAh
Battery charge limited voltage	4.2V
Support protocol	AD2P/AVRCP/HFP
Standards	GB8898-2011
Waterproof grade	IPX6

2

**Diagram of product interface**



**Diagram of control key**



3

Audio input: connect external devices (such as mobile phones, tablet PCs, etc.) with the 3.5mm AUX-in port by audio cable to play audio files.




Diagram of connecting phone to AUX in port to play music



Charging diagram

4

**Trouble shooting**

If the following "operations" cannot rule out your failure, please stop using this product and contact your dealer or PISEN customer service center.

1. What should I do when Bluetooth can not be connected?  
Answer: Please confirm your Bluetooth audio (mobile phone or computer) have built-in Bluetooth device, if yes, please open the Bluetooth mode and search for Bluetooth speakers to connect devices or restart Bluetooth speakers.
2. What should I do when the operation of the machine does not respond?  
Answer: Please confirm whether the Bluetooth speaker has electricity, if not, please charge in time.  
Note: If all operations above are unable to resume work, please contact customer service personally.

**Precautions**

- Do not throw, squeeze, disassemble or pierce this product.
- Do not place the product on the carpet, heaters and fabric materials, or expose it to direct sunlight.
- Do not throw this product in fire, water or corrosive liquid.
- Do not charge the speaker beyond the rating.
- The highest temperature should not exceed 45 °C. When charging this product.
- If the battery is not properly replaced, there will be an explosion hazard, and can only be replaced by the same type or equivalent type of battery.
- Unless with the supervision and guidance of professionals to ensure the safety of users, the following persons (including children) are not suitable for the product: people whose bodily functions or mental capabilities were degraded, people lacking awareness and operating experience of the product. Always supervise children to ensure safe use.

⚠ Do not put the battery into fire  
Do not use the battery after it immersed in Water  
CAUTION: Do not disassemble and damage the battery

5

**FCC STATEMENT :**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
  - (2) This device must accept any interference received, including interference that may cause undesired operation.
- Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**RF warning statement:**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

**PISEN**

Made by Guangdong PISEN Electronics Co., Ltd.  
Address: Jintang Industrial Park, Henggang Town,  
Longgang District, Shenzhen, P.R.China  
Factory Telephone: 86-755-28504090



**Use instructions**

**1. Key control**

- ① The power button("⏻" key): long press the button for 3 second to turn it on; another 3-second long press to turn it off while working;
- ② Bluetooth/phone composite button("📶" key): After pairing successfully in Bluetooth mode, long press the button for 3 second to re entered the pairing state; When phone calls coming in under the Bluetooth connection, "bell" prompt, short press to answer the phone, press again to hang up; directly long press to reject;
- ③ Volume -/Previous("⏮" key): long press the button for previous song, short press is volume -
- ④ Volume +/Next("⏭" key): long press the button for next song, short press is volume +
- ⑤ Mode switch (the "M" key): Every short press will switch the sound source when there is a variety of audio situations, the switch key only in the Bluetooth mode is invalid.

**2. Mode switching operation**

Four switching modes: An external audio source mode(wired), Bluetooth connection mode, USB flash disk mode, TF card mode; after opening the power switch, the default is the Bluetooth mode; when there is a need to switch to the other mode, just press the mode key switch (Mode), each click will switch to another switchable mode.

- ① Boot automatically into the pairing state, open the Bluetooth of mobile phone, search "PISEN-B003" to connect, No matter speaker connection or disconnection will have "Di" hint.

7

- ② When speakers work, and the peripheral interface (3.5mm AUX audio input interface) access source, automatically switch into external mode, if there is a need to change mode, you need to press the mode button switch (mode).
- ③ When the USB flash disk is inserted, it can be read directly (maximum support 32G); if there is a need to change mode, you can press the mode button switch (mode);
- ④ The TF Card (up to 32G) can be directly read when being inserted, if you need to change to other modes, press the mode button switch (mode).

**Note:** ① Among all modes, when a call comes, the original mode will interrupt in order to answer call first, then back to the original state after hanging up; when the device is on and not connected (no sound) for 10 minutes, the speaker will automatically shut down; ② all modes will work under power-on state, when the TF card, USB disk, external audio have no content play, then after a time delay it will switch automatically to the Bluetooth mode.

**LED lamp**

- After turning on, the blue light flashes and entering pairing mode, the blue light will keep on after pairing successfully;
- After turning on, when charging it under unpaired state, 2 lights will show the working state: blue light keeps flashing and red light is on and brighter; once being fully charged, all LED lamps will be off.
- After turning on, when charging it under paired state, the red light keeps on blue light keeps on faintly, then turns bright when the power is full;
- The blue light will flash 5 times continuously and then keeps on when enter TF card mode, USB flash disk access mode and external mode, when the remaining power is low, lights flash red.

8

**The name and concentration of the hazardous substance in the products**

Parts Name	Hazardous Substance					
	Pb	Hg	Cd	Cr <sup>6+</sup>	PBB	PBDE
Circuit Board Assemblies	X	○	○	○	○	○
Hardware Parts	X	○	○	○	○	○
Plastic Parts	○	○	○	○	○	○
Battery	○	○	○	○	○	○
Fittings	○	○	○	○	○	○

○: Indicates that the concentration of the hazardous substance in all homogeneous materials in the parts is below the relevant threshold of the GB/T 26572 standard.

X: Indicates that the concentration of the hazardous substance of at least one of all homogeneous materials in the parts is above the relevant threshold of the GB/T 26572 standard.

Notes: The environment-friendly use period identified in this product is only applicable to the product which is working under the conditions stipulated in the user instruction manual.

this product still meets requirements of EU RoHS directive 2015/863/EU

Portable Wireless Bluetooth Speaker	× 1
3.5mm Audio Cable	× 1
Micro USB charging cable 800mm	× 1
User manual	× 1
Mountaineering buckle	× 1

9

**Warranty card**

**Warranty period:**

The quality warranty period of this product is effective within 12 months since the day when it is purchased.

**Free service:**

If any failure arises due to the quality of the product within the warranty period, the user may contact with the dealer and enjoy free warranty service by presenting this warranty card and purchase voucher.

**We will not offer free repair service under the following circumstances:**

1. No warranty card is presented or the product label is damaged.
2. Damage caused due to disassembly by the user.
3. Failure caused due to water inlet or falling and man-made mechanical damage.
4. Failure or damage caused due to force majeure.

**Customer service information**

Name of customer	
Address	
Tel.	
Name of product	
Model of product	
Date of purchase	
SN	
Seller	
Repair record	

10