




# CL-680 MANUAL



1. Power on/off, Mode switch button.
2. Play/Pause, FM Scan Button
3. Previous Track/Radio Station Button
4. Next Track/Radio Station Button.
5. Volume Increase Button
6. Volume Decrease Button
7. Music Wall Light Control Button
8. LED Light Control Button.
9. Reset Button
10. Aux In
11. 12V DC Input Charge Port
12. 5V USB Output Charge port
13. Radio Antenna
14. Bluetooth Indicate Light
15. Charge Indicate Light

## 1. Turn ON, Turn OFF.

Press and hold Button 1 for 2 seconds to turn on or turn off the device.

## 2. Bluetooth Speaker Mode

1. Turn on Cuboid, the device enter into Bluetooth mode default or short press button 1 switch it to Bluetooth mode. There is a tone "Bluetooth" indicate you that the device entered Bluetooth mode.
2. When your Bluetooth enabled device finds the speaker, select "CL-680" from the list of found devices.
3. If required, enter the password 0000 (four zeros). Select OK or YES to pair the two units.
4. A tone will sound in indicating a successful pairing. The BL indicator will remain solid, indicating that you are connected.

## FM

1. Press the "MODE" button on the speaker switch to FM RADIO mode. There is a tone "FM Radio" indicate you that the device entered FM Radio mode.
2. Press and Hold button 2 for 2 seconds the device will automatically search FM radio station. The device will play the first station it found after finish auto search.
3. Press button 3,4 select station, press 5,6 adjust volume.

## Aux wired speaker

1. Turn on the cuboid. In Bluetooth or FM mode, if the auxiliary cable is inserted into the AUX IN port it will automatically change to Aux in mode
2. Connect one end of the included 3.5mm auxiliary cable to the AUX IN port in Cuboid and the other end to an external device's.
3. Open a media player on your device and press PLAY to start playing your music.
4. Use the controls on your connected device to select music and adjust volume.

## Music Wall Light

Press button 7 turn on/off music wall light or change mode of music all light.

## LED Light

Press button 8 turn on/off LED light or adjust brightness of LED light.

## Technical specific

- \*Driver: 4 ohm
- \*Speaker Power: 12W
- \*LED Light Power: 5W
- \*Power supply: DC12V, Li-on battery, 8800mah.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment □□

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.