



To switch off press & hold (1) until prompted "goodbye". If you lose power on your Bluetooth T device or move out of range your Retrobuds will say "disconnected", once this happens move closer to your device and press (1), switch OFF & ON, or press and hold (1) to reactivate pairing mode. Note retrobuds will connect automatically to the last connected Bluetooth device

once powered on. Т 





FIT: gently adjust the loop length to create the best length to fit the undercut of your inside ear, it should be just long enough to create a little tension and hold firmly in place.

It's important for best sound quality that you use the correct ear tip size. To change ear tip sizes; simply peel away & replace with bigger or smaller ear piece included. Make sure the ear tip is secure all the way around before placing into your ear.

WEAR: Secure to your clothing with the magnetic clip.

\_ \_ \_ \_

STOW: open the magnetic clip, wrap your cable around and close the clip to make tangle free and pocket size. т

## General guidelines: Keep away from high temperature or prolonged exposure to direct sunlight. Ao not discostemble. Do not drap the product. Keep out of reach of children. Waranty: Your BOOMPODS product is guaranteed against any defects in material or workmanship for one full year from the date of original purchase providing it has not been dissembled and it has not suffered accidental damage such as a knock or immersion in water, etc. The device must be used in accordance with the user manual. The warrantly is subject to presentation of the original invoice or receipt from the retailer and does not apply to normal wear and tear or to any device that has been misused or tampered with. If should be returned to the local service centre, the service centre will not bear any shipping cost of the returned item. Please check www.boompods.com.for.your.local.service.centre. Preside check www.boothipbas.com in or your local service certrie. FCC Statement This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if no installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not to radio or television reception, which can be determined by turning the equipment off and on, the user's encouraged to try to correct the interference by one or more of the following measures:

- The readoming includes. Rearient or relacate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authinity to operate the equipment.