# 此页非印刷&刻录页,正式文件请删除此页

# 使用说明书

成型	75×150mm-公差±2mm		更新		
尺寸			日期		
展开			2019-	初	
尺寸			07-08		
材质	157g 双铜纸				
工艺	单黑印刷				
成型	风琴折-5 折				
方式					
适用	SP20A-G 智能笔使用说明书				
版本	V1.0				

更新日志

更新	更新内容	版本
日期		
2019-	初版发行	V1.0
07-08		

Note: All the pictures in this manual are for reference only, subject to our available products

## ✤ Statement

a. Intellectual property right statement: The hardware design and software of this product are covered by the patents. Anyone who reproduces this product or the content of the instruction without the authorization of the Company shall assume legal liabilities.

b. This instruction is provided for reference only, and the functions shown in the manual may differ from the actual functions of the product the customers actually purchase and receive.


c. The picture is for reference only. Please subject to the actual product. The Company reserves the rights to improve and change the appearance and design of the product without notice.


Safety Warnings and Precautions

Before using and operating this device, please read thoroughly and comply with the following precautions in order to prevent accidents or abnormal operation.

- 1) Operating Environment
- Do not place the product in dusty and  $\geq$ humid environments in case of internal circuit fault.
- Do not place the product near heating devices(such as electrical heater).
- $\rightarrow$  Normal operating temperature is 0-40°C, normal operating humidity is 10%-90%RH.
- 2) Children Safety
- The product and accessories may contain some small-part. Please place them beyond the reach of children in avoidance of swallowing danger.

- 3) Water Precaution
- The product is not waterproof, Please keep it dry.
- 4) Maintenance
- Please contact professional service personnel for maintenance services.
- Do not insert any sharp or pointed  $\geq$ object into the device.
- Prevent the device from falls and  $\geq$ collisions with other objects.which may cause damages.





User Manual


## Product Function

## (1) Smart pen

1.

- Eraser
- Previous page
- Indicator light
- Next page
- Air Mouse
- Pen nib

② charger



- Magnet
- 2 USB cable
- 3 Indicator light
- 4 Wireless charging port

# 2. Connection


The charger is magnetically attached to the Interactive Intelligent Panel.

After the charger is being inserted into the Interactive Intelligent Panel, the button function of the smart pen can be used.

Note: The charger cannot be connected to the USB port of the external PC module.

1 Android channel As show, connect the charger to the USB port of the Interactive Intelligent Panel through the USB cable.

- Connect to the front USB 1)
- 2) Connect to the Side USB



.

Moving Speed

a.

b.

# 3. Pairing& Unpair



# ③ Pairing

Long press "Previous page" and "Air Mouse"buttons, yellow Indicator light on, if Yellow indicator flashes five times when loosened, matching success. The Smart Pen Setting interface displays the paired pen information.

Long press the "Previous page" and "Air Mouse" buttons, and the yellow indicator light will be on. When the button is loosened, the indicator light if display yellow and white indicator light, means over 4 pens

matching to the system. It is necessary to cancel the paired pens in order to match the new ones successfully.

# **④** Unpair

- Press smart pen "Next page " and a. "Air mouse" buttons at the same time to unpair the Interactive Intelligent Panel.
- Or Click the Disconnect button in the h Smart Pen Setting interface to unpair the Interactive Intelligent Panel.

# 4. Charging

The smart pen can be automatically wireless charged by inserting it into the charger that is connected to the Interactive Intelligent Panel.

## Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this harmful eauipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the

### following measures:

• Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### FCC Caution:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### Non-modification Statement:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### ISED Statement

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) This device may not cause interference, and

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.