




APPENDIX H


: USER'S MANUAL

I. Application

- A system that receives the battery voltage in the ACC ON state of the vehicle and drives the wireless charging system to transmit power to the target cellular phone with an output of 5W.
- Can be used with Qi certified internal mobile phone or wireless charging exclusive accessory case.



- Application method : Magnetic induction (5W)
- Module size : 77.4mm x 137.5mm x 23.2mm
- Module weight = 258g
- A13 Standard coil




TOP. View

SIDE. View

2. User manual

➤ Wireless charging module Main Connector



| No. | 신호명 | 비고 |
|-----|------------------|-------------------|
| 1 | ACC | (Power) |
| 2 | ACC | (Power) |
| 3 | N.C(No. Connect) | |
| 4 | N.C(No. Connect) | |
| 5 | B-CAN_LO | |
| 6 | B-CAN_HI | |
| 7 | N.C(No. Connect) | |
| 8 | LED_GREEN | LED Indicator와 연결 |
| 9 | LED_AMBER | LED Indicator와 연결 |
| 10 | GND_LED | LED Indicator와 연결 |
| 11 | N.C(No. Connect) | |
| 12 | GND | |

2. User manual

➤ Single Item Wireless Charging Module Operating Conditions

- 1) Power line connection : No.1,2 Pin(12V), No.12 Pin(GND)
- 2) Power supply
- 3) If you put a wireless rechargeable mobile phone on top of the charger


➤ Actual car wireless charging module operating condition

■ How it works

1. Close all doors of the vehicle
2. Switch the vehicle's power to ACC or higher
3. Put a wireless rechargeable cell phone on the tray

■ Development and Results

1. During normal charge operation
→ Amber LED on indicator is displayed.
2. At full charge 100%
→ Green LED on indicator is displayed.
[Green LED does not display depending on the type of mobile phone]
3. In case of internal problem
→ Amber LED on the indicator Flashes at 1 second intervals.



2. User manual

(a) Interference potential of the device or system

- Smart-key frequency interference protection
- To avoid interference between the wireless charger frequency and the Smart-key frequency band, stop the wireless charging when the door is open or the Smart-key is in the LF operating state.

(b) System Maintenance

- You can receive information about fault from the car and it can be repaired at the service center (10-year, 100,000-mile warranty)
- Functional inspection through total inspection of single parts

(c) Simple actions that users can take to correct interference.

- Function that automatically prevents interference
- User wants to stop wireless charging, use USM(User Setting Mode) to select the charging on/off function

Compliance Statement

Regulatory Compliance

IMPORTANT NOTE: FCC Compliance statement

This device complies with part 18 of the FCC Rules.

IMPORTANT NOTE: FCC RF exposure statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with a minimum distance of 20 cm (7.8 inches) between the antenna and your body.

Users must follow the specific operating instructions for satisfying RF exposure compliance.

Industry Canada

This device complies with RSS-216 of the Industry Canada Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Ce dispositif est conforme à la norme CNR-216 d'Industrie Canada applicable aux appareils radio exempts de licence. Son fonctionnement est sujet aux deux conditions suivantes: (1) le dispositif ne doit pas produire de brouillage préjudiciable, et (2) le dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

IMPORTANT NOTE: (For mobile device use)

Radiation Exposure Statement : This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

NOTE IMPORTANTE: (Pour l'utilisation de dispositifs mobiles)

Déclaration d'exposition aux radiations : Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

User's Caution Statement

Any changes or modifications to the equipment not expressly approved by the party responsible for compliance could void user's authority to operate the equipment.

Toute modification ou modifications non expressément approuvées par la partie responsable de la conformité pourraient annuler l'autorité de l'utilisateur de faire fonctionner cet équipement.