

# R/C Car RC1156



**STUNT CAR:**  
TURN STUNT CAR ON/OFF BY PRESSING AND HOLDING POWER BUTTON.

## SECTION 1

Watch Controller:

Turn watch on/off by pressing and holding power button.

## SECTION 2

Click finger button to switch between driving modes.  
Double-click finger button to switch car to volume mode (for adjusting volume).  
Click power button on watch to pause play.  
Click again to resume play.




Press and hold finger button for demo mode.  
Release button to resume normal play.  
Note: The fourth LED (far right) will light up when charging and turn off when charged.



## SECTION 3

Driving Mode 1:


In mode 1, the first LED (far left) will light up. Car will remain stationary when watch is kept level.  
Tilt watch in any direction to make car move accordingly.



In mode 1, the car will perform lateral drifts when watch is tilted left and right.

## SECTION 4

Shake watch to raise and lower car body.



## SECTION 5


Driving Mode 2:

In mode 2, the second LED (middle left) will light up.  
Car will remain stationary when watch is kept level.  
Tilt watch in any direction to make car move accordingly.  
In mode 2, the car will perform 360° spins when watch is tilted left and right.



## SECTION 6

Shake watch to raise and lower car body.



## SECTION 7

In mode 3, the third LED (middle right) will light up.  
This mode is for adjusting the car's volume settings.  
Tilt watch left and right to adjust volume.



changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.