# Let's get started.

GL·ÎNet

Puli / GL-XE300C4, GL-XE300C6 4G LTE Wireless Router

# **SETTING UP**



### Insert Cards & Power On



After Inserting cards, turn on the router by pressing the power button



# Connect via Wi-Fi

# Wi-Fi Connect via LAN

Connect to the Wi-Fi called GL-XE300-xxx, and input the default Wi-Fi password goodlife, which is also printed on the bottom of the router.





Default password is *goodlife* 




# Set up Router

Visit http://192.168.8.1 in your browser to set up your router; start by choosing your preferred language.

(≡ http://192.168.8.1 Č)

# **SUPPORT**



## Repair / Reset

If you cannot access the web-based setup page or cannot connect to the router, you can press the **Reset** button:

- Press and hold for 3 seconds, and then release to repair your network.
- Press and hold for 10 seconds, and then release to reset the router to factory settings. All user data will be cleared.



### **Technical Supports**

- For more detailed and updated instructions, please visit our website docs.gl-inet.com
- For further questions, you can get help from the following ways:
  - Email to support@gl-inet.com
  - Message us on our Facebook: facebook.com/gl.inet.wifi/
  - Post questions in our forum: forum.ql-inet.com
  - Ask professionals in other forums e.g. OpenWrt, LEDE or other professional

# **WARRANTY**

- We provide one year limited warranty for routers and 3-month limited warranty for accessories. Extra warranty may apply according to the local law in which the product purchase took place.
- Highly recommend using the included 5V/2A power adapter.
- Any damage to the router caused by not following the instructions will render this warranty null and void
- Any damage to the router caused by modifying the PCBA, components or case will render this warranty null and void.
- Issues caused by the use of third-party firmware may not get official support from us. Any damage to the router caused by inappropriate use, e.g. inappropriate voltage input, high temperature, dropping in
- the water or on the ground will render this warranty null and void.
- Pictures on the instructions are only for reference. We reserve the right to change or modify these materials without
- Keep your device within the recommended operating temperature (0°C to 40°C). Recommend storage temperature for your device is between -20°C to +45°C. Please note lower or higher temperatures may cause damage to the device.
- To avoid battery or device failure, do not remove or replace the non-removable battery.
- The device should shut down due to overheating (in the event the battery temperature exceeds 60°C).

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
   (1) This device may not cause harmful interference, and
   (2) This device must accept any interference received, including interference that may cause undesired operation.
   2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to concernate the equivalence.

operate the equipment.

3. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generate uses and can addate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- netretence by one or more of une clouwing measures.

   Receinatior relocate the receiving antenna.

   Increase the separation between the equipment and receiver.

   Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

   Consult the dealer or an experienced radio/TV technician for help important announcement.

### Radiation Exposure Statement

Radiation Exposure Statement. This device meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through personic and thorough evaluation of scientific studies. The standards include a substantial saleful, wragin designed to assure the safety of all persons regardless of age or health. The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: GL-XE300C4 and GL-XE300C6 have also been tested against this SAR limit of USA (FCC) is 1.0 W/kg averaged over one gram of tissue. Device types: GL-XE300C4 and GL-XE300C6 have also been tested against this SAR limit of USA (FCC) is 1.0 W/kg averaged over one gram of tissue. Device types: GL-XE300C4 and GL-XE300C6 have also been tested against this SAR limit of USA (FCC) as the same time of the same time.

The Equipment named above is confirmed to comply with the requirements setout in the European Council Directive on the Approximation of the Laws of the Member States relating to RED (2014/52/EU). The equipment passed the test which was performed according to the following European standards: ST. 11.0 EN 301 489-17 V.2.2; EN 301 489-52 V.1.1.0 This product uses WIFI 2.4GHz Operating Frequency is 2400-2483.5MHz. The Noduct comply with Directive 2011/65/EU and ENSOS66-2012 ReACGO-2493.5MHz. The Product comply with Directive 2011/65/EU and Exercise Complex of the Product comply with Directive 2011/65/EU and Exercise Complex of the Product comply with Directive 2011/65/EU and Exercise Complex of the Product comply with Directive 2011/65/EU and Exercise Complex of the Product Complex of the Product

# Hong Kong Office

GL Technologies (Hong Kong) Limited Unit 203, 2/F, Building 19W, 19 Science Park West Avenue, Hong Kong Science Park, Pak Shek Kok, N.T., Hong Kong

Shenzhen Guanglianzhitong Tech Co., Ltd. Room 305 - 306, Skyworth Digital Building, Shiyan Street, Baoan District, Shenzhen, China, 518000 (+86-0755-86606126)

Shenzhen Office

