

Quick Start Guide




YoSmart LED Bulb Mini Remote


Control your Bulbs by Remote




Do Not Connect to a Dimmer
YoSmart Bulb dims using YoSmart remote




Leave Your Fixture On.





KingTing Tech. Corporation

Fully charge your Remote before use.





Linking

Before use, the LED bulb needs to link with the remote.

 Turn off the LED Bulb by switch or Unscrew the LED Bulb



2. Select the LED Bulb group by tap the button a or b or c, then press and hold LINK button for 5 seconds, Remote enter linking status.



2. Press and hold the LINK button for 5 sec

3. Turn your fixture on and when prompted, screw in the LED Bulb.



4. Linking complete, the LED Bulb will flash 6 times.



You can now control your LED Bulb from the remote.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.