


Quick Start Guide

F9 HIT BOOM


HIT BOOM SPECIFICATION

Product Name	HIT BOOM	SNR (Signal to Noise Ratio)	>70dB
Model No.	F9	Bluetooth® Distance	<100ft
Bluetooth® Wireless Version	V4.2	MIC Sensitivity	-42±3db/Omnidirectional
Support Bluetooth® Protocol	HFP, HSP, AVRCP, A2DP	Charging Time	About 3 hours
Speaker Driver	ø 45mm, 2*10W(20W)	Waterproof Rate	IPX7
Frequency Response	70-20kHz	Charging Input	<DC 5V/2A
Sensitivity	>85db@1m1kHz Max Volume	Net Weight	~670g
Rated Impedance	4Ω		

In The Package



HIT BOOM



3.5mm Audio Cable




USB Charging Cable



Quick Start Guide

Quick Start Guide 01



Button Controls

Power On/Off	Press and hold "⏻" button for 2 seconds
Volume Up	Short press "+" button
Volume Down	Short press "-" button
Previous Track	Long press "⏮" button
Next Track	Long press "⏭" button
Play/Pause	Short press "⏸" button
Answer/End A Call	Short press "☎" button
Reject A Call	Long press "☎" button
Enable/Disable Tapping Sound Effects	Long press "+" and "-" button simultaneously
Enable/Disable Colorful Light Bar	Short press the "🔦" button

Power Indicator

Power indicator light flash white	During charging
Power indicator light flash white quickly	Low battery
Power indicator light is on	Fully charged

Quick Start Guide 02

Light bar (Bluetooth mode)

Power on	Solid on
Pairing	Flash red and blue alternately
Paired	Colorful breathing light cycles through
Tap function on/off	Red light flashes 3 times

Note:
1. If your device is not playing music nor is connected, the speaker will not be turned off.
2. Close the waterproof rubber cover before you put the speaker into water to improve its waterproof function.

Light bar (AUX mode)

AUX Mode	Solid red for 5 seconds
Play	Cycle through multiple colors with the music, and driver lights flash

Tapping Light Mode

Front	Driver lights flash 1s	Top	Light bar and driver lights flash 1s
Left	Drive lights flash 500ms	Bottom	Light bar and driver lights flash 1s
Right	Light bar flashes quickly		

Quick Start Guide 03

Pairing a Bluetooth device wirelessly

Please make sure your HIT BOOM has enough battery power. Bluetooth pairing may fail when the battery is too low.

1. Turn on your HIT BOOM and it will automatically enter pairing mode.
2. Turn on your device's Bluetooth and tap HIT BOOM and pair. You will hear a prompt tone when it is successful. Then you can play music.

When you turn on your HIT BOOM the next time, it will automatically try to connect to the last device used.

Note: If you want to pair it with a different device, disconnect the existing device.

Pairing two speakers to create a stereo pair (TWS mode)

You can pair two HIT BOOM together to create left and right channels and enjoy stereo sound.

1. Turn on both speakers. Their light bar will flash, indicating they are ready to pair.
2. Press and hold the Bluetooth button of one of the speakers until you hear a beep, then you will hear a prompt tone of "Ding Ding Ding", indicating the two speakers are paired successfully. Do not turn on your phone's Bluetooth function before the pairing is successful.
3. Turn on your device's Bluetooth and tap "HIT BOOM" and pair, it will automatically connect one of the speakers. When the pairing is completed, you can enjoy wireless stereo sound from both speakers.

Note:

1. Before pairing two speakers together, please make sure that the two speakers are not connected to other devices via Bluetooth. If one of them is connected with another device, they will fail to pair with each other.
2. Please note that only one speaker can control the volume. (This speaker is called the main speaker)
3. For a better listening experience, please put the speakers within 50 feet of each other. To achieve the best result, place the speakers in an open area without barriers.

Quick Start Guide 04

Wireless Hands-free Phone Call Function

Hands-free functions are only available for Bluetooth-enabled smartphones.

- Short press "☎" button to answer an incoming call. Short press again to end the call.
Long press "☎" button to reject an incoming call.

When two HIT BOOM are successfully paired, the sound will only be transmitted to the main speaker.

Connecting a non-Bluetooth audio device with the 3.5mm cable

1. Make sure your HIT BOOM battery has enough power and turn on the Bluetooth speaker.
2. Plug one end of the cable into your device's headphone jack and the light bar will be solid red for 5 seconds. Insert the other end into HIT BOOM.
3. Turn on your HIT BOOM Bluetooth speaker and you can start playing music.

Note: When the audio cable is plugged into the speaker, the Bluetooth function will not be available.

Safety precautions

1. Do not charge by a water source or in the rain to prevent electric shock.
2. Please follow the instructions for all operations and use.
3. Do not damage the cable, especially at the connector.
4. Unplug the USB charging cable when it is not in use or during a thunderstorm.
5. Please keep the speaker away from heat sources (including oil equipment that generates heat), such as stoves.
6. Do not disassemble the speaker.
7. Use officially certified chargers and cables (UL, CSA, VDE, CCC).
8. If you have any questions, please contact our customer service team.

Quick Start Guide 05

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.