

User's Guide



Contents

1. Introduction	2
2. Battery Precautions	3
3. Getting Started	4
4. Bluetooth Connection	5
5. Function Guidance.....	6
6. LED Display Status	6
7. Microphone Usage	6
8. Battery Charging	7
9. Product Care	7

Please read the following safety warning and precaution before using your device.

Specifications

MD-01

Output Power:	3W
Frequency range:	2402MHz-2480MHz
Power supply:	Li-ion battery or USB cable
Audio source:	iPhone, iPad, Smartphone, Notebook, MP3, MP4, etc
Function spec:	Bluetooth, Microphone, Line-in
Size:	89.5mm x 74mm x 27mm

Rechargeable battery with charging from USB cable

1. Introduction



Thank you for purchasing the MD-01, this device can be easily connected with smartphone, Tablet PC and other devices via Bluetooth during your outdoor activities or other daily use. It will bring you an easy lifestyle.

2. Battery Precautions

The device can be powered by a built-in rechargeable lithium battery. Please charge the battery for at least 8 hours before your first use of device.

- If the device is not used for a long period of time, the battery may be out of power. Please charge the battery.
- Rechargeable battery is only to be charged under adult supervision.
- Only use the supplied USB cable to charge the battery. Improper charging may damage the battery and the device.
- Do not attempt to open the rechargeable battery or battery pack. There aren't serviceable parts inside.
- Should a battery leak, the device may become damaged. Clean the battery compartment immediately, avoiding touching your skin.
- Keep the battery out of reach from children. If swallowed, consult a physician immediately.
- Avoid storing the battery in extremely hot or cold environment. A device with a hot or cold battery may not work temporarily, even when the battery is fully charged.
- Do not dispose battery in a fire as it may explode. Battery may also explode if damaged. Please dispose it according to local regulation. Do not dispose it as household waste.

3. Getting Started



4. Bluetooth Connection


Pair MD-01 to your tablet or smartphone.

1. Activate pairing mode on MD-01 by switching "AUX/BT" button to "BT". The LED will flash in blue color.
2. On your device, navigate to the Bluetooth function (refer to the tablet owner's manual to locate Bluetooth function).
3. Select "Set Up" Bluetooth and turn "ON" Bluetooth.
4. Select "Search" and "Discover" devices.
5. Select "MD-01".
6. If requested, type the password 0000.
7. Press the Enter key.

After completing the steps above, a message on your tablet will appear to confirming that your device is now paired/connected.




In case of unsuccessful pairing, turn off it and restart it to "BT", then do as steps above.

Notice:

1. If you turn off the device, but the Bluetooth on your smart phone remains open, when you restart the device, the Bluetooth will be connected automatically.
2. When your smartphone and this speaker are apart beyond bluetooth receiving range, after 10 minutes, this speaker will disconnect with your smartphone and turn into pairing mode. If within 10 minutes your smartphone is back, will connect with this speaker automatically.
3. If long press "", the speaker will be disconnected and ready to pair with other smartphones.

5. Function Guidance

Play music from your MD-01.

Button	Function
	Volume up/ Next song
	Play/Pause/Answer/End a call
	Volume down/ Previous song

6. LED Display Status

	LED Display	Light indication
Blue Light	Flash slowly	It's ready to pair
	Stay solid	It's paired
Red Light	Stay solid	charging in process
	OFF	Fully charged

7. Microphone Usage

When a phone call comes in, you could talk through the microphone on speaker.

Two short press the pause button, you could call the last number you called on your call records.

8. Battery Charging ---

The device has a built-in rechargeable lithium battery that can be charged by connecting to the USB port of your computer. When it's charging, the light will turn to red.

After charging, the device can be used without the power connection.

9. Product care ---

Your device is designed to be light, compact and durable. As an electronic device, it must be treated carefully. Putting unnecessary pressure on it or striking the device against other objects may cause damage. To avoid damage to your device please

- Do not drop, crush, bend or apply excessive force to the device.
- Do not expose your device to moisture, extreme or prolonged heat, cold, humidity, or other adverse conditions. Avoid storing it in damp, humid or wet places, as it is not waterproof.
- Clean the unit with a soft cloth or damp chamois leather. Never use solvents.
- The Unit can Only be opened by qualified personnel.
- This device contains magnets. Keep magnetic field sensitive products such as credit cards and video screen away from this device to avoid damage or malfunction.

FCC Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.