

# TrueCapsule2 说明书 简洁版 七国

材质：封面封底100克书纸 内页80克书纸 尺寸：90 x 84 mm




**Contents**

English 1 - 8  
Deutsch 9 - 16  
Español 17 - 24  
Français 25 - 32  
Italiano 33 - 40  
日本語 41 - 48  
中文 49 - 56

**Package Content**

**Specifications**

Bluetooth Version	5.0
Bluetooth Chip	QCC3090
Maximum Working Range	10m without obstacle
Standby Time	About 110hrs
Earbuds Charging Time	About 1.5 hours
Charging Case Charging Time	About 2 hours
Charging Case Recharge Earbuds	4 Times
Dimension (L*W*H)	42.0*34.5*24mm (earbuds)



**Control**

Power On	Automatically. Open the charging case. Manually: Long press the multifunction button for 1.5s.
Power Off	Automatically. Place the earbuds back into the charging docks and close the charging case. Manually: Long press the multifunction button for 1.5s.
Play	Automatically. Tap on the earbuds. Manually: Double click the multifunction button.
Pause	Automatically. Tap on the earbuds. Manually: Double click the multifunction button.
Volume+	Click the left multifunction button once.
Volume-	Click the right multifunction button once.
Previous Track	Long press the left multifunction button for 1.5s.
Next Track	Long press the right multifunction button for 1.5s.
Answer / Hang Up / Phone Call	Double click the multifunction button.
Bluetooth Pairing Off	Long press the multifunction button for 1.5s.
Switch Between Two Active CoEs	Long press the multifunction button for 2s.
Enter Pairing Mode	Place the earbuds back into the charging docks and open the charging case, long press the button of the charging case for 3s.
Activate Voice Assistant	Click the multifunction button three times.

**Wearing the Earphones**

1. Identify the left and right earbuds.
2. Insert the earbuds, and adjust to find the best angle.

**Getting Started**

**Pairing & Re-pairing**

When the charging case is powered, open the charging case and ensure that the headphones are in the charging case, then both earbuds will enter TWS pairing mode automatically. You will hear a voice prompt when the left and right earbuds connect to each other successfully. Then you need to long press the button of the charging case for 3s, the white indicator of the charging case starts to flash in white with a voice prompt "pairing" indicating pairing mode.

2. SOUNDPEATS TrueCapsule2 will show up on the Bluetooth list, click it to connect. You will hear a voice prompt "connected" from right earbud when the earbuds connect with your device successfully. Then the prompt of "SOUNDPEATS TrueCapsule2" will show up to request pairing, click it to complete the pairing.

**IOS**

**Bluetooth Pairing Request**  
Headset's earbuds to pair with your phone.  
Cancel Pair

**Android**

**Bluetooth Pairing Request**  
Pair with SOUNDPEATS TrueCapsule2.  
Cancel Pair

**Note:**

1. When SOUNDPEATS TrueCapsule2 L requests pairing, please select pairing, otherwise the earphones can't be use on more mode properly.
2. When SOUNDPEATS TrueCapsule2 is connected with a mobile phone with Qualcomm Snapdragon 888 chip or higher Qualcomm chip, it will automatically connect the two pairing names without manual pairing again.

**Charging**

SOUNDPEATS TrueCapsule2 Bluetooth earbuds are equipped with a lightweight charging case which can not only charge the earbuds, but also a case that is convenient to carry and store the earphones. Built-in rechargeable battery, can charge two earphones 4 times.

**Charging the headset**

The earbuds are partially charged if the factory. Please make sure they are fully charged before use.

1. Put the earphones into corresponding charging docks.

**Charging the case**

When charging case battery is low, the LED indicator of the charging case is in red. Please charge the case soon.

1. Connect the charging port with Type-C charging adapter. (Please make sure the current is not greater than 1A)
2. Please charge the case at least once every 3 months when not in use for a long time.

**Charging the headset**

The LED indicator of the charging case flash to indicate that the earphones have been successfully paired.

**Charging the case**

When charging case battery is low, the LED indicator of the charging case is in red. Please charge the case soon.

1. Connect the charging port with Type-C charging adapter. (Please make sure the current is not greater than 1A)
2. Please charge the case at least once every 3 months when not in use for a long time.

**Charging the headset**

The earbuds are partially charged if the factory. Please make sure they are fully charged before use.

1. Put the earphones into corresponding charging docks.

**Warranty**

We warrant this device 12 MONTHS from date of the original purchase for manufacturer defects.

www.soundPEATSaudio.com  
support@soundPEATSaudio.com

https://soundPEATSaudio.com/download/

**FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. The equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) The device must accept any interference received, including interference that may cause undesired operation.

Change or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.