



USER'S GUIDE

WELCOME...

to your new digital Baby Monitor!

Thank you for purchasing the product. Now you can see and hear your baby sleeping in the other room or you can monitor your older children in their playroom.


This User's Guide provides you with all the information you need to get the most from your product.

Before you can use the baby monitor, we recommend you insert and fully charge the battery in the parent unit, so that it continues to work if you disconnect it from the mains power to carry it to another location. Please read the Safety Instructions on page 6 before you install the units.

Got everything?


- 1 x Parent Unit
- 1 x Baby Unit
- 2 x Power adapter

Overview of your Parent unit



1. Lcd display
2. Signal indicating led
3. Power indicating led
4. Menu key / Music play control key(long press)
5. Power key / Return key
6. Volume – key / Down key (menu screen)
7. Volume + key / Up key (menu screen)
8. PTT key
9. Microphone
10. Speaker
11. Power adapter connector

Overview of your Baby unit



1. Light Sensor
2. Infrared LEDS
3. Camera Lens
4. Power LED
5. Microphone
6. Speaker
7. Pair key
8. Temperature Sensor
9. Power adapter connector

Table of contents

- 1. Safety Instructions6
- 2. Getting started7
 - 2.1 Baby unit power supply7
 - 2.2 Parent unit power supply.....8
- 3. Using the Baby Monitor VB601.9
 - 3.1 Setting up9
 - 3.2 Pairing camera.....10
 - 3.3 Night vision.....10
 - 3.4 Music player.....10
 - 3.5 Talk function.....10
 - 3.6 Adjusting the volume10
 - 3.7 Reset the parent unit.....10
- 4. Monitoring screen icons.....11
- 5. Menu Options.....12
 - 5.1 Main menu12
 - 5.2 Camera Registration.....13
 - 5.3 Alarm.....13
 - 5.4 Settings.....14
 - 5.5 System info.....15
- 6. Wall mounting instructions.....16

1. Safety Instructions


WARNING

This baby monitor is compliant with all relevant standards regarding electromagnetic fields and is, when handled as described in the User's Guide, safe to use. Therefore, always read the instructions in this User's Guide carefully before using the device.

- Adult assembly is required. Keep small parts away from children when assembling.
- This product is not a toy. Do not allow children to play with it.
- This baby monitor is not a substitute for responsible adult supervision.
- Do not place the baby unit or cables in the cot or within arm's reach of the baby (at least 1 meter away).
- Keep the cords out of reach of children.
- Do not use the baby monitor near water or a heat source
- Only use the power adapters provided.
- Do not touch the plug contacts with sharp or metal objects.


2. Getting started

2.1 Baby unit power supply




1. Connect the small plug of the power adapter to the baby unit and the other end to the mains socket.
- NOTE: Only use the power adapter provided**
2. A green light led will display indicate the baby unit is working

2.2 Parent unit power supply



Charging the parent unit fully before use is recommended.


This will allow the unit to operate on battery in the event of a power failure.

1. Connect the plug of the power adapter to the parent unit and the other end to the mains socket
- NOTE: Only use the power adapter provided**
2. The LCD screen illuminates and starts up automatically after a few seconds.
3. Press and hold  key at least 3 seconds to turn on the parent unit.

3. Using the Baby Monitor VB601

3.1 Setting up

- Place the baby unit in a convenient location (e.g. on a table) and point the camera lens towards the area you want to monitor. Adjust the baby unit until you are satisfied with the image in the parent unit.
- To mount the baby unit on the wall, see section "9. Wall mounting instructions" for more details.



NOTE

Do not place the baby unit within baby's reach! If there is interference on the picture or sound, try moving the units to different locations, and ensure they are not close to other electrical equipment.

9

3.2 Pairing camera

The enclosed baby unit has already been registered, You do not need to register it again unless the baby unit loses its link with the parent unit. See section "5.2 Camera Registration" for more details.

3.3 Night vision

The baby unit has 8 high-intensity infrared LEDs for picking up clear images in the dark.

3.4 music player

Press and hold key at least 3 seconds will turn on the music player and play lullaby through the baby unit; long press the key 3 seconds again will turn off it.

3.5 Talk function

Press and hold key on the parent unit to talk to your baby through the baby unit loudspeaker. The symbol will be displayed at the bottom of the screen.

3.6 Adjusting the volume


When the video is playing mode, press key to decrease volume or key to increase volume. The display will show the current volume for 5 seconds.

3.7 Reset the parent unit

Press and hold key at least 8 seconds, the parent unit will be forced to restart.

10

4. Monitoring Screen Icons



- Signal strength indicator
- Temperature of the baby's room
- Lullaby is playing
- Alarm activated
- Battery indicator
- PTT function activated
- Date and time (DD/MM HH:MM AM/PM)

11

5. Menu Options

5.1 Main menu



Press "Menu" key at monitoring screen will enter the main menu, It contains 4 items :


- Camera
- Alarm
- Settings
- System info

You can press the "Up" key or "Down" key to move the cursor to select an item and press "Menu" key will enter the sub-menu which you selected.

Press "Return" key will back to monitoring screen


12

5.2 Camera Registration



Press "menu" key to entry registering screen, then push the pair key on the back of baby unit within 10 seconds.

5.3 Alarm



Press "Down" key to choose item, "PTT" key to move the cursor and "Up" key to change value .

13

5.4 Settings

5.4.1 Language


Language setting menu allows you to choose your language from the following :

English / French / Spanish / Portuguese / Italian / German / Turkey

5.4.2 Time and date

There are contains 2 items in this menu

- Set time / date
- Set format



Press "Down" key to choose item, "PTT" key to move the cursor and "Up" key to change value .

5.4.3 Temperature unit

Switch the unit to Celsius or Fahrenheit

14

5.4.4 Anti-flicker

You are able to adjust the frequency of 50 / 60 HZ to suit your lighting for anti-flicker

5.4.5 System mode


This menu allows you to choose the working mode from the following: Normal mode / VOX mode

5.4.5 VOX Sensitivity

Switch the Vox sensitivity at Low / Medium / High level

5.4.7 LCD backlight

You are be able to adjust the brightness of the LCD you are viewing and the LCD backlight active time in menu operation.




5.5 System info

There are contains system information such as software version , hardware version, build date etc.

15

6. Wall mounting instructions

- Use the template below to mark the wall in the correct places to drill holes for wall-mounting screws



- Insert 4mm head screws (not supplied) into the holes and tighten the screws. Then, align your baby unit with the screws and push it down.
- Point the camera lens towards the area you want to monitor. Adjust the baby unit until you are satisfied with the image in the parent unit.

16

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.