Gabba Goods Wireless Emoji Speaker

Thank you for purchasing our product! In order to get the best use of this Emoji speaker, please read this user manual to get yourself familiar with the speaker's features and functions!

Caution:

Please use and store this product at room temperature. DO NOT leave out in hot temperature Do not expose this product to rain or wet conditions
Do not throw or drop this product as it will cause damage
Do not try to dismantling or repair the product on your own
Do not use a chemical solvent to clean the product
Please do not leave this product near a fire or open flame


What's included?

Bluetooth Emoji Speaker USB charging cable Auxiliary cable User manual

Features

- Wireless Bluetooth Connectivity
- Supports a memory card if you would like to play music from a chip
- With built-in Mic so you can answer phone calls while connected
- Rechargeable with its built in efficient lithium ion battery

Button Functions:



Instructions:

To Turn Speaker On/Off: Hold down the power button until the blue light turns on/off.

Connecting to your Bluetooth Enabled Device:

- 1. Turn on the speaker. There will be a voice prompt "Bluetooth pairing mode"
- 2. Go into your devices Bluetooth settings and pair/connect to "Emoji Speaker.
- 3. Once connected you will hear a voice prompt "The Bluetooth device is connected successfully"

Memory Card Play

- 1. Insert TF card
- 2. The speaker will automatically play the music stored on your memory card.

Please Note: If the speaker is on, it will automatically go into "Memory Card Mode" when you insert the card.

Incoming Calls:

- 1. When you receive an incoming call, the speaker will tell you the phone number of the person who is calling.
- 2. To answer the call, press the Play/Pause button.
- 3. To end the call, press the Play/Pause button again.
- 4. To reject the call, hold down the Play/Pause button.

Auxiliary mode:

- 1. Plug one end of the Aux cable into the speaker and the other side of the cable into your devices headphone jack
- 2. There will be a voice prompt "Auxiliary port connected", and you can now play your music from your device.

Charging the Speaker:

- 1. When the power is low, there will be a voice prompt "Battery is low please recharge"
- 2. Charge the speaker using the micro USB cable included.

Specifications:

Battery Voltage: 3.7V	Capacity: 400mAh
Charge voltage: 5V	Loudspeaker size: 40mm 4Ω 3W
Net weight: 80g	S/N: ≥80Db
Distortion: ≤0.5%	Size: 68X68X64MM

Manufacturer Warranty

We stand by our products! That's why we guarantee them from any functional defects for one year from the original date of purchase.

Should you have an issue please email us at info@GabbaGoods.com or visit us on the web at www.GabbaGoods.com

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.