

Product: Bluetooth Speaker

Model: CQL1512-B

CHARGING THE BLUETOOTH DEVICE

1. Connect the speaker's Micro USB socket with the power source's USB port through USB cable.
(Micro USB port is located on the back of the device.)
2. The power indicator will show red while the battery is charging. When the speaker has reached a full charge the LED indicator will turn off to indicate the battery is fully charged.
3. Disconnect the USB cable when it is fully charged.
(A full charge will take approximately 3-4 hours.)

PAIRING / RECONNECTING THE DEVICE

1. Slide the switch on the back of the speaker into the "On" position. The speaker will enter searching / pairing / reconnect mode.
2. Now, turn on the Bluetooth function of your device.
3. Search for "AMP-XX" and select it to begin Bluetooth pairing.
(For first time pairing or pairing a new mobile device.)
4. The speaker will reconnect automatically if your mobile phone has been paired previously.
(Note: Depending on the device's type and configuration, manual reconnection may be required each time.)
5. If pairing is successful, speaker will make a tone to confirm.
6. Slide the power switch to the "Off" position to turn the unit off.
(Note: If you cannot search for the Speaker, this means the last device is reconnecting automatically. Choose to forget the AMP-XX speaker from your bluetooth menu and try to pair with the speaker again.)

SPEAKER CONTROLS AND FUNCTIONS

- All functions and controls are done through your media device.
(To pause, play, select tracks, and control volume you must do so from your device.)

AUXILIARY-IN FUNCTION

1. With the speaker powered on, connect the included Auxiliary cable into the speakers auxiliary port and plug the other end into your phones auxiliary port.
2. The speaker will switch to "AUX IN" mode automatically from Bluetooth mode. You can now play your media as desired.
3. Disconnect the Auxiliary cable when finished.
(Note: If there is no sound while auxiliary cable is connected to bluetooth device, ensure all other bluetooth devices are not paired and repeat step one. If the problem persists replace auxiliary cable.)

Limitation of Liability

In no event, under any cause of action of theory of liability, shall Sicura Media Inc., its distributors or suppliers be liable to you or any third party for indirect, incidental, consequential, special, exemplary or punitive damages, of any and all nature whatsoever, arising out of use of or inability to use a product. This includes without limitation, property damage, loss of value of the product or any third party products that are used in or with the iWave products, even if the iWave product has been advised of the possibility of such damages that one may encounter. Without limiting the foregoing, you understand and agree that iWave has no liability for any damages or destruction to the consumer electronics devices or other personal property that are Contained inside or outside of the iWave products. This includes without limitation, laptops, Cellular phones, or other hand-held devices, or any loss of data contained in the foreign device. Notwithstanding any damages that you might incur for any reason whatsoever (including without limitation, all damages referenced herein and all direct or general damages in contract, tort (including negligence) or otherwise), the entire aggregate liability of iWave and any of its distributors and/or suppliers shall be limited to the amount actually paid by you for the iWave product giving rise to liability. Some states and/or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. The Limitations of liability set forth above shall apply to the maximum extent permitted under the applicable law.



SPECIFICATIONS:

- Model No.: SP3162 AMP-XX
- Driver Unit size: DIA 2.75"
- DC Power Input : 5V / 500 mA
- Bluetooth: A2DP / AVRCP / HSP
- Output power: 2.5 X 2W
- Frequency: 20Hz-18KHz
- Working distance: 30ft (Distance may vary)
- Rechargeable Battery: 600 mAh, 6 hrs playback
- Power Supply: Lithium battery/ USB charge



iWave and the iWave logo are trademarks of iWave Sicura Media, Inc. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by is under license. All other trademarks and trade names are those of their respective owners. ©2016

New York NY 10018
Support@iwaveaudio.com
www.iwaveaudio.com
Made in China exclusively for
iWave Sicura Media, Inc.

FCC Disclaimer:

This device Complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
1- This device may not cause harmful interference, and
2- This device must accept any interference received, including interference that may cause undesired operation. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help or assistance.

This device complies with Part 15 of the FCC Rules and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:
1- This device may not cause harmful interference, and
2- This device must accept any interference received, including interference that may cause undesired operation. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment. Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.



Warning:
Please read these safety warnings and cautions carefully to ensure your personal safety and prevent property damage.

Fire and Electric Shock Hazard

- Do not drop, disassemble, open, crush, bend, deform, puncture, shred, microwave, incinerate, paint, or insert foreign objects in to the speaker. Such actions could result in electric shock.
- Do not expose your speaker to extremely high or low temperatures it can cause malfunction.
- Do not leave your speaker in direct sunlight for extended periods of time.
- Do not leave your speaker near open flames such as cooking burners, candles, or fireplaces.
- Do not block any ventilation openings.

Fall Hazard

- Do not place the speaker on high surfaces such as shelves. During music playback the speaker may move which could cause the speaker to shift and fall off of the edge.

Warning:

To reduce the risk of electric shock, do not remove cover (or back). Refer servicing to qualified service personnel.

CAUTION:

- Do not use abrasive cleaners to clean your speaker. It could cause scratches and damage.
- Do not bring your speaker in to contact with any sharp objects. It could cause scratches and damage.
- Do not insert anything into your speaker unless otherwise specified in the user instructions. This may damage the units internal components.
- Do not attempt to repair, modify, or disassemble your speaker yourself, it does not contain any user-serviceable components.
- Do not attempt to replace your speaker battery, it is built-in and is not changeable.
- Use only the manufacturer supplied charger to charge your speaker. Other chargers may look similar, but using them could result in electric shock and could damage your speaker.
- Observe all signs and displays that require an electrical device or RF radio product to be switched off in designated areas.
- Turn off your speaker prior to boarding an aircraft. Do not use the speaker inside an aircraft unless allowed by your airline.
- Dispose of the speaker and its battery in accordance with local regulations. Do not dispose of the battery with regular household waste.



User Manual for SP3162

AMP-X

WIRELESS PORTABLE SPEAKER

Rechargeable
Battery

2.5 X 2 W Output
Stereo Sound

6 Hours Of
Playtime

PACKAGE INCLUDES:

- 1 X BLUETOOTH SPEAKER
- 1 X USB TO MICRO USB CABLE
- 1 X 3.5 MM AUXILIARY CABLE
- 1 X INSTRUCTION MANUAL

IMPORTANT PLEASE READ BEFORE USING THIS PRODUCT

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation