


()

Earbud Controls

()

Right side shown. All controls and features are duplicated on the left earbud.




()

Battery Charging

Initial charge time is approximately 2 hours. Charge fully before use. The low battery indicator will flash for 1 minute, then the unit will automatically power OFF.

- 1. Pull back the cover on the DC Power Input.
- Using a Micro-USB to USB cable, connect to the USB port of a powered on computer or USB power adaptor (not included) to charge the unit.
- 3. Charge both earbuds at the same time with the included dual Micro-USB charging cable.

Status	Indicator
Power ON / Bluetooth Paired / Earbuds Linked	Slow flashing blue light
Pairing Bluetooth	Quick flashing red / blue lights
Linking Earbuds	Quick flashing red / blue lights
Low Battery	Slow flashing red light
Charging	Solid red light
Fully Charged	Solid blue Light



Pairing Bluetooth & Playing Audio

After initial pairing to a Bluetooth device, the earbuds will stay paired unless unpaired manually by the user, or erased due to a reset of the device. If your device should become unpaired or you find it is unable to connect, repeat these steps.

Note: Turn either of the earbud on. This pairing process is required for **another earbud only**.

- From off mode, press and hold the Power/Pair button for approximately 9 seconds until the red and blue LED light ash alternately, indicating that the earbuds are in pairing mode. When pairing, remain within 3 feet of the unit.
- From your smartphone or other Bluetooth device, access Bluetooth Settings and search for nearby devices. Select IAEB67 when it is discovered.
- When successfully linked, a chime will sound and a voice prompt will announce the connection. Audio played through the connected Bluetooth device should now be heard through the earbuds.
- Use the controls on the connected device to select and begin playing audio. Use the controls on the connected device or the earbuds to play, pause, skip, or change volume.

Linking Earbuds

The earbuds have already been linked for your convenience. However, if the earbuds should become unlinked or you find they are unable to connect, please follow these steps. Note: Power on both earbuds. This linking process is required for

each earbud.

- Press and hold the Link button for approximately 9 seconds until the red and blue LED light flash alternately, indicating that the earbuds are in pairing mode.
- When successfully linked, a chime will sound and a voice prompt will announce the connection.

Speakerphone

- To accept a call, press the **Speakerphone** button, or use the controls on the connected phone.
- To end a call, press the **Speakerphone** button, or use the controls on the connected phone.
- 3. To re-dial the last dialed number, press the **Speakerphone** button twice.

Customer Support

Customer Service: 1-888-999-4215 | Email Support: prodinfo@ dpiinc.com | Email Parts: partsinfo@dpiinc.com

For Warranty Information and the most up-to-date version of this User's Guide, go to **www.iLiveElectronics.com**

To download this User's Guide in English, Spanish, or French, or to get answers to frequently asked questions, visit the support section at: **www.iLiveElectronics.com**

Para descargar este Manual del Usuario en inglés, español y francés, o para obtener respuestas a preguntas frecuentes, visite la sección de apoyo en: **www.iLiveElectronics.com**

Pour télécharger ce guide de l'utilisateur en anglais, espagnol ou français, ou pour obtenir des réponses à des questions fréquemment posées, consultez la rubrique d'assistance sur: www.iLiveElectronics.com

Copyright © 2017 Digital Products International (DPI, Inc.) All other trademarks appearing herein are the property of their respective owners. Specifications are subject to change without notice.

FCC Warnings

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if no installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
 This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Additional Warnings

- WARNING: To prevent fire or shock hazards, do not expose this unit to rain or moisture.
- WARNING : Where the mains plug or appliance coupler is used as the disconnect device, such disconnect device shall remain readily operable
- Lithium batteries, like all rechargeable batteries, are recyclable and should be
 recycled or disposed of according to state and local guidelines. They should
 never be disposed of in normal household waste, and they should never be
 incinerated, as they might explode. Contact your local government for disposal
 or recycling practices in your area.
- · This product meets and complies with all Federal regulations.
- To avoid hearing damage, make sure that the volume on your music player is turned down before connecting your headphones. After placing headphones in/on your ears, gradually turn up the volume until you reach a comfortable listening level.



 $(\mathbf{\Phi})$

WARNING: This product can expose you to chemicals including lead, which is known to the State of California to cause cancer. For more information go to www.P65Warnings.ca.gov

Note : Certain electrical sources can cause slower performance or disconnection from our wireless earbuds if they are nearby.