





# QUICK GUIDE



## What's in the box

Consult the checklist below for all components.






# Description

Power	DC12V ± 10%
Status light	<ul> <li>Red light solid on: the camera network is abnormal</li> </ul>
	<ul> <li>Blinking red light: awaiting WiFi connection, or currently</li> </ul>
	connecting (faster blinking)
	<ul> <li>Blue light solid on: camera running correctly</li> </ul>
	<ul> <li>Blinking blue light: awaiting manual WiFi configuration, or</li> </ul>
	currently connecting (faster blinking)
Microphone	Captures sound for your video
SD card	Supports local SD Card storage (Max 128G)
Speaker	Speaker speak with the app and it will revert too
Reset	Press and hold for 5 seconds with pin to reset the camera (if
	you have modified settings, they will return to factory defaults)
	Pressing for 1 second will activate manual WiFi setup mode

### Install

1 Fix the Camera to the wall with screws

2 Ajust camera angle to a correct view ( as shown in the picture )





#### Download

CloudEdge is available for both iOS and Android OS. Search the name 'CloudEdge'in App Store or Android Market, or scan upper QR–Code to download the App.

# Support Support Image: Support Ima

#### Set up router


This product only supports 2.4GHz frequency band router, does not support 5GHz frequency band router, please set the relevant parameters of the router before WiFi configuration, WiFi passwords do not include special characters such as ~!@#\$%^&\*(). When the device is configured in WiFi, the mobile phone and device are as close as to the router, which can speed up the configuration of the device.



Step 1 Open the CloudEdge App, click 'SIGN UP', input a valid email address and select 'registration means agreement with user agreement privacy agreement' then click 'NEXT'.

		<	SIGN UP
China +8	86 >		
Account		United States	+1 >
Password	9	Email	
Forgot your password?		Registration me	eans agreement with user agreement and
		Print Carton	
LOG IN			NEXT
or SIGN UP			
TROPAN SIGN OF	2		

Step 2 Enter the email address and click 'OK', create a nickname and login password.



Note: Make sure your router, device, and mobile phone are nearby.

Few notices before adding the device

- 1. This device only supports 2.4GHz WiFi router, please make sure you are using a 2.4GHz WiFi router.
- 2. Please follow the instructions and make sure the password is inputed correctly.
- 3. One device can only be added with one App account, if the device has been added with another account already, then it can't be added to any another account again.

#### Process

Step 1 Open the CloudEdge App, click '+', and select the type of device to add.

$\equiv 1$	MY DEVICE	+	Choose Device Type
			CAMERA >
			26 camera >
			BATTERY CAMERA >
			DOORBELL >
			NVR >
	+		
Tap to ad	d devices and select the two the next step	ways in	

Step 2 Please confirm the red LED light blinks, select 'The device has flashed red slowly or you hear a tone', click 'Next'. Then input the wireless password, click 'Next'.

<	Install Camera Other methods	<	WLAN Conn	ection
		Please fill in the wireless network to be connected Please ensure that the mobile phone is connected to the 2.4G WIFI network.		
		****	x	Change WiFi
		•••••	••	
	<ol> <li>After powering on the device, wait until the device starts</li> <li>Make sure the status indicator changes from steady red to slow red, or hear the device prompt: "Please configure wireless network for camera".</li> </ol>			Show password
	Descriptions for Status light			
	The device has flashed red slowly or you hear a tone			
	Next		Next	


Step 3 The device is scanning the QR code at a distance of 15~25cm (you can click the 'operation' to view the scanning mode). After the device scans successfully, click 'Hear tone'.






Please point the QR code in the screen of the mobile phone towards the device and keep the distance of about 15~25cm. Wait for the device to scan the QR code on the mobile phone.

Step 4 The device is successfully connected to the network. After the configuration is completed, the App automatically adds the successfully scanned device, and return to the device list. The configuration is completed.



Step 5 Click the play button to complete the preview. (Remind: long press the image to be previewed to remove the device, add device again to reset the device)







#### Video flip

Flip your video stream up or down for maximum flexibility.

#### Motion detection

Built-in motion sensors detect movement, and the camera will send you push notifications and app alerts.

#### Record

Support 24H continuous recording with high capacity SD storage.

#### Day & Night

Never miss a moment, even in complete darkness, with powerful night-vision technology.







Night



- Q: The device cannot be previewed properly?
- A: Check whether the network is normal, you can place the camera close to the router, and if not, it is recommended to reset the device and add it again.
- Q: Why is it still in the list of devices after reseting?
- A: The reset device only resets the network configuration of the camera, but cannot change the configuration on the App, remove the camera, and must be deleted by the App.
- Q: How to cut the camera network to another router?
- A: First remove and reset the device on the App and then configure the device again by the App.
- Q: Why doesn't the device identify the SD card?
- A: It is recommended to plug in SD card after power cut. Confirm whether the SD card is normally available and the format is FAT32. And the TF card can't be identified when the internet environment is not good.
- Q: Why I can't get the notifications with my cell phone App?
- A: Please confirm that the App has been running on the phone, and the relevant reminder function has been opened;Message notification and authority confirmation in the mobile phone system have been opened.

#### **FCC Information**

This device complies with Part 15 of the FCC Rules.

**Caution:** Any changes or modi\_cations not expressly approved could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment o\_ and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit di\_erent from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

#### Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.