



QUICK GUIDE



What's in the box


Consult the checklist below for all components.











Description

Power	DC12V ± 10%
Status light	Red light solids on: the camera network is abnormal
	Blinking red light: awaiting WiFi connection (faster blinking)
	Blue light solids on: camera running correctly
	Blinking blue light: currently connecting (faster blinking)
Microphone	Captures sound for your video
SD card	Supports local SD Card storage (Max.128G)
Speaker	Speaker speak with the app and it will revert too
Reset 1&2	Press and hold for 5 seconds to reset the camera (if you have
	modified settings, they will return to factory defaults)



- 1 Fix the Camera to the wall with screws
- 2 Ajust camera angle to a correct view (as shown in the picture)

Connec

Download

Smart Life is available for both iOS and Android OS. Rearch the name 'Smart Life' in App Store or Android Market, or scan the QR-Code to download the App.

Support







Set up router

This camera only supports 2.4GHz WiFi networks. Check that your WiFi router is switched on. For a faster installation, place the camera and your smartphone near the WiFi router(Internet box) in order to benefit from a better connection.











Registration process

Step 1 Open the Smart Life App, click "Register", read the "Privacy Policy" and click "Agree".





Step 2 input a legal and valid Mobile number or Email address and click "Continue". Input Verification Code, then log in the app.



QR Code Configuration

Open the Smart Life App, click "Create family", and you can customize the Family name and related settings.






Continue to click "Security & Sensor" >> "Smart Camera", and then choose "Add Device" or "+", ready to add camera.





In "Add Device" this interface, continue to click "next step", and then you should input your WiFi's passwords.




Note:

- 1) Camera only supports 2.4GHz WiFi network.
- The number of bits in the ssid and passwords of the router should not exceed 24 digits.

In this interface, you should scan the QR code in your phone with the camera. When the doorbell comes out with a "dong dong dong" sound you can complete the configuration in about 30 seconds.

Scan with the camera

When you tap CONTINUE, the mobile phone displays a QR code. Hold the camera 15 to 20 cm in front of the mobile phone for the camera to scan the QR code.





Heard nothing at all

Heard the beep

When connecting, you should make sure your router, mobile, and camera are as close as possible. When camera added successffully, click *z* you could also DIY the camera's name.

Connecting

Make sure your router, mobile, and device are as close as possible

Device added successfully






- ✓ Device found
- Register device to the smart clou
- * iriillalizing devic

Completed



In "Smart Camera" interface, click " \angle ", you can set the camera common functions.





- Q: In the network process, the process bar is always not 100%, add failure?
- A: This smart doorbell only supports 2.4GHz WiFi router, please make sure you are using a 2.4GHz WiFi router. And confirm the WiFi password again.
- Q: Repeated additions are failures?
- A: After adding a failure, it is recommended to restart the device or power off, and then try to add again.
- Q: The device cannot be previewed properly?
- A: Check whether the network is normal, you can place the smart doorbell close to the router, and if not, it is recommended to reset the device and add it again.
- Q: How to cut the smart doorbell network to another router?
- A: First remove and reset the smart doorbell on the App and then configure the smart doorbell again by the App.
- Q: Why I can't get the notifications with my cell phone App?
- A: Please confirm that the App has been running on the phone, and the relevant reminder function has been opened; Message notification and authority confirmation in the mobile phone system have been opened.
- Q: Why doesn't the device identify the SD card?
- A: It is recommended to plug in SD card after power cut. Confirm whether the SD card is normally available and the format is FAT32. And the TF card can't be identified when the internet environment is not good.



Video flip

Flip your video stream up or down for maximum flexibility.

Motion detection

Built-in motion sensors detect movement, and the camera will send you push notifications and app alerts.

Record

Support 24H continuous recording with high capacity SD Storage or Cloud Storage.

Daytime & Night

Never miss a moment, even in complete darkness, with powerful night-vision technology.







Night

FCC Statement:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.