


Quick Start Guide



Cyber Acoustics USB & BT Speaker Bar – Pro Edition (CA-2890PRO)





Use at Home or Office


www.CyberAcoustics.com

CA P/N: CA-2890PRO Rev. A00
2023-07

In the Package



Quick Start Guide



USB Type C to A Adapter

Note: The USB Type C to A Adapter is attached on the USB C cable.



Cyber Acoustics
USB & BT Speaker Bar – Pro Edition (CA-2890PRO)

Table of Contents

Pages

Getting Started - USB Connection.....

1

Getting Started - Bluetooth Connection

2,3

Lights

4

Controls

5

Technical Specifications

6

Frequently Asked Questions

7,8,9

Customer Support & Safety and Precautions

10

Compliance Information


11,12

Getting Started - USB Connection

The Cyber Acoustics Speaker Bar is used with a USB connection to your Windows PC or Mac and can also be connected at the same time to your smartphone or tablet with Bluetooth.

USB connection - Using with a PC or Mac

- Insert the USB Type C end of the Speaker Cable into the USB Type C port on your computer. You can also use the provided USB C to A adapter to connect the Speaker Bar to an available USB Type A port on your computer.
- The Speaker Bar will power on and connect to your PC in USB mode.
- Source Light will be lit solid green.



The Cyber Acoustics Speaker Bar features full plug and play support for Windows 10, OSX / MacOS and Chromebooks. After plugging the Speaker Bar into the computer, you may use for playing music, videos or as a speakerphone with applications such as Zoom, Teams, Skype, etc.

If the computer does not automatically recognize the Speaker Bar when it is plugged into the USB Type C port, try plugging the USB cable into a different USB Type C port. If this does not work, then restart the computer. This will cause the Speaker Bar to be recognized in most instances.

Important: If the Speaker Bar is also connected by Bluetooth to a smartphone, the Speaker Bar will auto-switch from USB mode to Bluetooth mode when there is an incoming call on the connected smartphone (see page 3 to connect your smartphone). To change back to USB mode after the call is complete, press the Multi-Function button twice (see controls on page 5).

Getting Started - Bluetooth Connection - Step 1

Before you start, insert the USB Type C end of the Speaker Cable into the USB Type C port on your computer (see page 1 - USB Connection).

- Press the Multi-Function Button two times (see controls on page 5) to switch between USB mode and Bluetooth mode.
- When changed to Bluetooth mode, the Speaker Bar will be in pairing mode and the Source Light will be flashing blue, or if already connected to a smartphone or tablet the Source Light will be solid blue.

Source Light Flashing Blue

- The Cyber Acoustics Speaker Bar is ready to pair and connect (see page 3 to connect your smartphone or tablet).

Source Light Solid Blue

- Your device has connected to the Cyber Acoustics Speaker Bar and is ready to use.
- The Cyber Acoustics Speaker Bar allows the last device it was connected with to automatically reconnect with the speaker each time the speaker is turned on and that device is within range.*
- When connected to a smartphone, the Speaker Bar will auto switch to Bluetooth mode from USB mode when there is an incoming call on the connected smartphone.

The Cyber Acoustics Speaker Bar can be connected to one device at a time.

- To pair and connect to a different device, you need to first disconnect the currently paired device.
- To disconnect the current device, press and hold down the Multi-Function Button for 5 seconds.
- The Source Light will begin flashing blue and the Cyber Acoustics Speaker Bar is ready for the next device to pair and connect.

* Your device needs to be within 100 unobstructed feet of the Cyber Acoustics Speaker Bar to pair and connect. If there is an issue when connecting please move your device closer to the speaker, then pair and connect.

Getting Started - Bluetooth Connection - Step 2

With your iPhone, iPad/Tablet, Smartphone

- Go to Settings > Bluetooth, check Bluetooth is on
- Select 'CA-2890PRO Speaker Bar' when it appears under DEVICES
- Your device will connect in a few seconds
- The Source Light will turn solid blue
- The Cyber Acoustics Speaker is ready to use

Note: Your smartphone or tablet instructions may vary

Lights

Source Light

USB mode: Solid Green

Bluetooth mode:

Flashing Blue – Ready to pair with smartphone or tablet

Solid Blue – Connected to smartphone or tablet

USB Type A or Type C Setting Light

Off: The speaker volume and EQ will be optimized for power available from a USB Type A port.

Solid White: The speaker volume and EQ will be optimized for the higher power available from a USB Type C port.



Call / Microphone Mute Indicator

Flashing Red: Incoming call from smartphone

Solid Purple: Call in progress on smartphone

Solid Red: Microphone muted (call functions not available as noted above)

Red Light Off: Microphone unmuted (call functions active as noted above)

Controls



Multi-Function Button

Press twice to switch between Bluetooth and USB mode

Press and hold for 5 seconds to disconnect the connected smartphone or tablet

Press once to Answer/End a call or Play/Pause music

- Music will pause automatically when there is an incoming call from a smartphone

Press twice to reject an incoming call



When talking, press once to mute the mic input; press again to unmute.



Selection to set speaker for USB Type A or Type C connection

Default Setting – USB Type A connection (LED is not lit)

Press once to switch to USB Type C connection (LED is lit)

Press again to switch to USB Type A connection (LED is not lit)



Press once to increase the volume

Press and hold to increase the volume continuously until maximum level
(A light beep sound will be heard when the volume level reaches maximum)



Press once to decrease the volume

Press and hold to decrease the volume continuously until minimum level
(A light beep sound will be heard when the volume level reaches minimum)

Technical Specifications

Specifications	
Power	<ul style="list-style-type: none">• 5V / 3A – USB-C Power Source, 5V / 1A – USB-A Power Source• USB-C 5W when playing music (2.5W x 2)• USB-A 3W when playing music (1.5W x 2)
Frequency response	<ul style="list-style-type: none">• Speaker: 80 - 16,000Hz• Microphone: 100 - 16,000Hz
Impedance	<ul style="list-style-type: none">• Speaker: 4 ohms• Microphone: 2.2k ohms

Recommended System Requirements	
Supported operating system	Windows 11, Windows 10, Mac OS X 10.4.11 or higher
Operating temperature	Product working at ambient temperature for 0~35°C

Frequently Asked Questions

Frequently Asked Questions	Possible Solutions
Bluetooth connection Can't connect for the first time	<ul style="list-style-type: none">• Re-insert the USB cable of the speaker to your PC and switch it to BT pairing mode.• Check your Bluetooth source device and be sure you have found the section that allows you to discover new Bluetooth products. If you see the speaker on the list, but cannot connect, you may need to do a new pairing with your device and the speaker. To start a new pairing with your Bluetooth device, select "Forget this device," to remove the "CA-2890PRO Speaker Bar" from the list. You may need to turn off the Bluetooth function on your device to fully clear your list.• Return to your source device, and re-enable the Bluetooth function. Look for the "CA-2890PRO Speaker Bar" to show back up on the list.• Select the speaker on your screen, and pair it.
Bluetooth connection Can't connect when returning	<ul style="list-style-type: none">• If the speaker does not automatically reconnect with your Bluetooth device, you may need to go into your device's Bluetooth settings and select the speaker to reconnect.• Be sure to check your room environment. Today's Bluetooth technology has a designed limit of approximately 100 unobstructed feet, line of sight. Your best results will be when your source device and Speaker Bar are in the same room. Extremely large rooms, or rooms with lots of wireless electronics, Wi-Fi routers, radio transmitters, etc. may affect your ability to pair and connect.• Check for obstructions, walls or other objects that might impede the Bluetooth signal.• Try returning to the source device to a closer proximity with your speakers.

Frequently Asked Questions

Frequently Asked Questions	Possible Solutions
USB connection Windows 11 / Windows 10: Speaker Bar does not set up automatically	<ul style="list-style-type: none"> • In the search box on the taskbar, type control panel, then select it from the results. • Select Hardware and Sound from the Control Panel, and then select Sound. • On the Playback tab, right-click “CA-2890PRO Speaker Bar”, select Set as Default Device, and then select OK. • Verify green circle with a check mark next to “CA-2890PRO Speaker Bar”. • On the “Recording” tab, right-click “CA-2890PRO Speaker Bar”, select Set as Default Device, and then select OK. • Verify green circle with a check mark next to “CA-2890PRO Speaker Bar”. • (Optional) To adjust the speaker volume, click Properties. • When finished, click “Apply” then “OK”.
USB connection Mac: Speaker Bar does not set up automatically	<ul style="list-style-type: none"> • Open the Finder Application, then select Applications. • Open System Preferences, then click Sound. • Select the Input tab, then select “CA-2890PRO Speaker Bar”. Make sure that the mute button isn’t selected. • Select the Output tab, then select “CA-2890PRO Speaker Bar”. Make sure that the mute button isn’t selected. • When finished, close System Preferences.

Frequently Asked Questions

Frequently Asked Questions	Possible Solutions
USB connection Speaker Bar does not have sound / Microphone is not working	<ul style="list-style-type: none">- Check the computer's volume level.- Check the proper seating of the USB cable connection.- Verify the application settings you are using. Some applications have a separate volume level control.- Check that the computer recognizes the Speaker Bar, showing it is connected and selected within your computer OS settings (see the Page for Windows and Mac setting instructions).- Verify the input / output levels within the sound / audio settings of your computer's settings.- Unplug the Speaker Bar from the USB port of the computer and then reconnect to the USB port of the computer.- Restart your computer and re-verify the above steps. Restarting often helps a computer connect to the speaker. <p>If using Zoom or Microsoft Teams, further instructions for audio settings can be found on the below websites.</p> <p>Zoom https://support.zoom.us/hc/en-us/articles/201362283-Testing-computer-or-device-audio</p> <p>Microsoft Teams https://support.microsoft.com/en-us/office/manage-your-call-settings-in-teams-456cb611-3477-496f-b31a-6ab752a7595f</p>

Customer Support

If you have a question about your Cyber Acoustics Speaker Bar, our Customer Service Team wants to assist you.

Contact us at:

www.cyberacoustics.com/support/contact

Safety and Precautions

- Read and follow all instructions – All operating and use instructions should be followed.
- Protect the Speaker Bar from being pinched, particularly at the connectors. Unplug during lightning storms or when unused for long periods of time.
- Do not place near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not make alterations to the Speaker Bar.
- Do not place near naked flame sources, such as lighted candles.
- Do not expose to excessive heat (e.g. from storage in direct sunlight, fire or the like).

2023 Cyber Acoustics or its subsidiaries. All rights reserved. Cyber Acoustics and other trademarks are trademarks of Cyber Acoustics or its subsidiaries. Other trademarks may be trademarks of their respective owners.

Supplier's Declaration of Conformity 47 CFR § 2.1077 Compliance Information

Unique Identifier: (CA-2890PRO)

Responsible Party - Cyber Acoustics, Inc.

3109 NE 109th Ave., Vancouver, WA 98682

cyberacoustics.com



Compliance Information Statement:

FCC Part 15

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiving device
- Connect the equipment into an outlet on different circuit from the receiving device
- Consult the dealer or an experienced radio/TV technician for help
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF exposure statement

This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.

This equipment meets the exemption from the routine evaluation limits in section 2.5 of RSS-102. It should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.

Cet équipement est conforme à l'exemption des limites d'évaluation habituelle de la section 2.5 de la norme RSS-102. Il doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et toute partie de votre corps.

IC WARNING

This device contains licence-exempt transmitter(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- 1. L'appareil ne doit pas produire de brouillage;
- 2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.