

Setup & Initialization

1 ... 2 ... 3

Follow installation manual to install new thermostat

Set up Date/Time, Heating Type, Operation Mode

Set up Wi-Fi, download App, create user account


Turn off power to the heating/cooling system until installation is complete.

YouTube www.vinesmarthome.com HELP
YouTube: Vine Smart Home

System Menu




Main Screen



Wi-Fi Setup

- Step 1**
On Main Screen, tap Wi-Fi for Wi-Fi setup
- Step 2**
Scan for a list of available Wi-Fi networks
- Step 3**
Enter password. If not required, leave it blank and click OK.



After successfully connecting to the internet, download the App "Xing Control" from the Apple App Store or Google Play onto your phone, then register this device to your account.



Create a User Account, then click here to add the device to the account
Follow on-screen instructions on the App or webpage.

Troubleshooting Wi-Fi connection



- Failed Wi-Fi connection may be caused by the following:
- Does not support 5GHz Wi-Fi Connection.
 - Does not support Wi-Fi name with non-ASCII characters.
 - Changed password or additional authentication through a webpage.
 - The router is not connected to the internet or the signal from the router is too weak.

(1) If your device loses connection with your wireless network, it will automatically attempt to reconnect after five minutes. If that fails, it will make a new attempt every 15 minutes for the next 24 hours. Any manual operation of the thermostat will disable automatic connection attempts. (2) Energy Saving is available on certain models. The Wi-Fi function will enter a five-minute sleep mode when there is no manual operation. The system will wake up and reconnect to the internet every five minute interval.


Programming

Programming can be accessed from the **System Menu** -> **Heating & Cooling**, or from **Mode Setup** on the main screen. Use the **App** or **Webpage** to change the name of a program, and to **add** or **delete** a program.

Enjoy an unlimited number of programs, each day of the week can be individually programmed, and can have up to 8-periods per day!

Step 1

On the main screen, tap the mode icon



Step 2

Next to Current Program, Tap [Edit]



Switch to run another program.


Step 3

Tap a day of the week, or days in a group.



Step 4A: View

View the program



Select to alternate between Graphic and List Views
Switch View

List
Expanded view of daily setpoints

High/Low setpoints and average temperature for the day

Step 4B: Set

Set the periods and define the set points of the program

PERIODS
Divide a day into 2 to 8 periods as needed

SETTING
For each period, set the **Starting** time, the **Set-to** temperature, or set the period to **Off**. The settings end when the next period starts

SAVE & EXIT

INSERT
Insert a period before the current one; an hour of time will be given by default

DELETE
Delete the current period. The next period will splice together with the one deleted

11

Step 4C: Copy

Copy to other day(s)

Use the **App or Webpage** to change the name of a program, and to **add or delete** a program.

Tap the day to select, tap again to deselect

Copy all the settings to one or more days of the week

Download App

www.vinesmarthome.com



XING CONTROL
XING CONNECTED CORP. (ZIBO)
WWW.XINGCONNECTED.COM



13

Add Device to Account using Verification Code


After you create your account in the App or Webpage, you need to add the device to your account in order to remotely access the device. Simply follow on screen instructions in App or Webpage to complete this task.

- 1) Have the device connected to the internet (see Wi-Fi instructions on the other side of this guide.)
- 2) You need to be physically next to the device.

On the Wi-Fi status screen, tap App/Cloud Registration.

Next, in the App or Webpage, enter the **MAC ID** and **Temp. Verification Code** displayed on the screen.


- The MAC ID is a unique network ID for this device. This helps to identify your device over the internet.
- The Temporary Verification Code (TVC) is a 4-digit code randomly generated each time you enter this screen or enter the code. It expires in 90 seconds, then a new one will be needed.
- A QR code including both the MAC ID and TVC is generated for your convenience.
- During technical support, the TVC also functions as the verification of "the user currently in possession of the device".



Tap to generate a new code

14

Program with App/Webpage




New Schedule Period: Tap a time column to mark the beginning of a new period, then drag the remaining section up and down to finalize the set points.

Delete a Period: Drag a section of the schedule you want to remove to merge it with the previous or next period.

15

Mode Setup



Heating, Cooling, & Fan Operation

READINGS: The current temperature reading is the result of a comprehensive algorithm that averages the last five minutes of the surrounding environment. The device will take approx. 20 minutes to obtain the reading and reflect the actual room temperature after its initial start-up.

SCREEN TIMEOUT: There are several waiting periods whenever the system switches modes automatically or manually. Each waiting period (screen timeout) can be displayed up to 5 minutes with no action while the system awaits engagement.

DEADBAND: The default setting for deadband (also called a neutral zone or an interval [band] where no action occurs [the system is 'dead' - i.e. the output is zero]) is +/-1.8°F around the set points. When Auto is selected, the thermostat will operate within +/-3°F around the set points. To adjust the boundaries, enter PM at the System Activation screen.

SYSTEM OFF: You can turn the system off and stop the current program from running; the system can also be set to OFF for any specific time period within a program. While the system is off, fan operation and programming are not available.

16


System Lock, Unlock

There are three ways to lock and unlock the thermostat:


1. Push the rectangular button on the left side of the thermostat, or
2. Go to **System Menu** => **Activation** => **Sys. Locking**
Once the System Locking Screen appears, enter a 4-Digit Locking Code to lock the thermostat and enter the same code to unlock it.
3. The App or Web Portal may also be used to lock and unlock the thermostat. There is no need for a password in this scenario.

The password chosen is not saved or permanent, meaning a new 4-Digit Locking Code can be used any time the thermostat is locked.

To unlock the device without the locking code, simply take the thermostat off the wall plate, then mount it back.



17



Date, Time

Only the current date and time may be entered.

Date and Time can be set from the device, App, or can be automatically updated from the internet.

ON DEVICE: There is no restriction for any date and time you want to set as current. However, once the device is registered or linked to a user account, the date and time on the device will automatically update with the current time associated with the user account.

APP or WEBSITE: Select your time zone; the date and time for the device as well as the user account will automatically update.

AUTO UPDATE FROM INTERNET: An option from the System Menu allows the device to synchronize the time with the user account.

Weather & Location

The weather forecast is an internet enabled feature which requires a specific location for the device. The location is automatically determined when adding the device to the user account. You can also log into your account in the App or Webpage to assign a location to the device.

18

Temperature Limits, Alert Messages

These are NOT safety features to rely on!


Abnormal Conditions Alert

Adjust the temperature limits at which an Abnormal Conditions Alert message will be sent to the message box of your account and to the device. Select **Never** to bypass this feature.

Auto Heating or Cooling


During a mild weather season, people may select to turn system off while out for an extensive period of time for vacationing. This feature automatically turn heating or cooling on when the room temperature reaches certain limit.

To adjust Auto Heating or Cooling setpoints, enter PM at System Activation screen.



System Message

System messages can be self-generated by the device or sent by the Smart Cloud Server over the internet. You can view the message on the device: **System Menu** -> **Activation** -> **Sys. Message**, or in the message center of your account in the App or Webpage. Some messages may require you to reply by selecting the options provided while others serve to inform you.



Activation, System Codes

Features listed may not be available to your device

Your Smart Wi-Fi Vine Thermostat comes with many advanced features; some are displayed here and are directly accessible on the device, some through the App or Webpage, while many others operate automatically within the device.

Tap the codes on the screen to access related features or functions.

Over time, you may encounter new feature activations or situations during technical support that may require you to gain access to locked features.

You may receive instructions by phone or e-mail from one of our support technicians.

INTERNET CONNECTION REQUIRED

Many advanced features require an internet connection and a user account to link the device.

20

THIS DOCUMENT CONSISTS OF IMPORTANT LIMITED WARRANTY INFORMATION REGARDING YOUR CLAIMS AND ACCOUNTABILITY, AS WELL AS RESTRICTIONS AND EXCLUSIONS THAT MAY APPLY TO YOU.

1. WHAT THIS LIMITED WARRANTY ENTAILS; DURATION OF COVERAGE

Xing Connected, Pleasanton, California USA, warrants to the owner of the enclosed product that the product contained in this box will be free from defects in materials and workmanship for a period of two years from the date of delivery following the original retail purchase. If the Product fails to conform to this Limited Warranty during the Warranty Period, Xing Connected will, at its sole discretion, either (a) repair or replace any defective Product or component, or (b) accept the return of the Product and refund the money actually paid by the original purchaser for the Product. Repair or replacement may be made with a new or refurbished product or components, at Xing Connected's sole discretion. If the Product or a component incorporated within it is no longer available, Xing Connected may, at its sole discretion, replace the Product with a similar product of similar function. This is your sole and exclusive remedy for breach of this Limited Warranty. Any Product that has either been repaired or replaced under this Limited Warranty will be covered by the terms of this Limited Warranty for the longer of (a) ninety days from the date of delivery of the repaired Product or replacement Product, or (b) the remaining Warranty Period. This Limited Warranty is transferable from the original purchaser to subsequent owners, but the Warranty Period will not be extended in duration or provided in coverage for any such transfer.

2. TOTAL SATISFACTION RETURN POLICY

If you are the original purchaser of the Product and you are not satisfied with this Product for any reason, you may return it in its original condition within thirty days of the original purchase and receive a full refund.

3. WARRANTY TERMS; HOW TO RECEIVE SERVICE IF YOU WANT TO CLAIM UNDER THIS LIMITED WARRANTY

Before making a claim under this Limited Warranty, the owner of the Product must (a) notify Xing Connected of the intention to claim by visiting vinesmarthome.com/support during the Warranty Period and providing a description of the alleged failure; and (b) comply with Xing Connected's return shipping instructions. Xing Connected will have no warranty obligations with respect to a returned Product if it determines, in its reasonable discretion after examination of the returned Product, that the Product is an Ineligible Product (defined below). Xing Connected will bear all costs of return shipping to owner and will reimburse any shipping costs incurred by the owner, except with respect to any Ineligible Product, for which owner will bear all shipping costs.

4. WHAT THIS LIMITED WARRANTY DOES NOT COVER

This Limited Warranty does not cover the following (collectively "Ineligible Products"): (i) Products marked as "sample" or "Not for Sale" or sold "AS IS"; (ii) Products that have been subject to: (a) modifications, alterations, tampering, or improper maintenance or repairs; (b) handling, storage, installation, testing, or use not in accordance with the User's Guide or other instructions provided by Xing Connected; (c) abuse or misuse of the Product; (d) breakdowns, fluctuations, or interruptions in electric power or the telecommunications network; or (e) Acts of God, including but not limited to lightning, flood, tornado, earthquake, or hurricane; or (iii) any non-Xing Connected branded hardware products, even if packaged or sold with Xing Connected hardware. This Limited Warranty does not cover consumable parts, including batteries, unless damage is due to defects in materials or workmanship of the Product, or software (even if packaged or sold with the product). Xing Connected recommends that you use only authorized service providers for maintenance or repair. Unauthorized use of the Product or software can impair the Product's performance and may invalidate this Limited Warranty.

5. DISCLAIMER OF WARRANTIES EXCEPT AS STATED ABOVE IN THIS LIMITED WARRANTY, AND TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, XING CONNECTED DISCLAIMS ALL EXPRESS, IMPLIED, AND STATUTORY WARRANTIES AND CONDITIONS WITH RESPECT TO THE PRODUCT, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, XING CONNECTED ALSO LIMITS THE DURATION OF ANY APPLICABLE IMPLIED WARRANTIES OR CONDITIONS TO THE DURATION OF THIS LIMITED WARRANTY.

6. LIMITATION OF DAMAGES

IN ADDITION TO THE ABOVE WARRANTY DISCLAIMERS, IN NO EVENT WILL XING CONNECTED BE LIABLE FOR ANY CONSEQUENTIAL, INCIDENTAL, EXEMPLARY, OR SPECIAL DAMAGES, INCLUDING ANY DAMAGES FOR LOST DATA OR LOST PROFITS, ARISING FROM OR RELATING TO THIS LIMITED WARRANTY OR THE PRODUCT, AND XING CONNECTED TOTAL CUMULATIVE LIABILITY ARISING FROM OR RELATED TO THIS LIMITED WARRANTY OR THE PRODUCT WILL NOT EXCEED THE AMOUNT ACTUALLY PAID FOR THE PRODUCT BY THE ORIGINAL PURCHASER.

7. LIMITATION OF LIABILITY

THE XING CONNECTED ONLINE SERVICES ("SERVICES") PROVIDE YOU INFORMATION ("PRODUCT INFORMATION") REGARDING YOUR XING PRODUCTS OR OTHER PERIPHERALS CONNECTED TO YOUR PRODUCTS ("PRODUCT PERIPHERALS"). THE TYPE OF PRODUCT PERIPHERALS THAT MAY BE CONNECTED TO YOUR PRODUCT MAY CHANGE FROM TIME TO TIME. WITHOUT LIMITING THE GENERALITY OF THE DISCLAIMERS ABOVE, ALL PRODUCT INFORMATION IS PROVIDED FOR YOUR CONVENIENCE "AS IS," AND "AS AVAILABLE." LIMITED WARRANTY DOES NOT REPRESENT,

WARRANT, OR GUARANTEE THAT PRODUCT INFORMATION WILL BE AVAILABLE, ACCURATE, OR RELIABLE OR THAT PRODUCT INFORMATION OR USE OF THE SERVICES OR PRODUCT WILL PROVIDE SAFETY IN YOUR HOME. YOU USE ALL PRODUCT INFORMATION, THE SERVICES, AND THE PRODUCT AT YOUR OWN DISCRETION AND RISK. YOU WILL BE SOLELY RESPONSIBLE FOR (AND XING CONNECTED DISCLAIMS) ANY AND ALL LOSS, LIABILITY, OR DAMAGES, INCLUDING TO YOUR WRITING, FIXTURES, ELECTRICITY, HOME, PRODUCT, PRODUCT PERIPHERALS, COMPUTER, MOBILE DEVICE, AND ALL OTHER ITEMS AND PETS IN YOUR HOME, RESULTING FROM YOUR USE OF THE PRODUCT INFORMATION, SERVICES, OR PRODUCT. PRODUCT INFORMATION PROVIDED BY THE SERVICES IS NOT INTENDED AS A SUBSTITUTE FOR DIRECT MEANS OF OBTAINING THE INFORMATION. FOR EXAMPLE, A NOTIFICATION PROVIDED THROUGH THE SERVICE IS NOT INTENDED AS A SUBSTITUTE FOR AUDIBLE AND VISIBLE INDICATIONS IN THE HOME AND ON THE PRODUCT, NOR FOR A THIRD PARTY MONITORING SERVICE THAT MONITORS ALARM STATE.

8. YOUR RIGHTS AND THIS LIMITED WARRANTY

This Limited Warranty gives you specific legal rights. You may also have other legal rights that vary by state, province, or jurisdiction. Likewise, some of the limitations in this Limited Warranty may not apply in certain states, provinces or jurisdictions. The terms of this Limited Warranty will apply to the extent permitted by applicable law. For a full description of your legal rights you should refer to the laws applicable in your jurisdiction and you may wish to contact a relevant consumer advisory service.

LIMITED WARRANTY
Please visit our website for the complete disclosure of this statement!

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning:

The device has been evaluated to meet general RF exposure requirement. To maintain compliance with FCC's RF exposure guidelines, this equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.