# smart watch **Intelligent Sports Watch** Instructions

### ◆Description of Appearance



## ◆Schematic Diagram of Charging

equipment.


P32-V1.4

Operate strictly according to the following figure: 1. Charge the product by aligning the magnetic charging cable supplied with the product to the charging contact on the back of the watch.

2.Insert the USB plug into the USB adapter. (No adapters are included in the package.)

3.Do not use a battery adapter with a voltage exceeding 5V and an output current exceeding 1A for charging, otherwise it will cause charging failure and damage the magnetic charging cable or

4.When the watch is recharged after it is out of power, it needs to be activated first, and the watch screen will light up within about 5 minutes of normal charging.



## ◆Function Introduction

1.On/Off key: Long press the On/Off key to power on the device. On the function interface, press the key to return to the previous menu. 2.Main Time Interface:

1) Slide the screen up/down or left/right to switch between functions.

2 Press the side key to brighten or darken the screen.





connected to set real-time monitoring and view the data







Power Off, and View Watch Information. Swipe right to



with the App. In addition, the mobile phone GPS should have been turned on and the App can



tch can control the phone's d on the phone player before it can be controlled on the watch. (Note that this function needs to be connected to the mobile phone and

ver to play/pause/previous

g. This function must be

open the message push permission)



## ◆ Installation and Connection of Watch App

This product is a Bluetooth product. Many functions can be used normally only after the supporting App has been connected. For example, Watch Time, Call Reminder, WeChat Reminder, etc. can be used normally only when the App is connected at all times. (For Bluetooth on the mobile phone.) Scan the following QR code with the mobile phone and select a version suitable for its operating system or enter a major App marketplace to download and install "Glory Fit".



## Device Linking

Turn on the downloaded App to set the connection. The Bluetooth on the mobile phone needs to be on. Android phone users should turn on the GPS positioning function on the mobile phone and support the App to have the authority to read mobile phone positioning To use the device for the first time, you need to register an account with an email address use a third-party sign-on system or click Skip to log in as visitor. The use of an account experience. The watch is connected as follows:



Exercise" to switch and view the state of motion and motion trail. (You need to carry the mobile phone when exercising and the GPS on the mobile phone needs to be enabled.) Click "Pause" or long press "End" to stop the sport.

₫ 240 Excellent

0.00

page, you can set Personal Information, Exercise Goal, etc.

Call reminder

APP reminder

Sedentary reminder

Raise hand to activate display

👸 Smart alarm clock

Do not disturb

Universal settings

C Firmware upgrade

\* Clear data

4. Click the "Device" and "My" pages to set the Watch Dial, Heart Rate Monitoring, App

Physiological Cycle

O Common problem

Home Sports Desice Side Home Sports Device Side

Background Activity Permissions

Third party access

Reminder, "Shake to Take Pictures" in More Reminders, etc. respectively, On the "My

Running outdoors this month 0.40 Kild

## ◆ App Operating Instructions

Note: A mobile phone using Android operating system must allow the App to

obtain the authority and run in the background, otherwise, the use experience

1. Enter the homepage of the App and view the current synchronized data of the watch. Slide the screen down to refresh the synchronized data manually. Click the [Step Count Icon] to view the sports data and history on the watch. Click the weather icon on the top left corner to obtain and view the local weather conditions or enter a city name manually to position and obtain weather.



2. Click the Heart Rate, Blood Pressure and Sleep Record modules to view the heart rate record of the whole day (the automatic heart rate monitoring function needs to be enabled), blood pressure measurement record, and yesterday's sleep record and analysis. Click the calendar icon on the top right corner to view the history.



### 3. On the Sports interface, you can add your preferred frequently used sports. Click "Start

- Do not charge in condition of water stains.
- 2. This product is an electronic monitoring product, which is not used as medical treatment. The data is for reference only.
- 3. Don't wear this device when bathing or swimming for a long time.
- 4. Use the matching charging cable for charging.

1. Why the watch cannot be searched in the App?

- A: a. When the Bluetooth on the watch is not searched by the mobile phone during Bluetooth broadcast, the Bluetooth on the watch will sleep. Please turn off the Bluetooth on the watch and that on the mobile phone and search and connect the Bluetooth again about one minute later.
- b. The GPS positioning function on the mobile phone must be turned on. In "Setup" on the mobile phone using Android operating system, be sure to allow the App to obtain the positioning authority.

#### 2. Why the watch cannot receive reminders?

- A: To use the App for the first time, on the "Device" page, click "App Reminder" and the message reminder notification authority will pop up automatically. Please select "Glory Fit to allow reading. Click the auxiliary function again to enable the Glory Fit message notification function and, in the App, enable the corresponding third party reminder notification function.
- 3. Why no reminders are received after the reminder function has been enabled?
- A: If the message notification function and the corresponding notification authority have been enabled, the Bluetooth on the mobile phone should be kept on and connected to the watch at all times. For example, only when WeChat or QQ has not been logged in on otherclients will the message reminder function on the watch be available when an message pops up on the mobile phone. A mobile phone using Android operating system must allow the App to run in the background and set white lists.

## **♦FCC Requirement**

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or

more of the following measures: - Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

P32-V1.3 USB adapter 1