

## P15 WIRELESS HEADPHONE

### Key Operating Instructions :

- 1.Power:Turn on/off key,Long press three seconds is power on.off
- 2.–PREV/VOL–  
In Wireless mode,Short Press: Previous; Long Press: volume–  
In MP3 mode,Short Press: Previous; Long Press: volume–  
In FM mode, Short Press: Previous a frequency; Long Press: volume–
- 3.PLAY  
In Wireless mode when get the calling:Short Press is answer the calls;Long Press is Refuse to listen, continuous push 2 times is redial  
In Wireless mode, Short Press: play/pause;  
In MP3 Mode,Short Press :Play/Pause  
In FM mode,Short Press:Automatic searching the broadcasting station.
- 4.+NEXT/VOL+:  
In Wireless mode, Short Press: next; Long Press: volume+  
In MP3 mode, Short Press: next; Long Press: volume+  
In FM mode, Short Press: next frequency; Long Press: volume+
- 5.Mode:  
Short Press to change the mode,Wireless /MP3/FM Radio/AUX LINE IN;

### LED Indicator:

In In Wireless mode, the blue/green light will be twinkle flash,when the headphone matches the phone successfully, the blue light will slow flashing when connection successful .  
In MP3 mode,the green light will slow flashing when playing;  
In FM mode,the green light is on steadily when hearing the FM radio, the light twinkles fast when searching the FM radio  
In charging mode: the red light is on steadily when charging,when it's fully charged, the red light will be off.

### Wireless using the operating manual:

1. Short Press the power key three seconds to open the power, it is Wireless of the default open
- 2.The blue/green light twinkles fast,Wireless into pairs.
- 3.When your mobile phone searches the Wireless product,the Wireless name is P15
- 4.When your mobile phone searches the Wireless product and connects successfully,if it displays need put into the password,the password is 0000
- 5.The blue light will continuous flash 2 times on each 5 seconds after Wireless connects successfully
- 6.When you open your mobile phone of music player,you can listen to the music,this product can control the next song and previous song by Wireless ,play and pause, answer the phone and redial, etc.

### MP3 Operating Instructions

1. Short Press power key three seconds to open the power;
2. Insert TF card that the MP3 will play automatically. Or long press the mode key and will switch to MP3 mode.
3. Short press the Play key:MP3 play/pause;
4. Short Press Next/Previous: :next/previous song
5. Long Press Next/previous:Volume+/-

### FM Operating Instructions

1. Short Press power key three seconds to open the power;
2. Short Press Mode key to FM Mode;
3. In FM mode ,short press the Play key is automatic searching all the frequency.
4. Short Press Next or Previous: select the frequency that has been searched.
5. Long Press Next or Previous:Volume+/-

### LINE Connecting To Audio Jack:

1. Power on mode ,short press MODE key will turn to AUX LINE IN mode.
2. Support mobile phone/iPod/MP4/MP3/CD/PC,etc

### Functional Parameter:

USB charge : DC 5V IN  
FM frequency : 87.5–108MHz  
Wireless frequency :2.401–2.480GHz  
Wireless distance:10 meters  
Frequency : 50Hz–20KHz  
Output power:35mW  
SNR : 88dB  
Charging time : ≤2 hours

### FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

### FCC RF Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

Company name: Guangdong Liangying Electronic Industrial Co. Ltd.

Address:Gurao Town,Chaoyang District, Shantou City,Guangdong,China.

FCC ID:2AGKLCBE121719

Remarks:If the headset cannot be turned on,please charge the headset and use it again.