


封面  
90mm

正

# User Manual



EN

Made in China

### Welcome:

Thank you for choosing this wireless product. To ensure optimum performance and safety, please read these instructions carefully before operating this product. It is strongly recommended you keep this manual for future reference.

### Issue? Let us help you right away!

Our goal is your complete satisfaction. That's why we offer you a satisfaction guarantee. If you have any issues at all, please reach out to us right away  
Sales@sz-deying.com

### Package Contents:

- 1 x Wireless Keyboard C203
- 1 x Wireless Mouse TM176G
- 1 x User Manual

### Keyboard Product Specifications:

1. Key Type: Crater keys
2. Battery Type: 1 AA battery
3. USB 2.0 interface, plug&play, no driver required
4. Compatible with Win XP, Win Vista, Win7, Win8, Win8.1, Win 10, Mac
5. Operating Voltage: 1.5V
6. Operating Current: 20mA
7. Sleeping Current: 100uA
8. Sleeping Time: 5 minutes
9. Keystroke: 50±5gf
10. Key life: 10 million key strokes
11. Dimension: 445\*186.8\*20mm
12. Weight: 550g

EN1

### Keyboard Instructions:

The wireless keyboard use one AA battery (not include). Open the battery compartment cover. Install the battery in to the compartment, and make sure the polarity of the battery is correct. the positive (+) and negative (-) ends of battery must match the positive (+) and negative (-) markings in the battery housing .

### Keyboard Re-pairing Method:

1. Unplug the USB receiver
2. Plug the USB receiver to the USB port, keep the keyboard and USB receiver distance within 20cm, Press "Esc + K" keep 5S right away, then the keyboard light will flash, it is successfully re-paired.

**IMPORTANT NOTE:** You must complete all operations in step 2 within 10 seconds after you Plug the USB receiver to the USB port.

### Mouse Re-pairing Method:

Press and holding "right key+center key" to re-connect.

### Functional Zone:

Press "Num Lock" button, the LED of "1" will turn off and the numeric zone will change to functional zone.

Number "2", "4", "6", "8" are for down, left, right, up direction.

Number "1", "3", "7", "9" are for "End", "Page Down", "Home", "Page Up".

Number "0" is for "Insert".

Decimal point is for "Delete".

EN2

反

### LED Indicator:

Num Indicator: It will show Blue color when the numeric zone is on and the functional zone is off.

Low Power Indicator: The three LED will flash together for 8 seconds when the voltage is lower than 2.2V. This will happen when you wake up the keyboard after sleeping or when you turn it on again until you change the battery.

### Wireless Mouse:

Product Specifications:

1. Working Frequency: 2.4GHz
2. Operation Voltage: 1.5V
3. Battery Type: 1 AA battery
4. Current Dissipation: 1.5V-10mA
5. Standby Current: 0.5-2.0mA
6. Sleeping Current: <0.1mA
7. Sleeping Time: 25 seconds
8. DPI Resolution: 800/1200/1600
9. Working Distance: ≤10M
10. Key Life: 3 million
11. Dimension: 38.29\*107.5\*59.5mm
12. Weight: 90g

EN3

### FCC Caution.

#### § 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### § 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### § 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

#### \* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

尺寸：90\*90mm

材质：105G书写纸，单黑双面印刷，折叠

材质厚度：T=0.1±0.02mm