


1. What's in the Box

Check to ensure you have the necessary parts; which should include:

- 1 x Whitebox
- 4 x Antennas
- 1 x Network cable
- 1 x Power supply



Connect antennas to the back of the Whitebox. (These are used to passively monitor nearby wireless networks for traffic, to ensure no tests are run when the line is active – we do not monitor your traffic)



2. Connect


If you have a combined modem / router

Connect one end of the network cable to a spare port on your router. Connect the other end to the blue port marked "Internet" on the rear of the Whitebox.



If you have a separate modem and router

Keep your NBN connection or modem connected to your separate router as usual.



3. Plug in wired devices


Disconnect any other wired network devices from your home ADSL / cable router. Plug them into the ports marked 1 – 4 on the rear of the Whitebox. (Please note the USB ports are non functional)

4. Power up

Connect the **power supply** to your Whitebox. Switch on at the mains socket, then press the button on the back marked **'ON/OFF'**.

When the light below the  icon remains steady the Whitebox is fully set up.

Make sure everything is connected before you switch on.



5. Log in

Your Whitebox is now ready to start testing your internet performance. You can directly login into nbn-nielsenpanel.com to check the status of your account.



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and consider removing the no-collocation statement.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment..

The equipment complies with FCC Radiation exposure limit set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.