

Exos Bluetooth® Headphones


100245-001B

Instruction Manual



IC ID: 21530-100245
FCC ID: 2AGR4-100245

OVERVIEW



1. Power switch
2. Mute/function button (MFB)
3. Next Track/Volume UP
4. Previous Track/Volume Down
5. Mode switching
- 6, 3.5mm audio port

7. LED Indicator Light
8. Micro USB Charging Port
9. Mute/function button
10. Micro SD slot

BLUETOOTH® OPERATION

1. Please ensure that the Bluetooth function has been turned on in the settings of your Bluetooth enabled device.
2. Turn the headphone on by Sliding the Power switch. The LED indicator light will flash to detect Bluetooth enabled devices near you and will enter pairing mode.
3. "GENLINE HP" will appear on the Bluetooth device list, select "GENLINE HP" to establish pairing. If instructed to enter a PIN code, please enter "0000".
4. The LED indicator light will turn blue to indicate successful pairing.
5. When you want to play audio from another Bluetooth device, disconnect the headphone from the original device and follow steps 1-3 to re-pair the headphones with a new Bluetooth enabled device.

BUTTON CONTROL

- Power On/Off: Slide the Power switch
- Play/Pause: Short press the MFB button
- Volume Up/ Next Track: Short press + button once to change music to next track. Press and hold to increase volume.
- Volume Down/ Previous Track: Short press - button once to change music to previous track. Press and hold to decrease volume.

HANDS-FREE PHONE USE

- Answer incoming call: Short press MFB button.
- End call: Short press MFB button.
- Redial last call: Short press MFB button twice
- Reject incoming call: Press and hold MFB button.

AUX PLAYBACK OPERATION

1. Turn on the headphone.
2. Connect the headphone to a smartphone, audio device, or laptop with the 3.5mm AUX cable (included)
3. The next (previous) song, volume, and play/pause buttons can only be adjusted on the device that is connected through the 3.5mm AUX cable.

SD CARD PLAYING

Insert a SD card, the headphone will play the music on the card automatically.
Short press Mode switch can be changed to Bluetooth mode.

CHARGING THE HEADPHONE

1. When the battery is low, please charge via the included USB cable. The charging time is approximately 3 hours and provides up to 6 hours of continuous operation. Standby time is approximately 12 hours.
2. The LED indicator light will be red during charging and will be no light once it is fully charged

WARNING

1. Do not disassemble, repair, or modify the headphone.
2. Do not place product in or near fire to avoid danger, as it uses a lithium battery.
3. Avoid storage at extreme temperatures; this can shorten the battery life and may affect the headphone.

Front Cover

page 02

page 03

page 04

page 05

SPECIFICATION

- Model: Exos Bluetooth® Headphones
- Bluetooth Specification: Bluetooth® V4.2
- Profiles Supported: A2DP, AVCTP, AVDTP, AVRCP
- HFP, SPP, SMP, ATT, GAP, GATT, RFCOMM, SDP, ZCAP
- Wireless Working Range: 10m (without obstacles)
- Built-in Battery: Lithium Battery, 300mAh
- USB Recharge Voltage: DC 5V
- Output Power: 6.5mW
- Frequency Response: 20Hz-20KHz

PACKING LIST

- Bluetooth® Headphone
- USB Charging Cable
- 3.5mm AUX Cable
- Storage Pouch
- User Manual
- Gift Box

KIND REMINDER

1. To protect the headphone life span and to avoid hearing damage, please do not listen to music under high volume for long periods of time.
2. When an error occurs with the headphone, please turn off the headphone and restart it to troubleshoot.
3. When the headphone power is low, the Bluetooth range may be affected. Please charge the headphone to avoid disruptions during use.

Problem

Unable to pair the headphones with a mobile device

Troubleshooting Method

1. Please switch the headphones on separately for a Bluetooth enabled device to connect to. If not, restart the headphone.
2. Difficultly in searching and connecting to a desired device, please turn off or disable the Bluetooth function on the mobile device.
3. The power of the battery is insufficient, please recharge the headphone.

Problem

The music stops from time to time

Troubleshooting Method

1. Inspect the distance between the headphone and the transmission range.
2. Inspect if there is an obstacle between the headphones.
3. The power of the battery is insufficient, please recharge the headphone.

Problem

The sound is low or distorted

Troubleshooting Method

1. Inspect the volume of the connected headphones or Bluetooth enabled device and adjust the volume as needed.
2. The power of the battery is insufficient, please recharge the headphone.

Problem

The Bluetooth indicator light remains OFF

Troubleshooting Method

1. The power of the battery is insufficient, please recharge the headphone.
2. Restart the headphone.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by The Gem Group is under license. Other trademarks and trade names are those of their respective owners.

The device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) L'appareil ne doit pas produire de brouillage; (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the

instructions, there is no cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Back Cover

page 06

page 07

page 08

page 09