

76.2mm

Brooks Bluetooth® Earbuds

---

IC ID: 21530-101140  
FCC ID: 2AGR4-101140

BC Instruction Manual

**OVERVIEW**

L R

1. LED Indicator Light
2. Volume Up / Next Track Button
3. Power/Multi-function Button
4. Volume Down / Previous Track Button
5. Micro USB Charging Port
6. Mic

**SPECIFICATION**

Bluetooth specifications: Bluetooth® version 5.0  
Support profile: A2DP,AVRCP,HFP,HID,AVCTP,AVDTP,SPP  
Transmission distance: up to 10m (This may vary based on environmental factors or the type of Bluetooth® device being used)  
Built-in battery: 65 mAh Lithium Battery  
USB Recharge voltage: 3.7V  
Frequency Response: 20hz-20Khz  
Sensitivity: 100dB ± 3  
Product dimensions: 24.5x11.8x580mm  
Playback time: 5-6 hours  
Charging time: 2 hours

**PACKING LIST**

- Bluetooth® Earbuds
- USB Charging Cable
- Silicone Earbud Covers
- Travel Case
- User Manual

**BLUETOOTH® OPERATION**

1. Please ensure that the Bluetooth function has been turned on in the settings of your Bluetooth enabled device.
2. Turn the earbuds on by pressing the power/multifunction button until the LED indicator light begins to flash. The LED indicator light will flash to detect Bluetooth enabled devices near you and will enter pairing mode.
3. "GEMLINE EB" will appear on the Bluetooth device list, select "GEMLINE EB" to establish pairing.
4. When you want to play audio from another Bluetooth device, disconnect the earbuds from the original device and follow steps 1-3 to re-pair the Earbuds with a new Bluetooth enabled device.

**BUTTON CONTROL**

- Power On/Off: Press and hold the power/multi-function button for approximately 4 seconds.
- Play/Pause: Press the power/multi-function button once to Play/Pause.

- Volume Up/Next Track: Press and hold "+" button to increase volume, press once for next track.
- Volume Down/Previous Track: Press and hold "-" button to decrease volume, press once for previous track.
- Hands-free Phone Use: Press the power/multi-function button once to answer an incoming call. While on a call, press the power/multi-function button once to end the call.
- Reject a call: Press and hold the power/multi-function button to reject a call.

封面

1

2

3

4

**CHARGING THE EARBUDS**

1. When the battery is low, please charge via the included USB cable. The charging time is approximately 2 hours and provides up to 5-6 hours of continuous operation.
2. The LED indicator light will be red during charging and will turn off once it is fully charged. When the battery is low, the LED indicator light will flash red.

**WARNING**

1. Do not disassemble, repair, or modify the earbuds.
2. Do not place product in or near fire to avoid danger, as it uses a lithium battery.
3. Avoid storage at extreme temperatures, this can shorten the battery life and may affect the earbuds.
4. Keep the earbuds dry and do not store the earbuds in damp areas to avoid damage to the earbuds.
5. Avoid dropping the earbuds as it may cause damage to the product.

**KIND REMINDER**

1. To prolong the earbuds life span and to avoid hearing damage, please do not listen to music under high volume for long periods of time.
2. When an error occurs with the earbuds, please turn off the earbuds and restart it to troubleshoot.
3. When the earbuds power is low the Bluetooth range may be affected. Please charge the earbuds to avoid disruptions during use.

PROBLEM	TROUBLESHOOTING METHOD
Unable to pair the earbuds with a mobile device	<ol style="list-style-type: none"> <li>1. Inspect whether the earbuds are searching for a Bluetooth enabled device to connect to. If not, restart the earbuds.</li> <li>2. Difficulty in searching and connecting to a desired device can be affected if multiple devices are equipped, turned on, and in range for Bluetooth connectivity. Please turn off or disable the Bluetooth function on the other devices.</li> <li>3. The power of the battery is insufficient, please recharge the earbuds.</li> </ol>

PROBLEM	TROUBLESHOOTING METHOD
The music stops from time to time	<ol style="list-style-type: none"> <li>1. Inspect the distance between the earbuds and the Bluetooth enabled device, it may exceed the Bluetooth transmission range.</li> <li>2. Inspect if there is an obstacle between the earbuds and the Bluetooth enabled device.</li> <li>3. The power of the battery is insufficient, please recharge the earbuds.</li> </ol>
The sound is low or distorted	<ol style="list-style-type: none"> <li>1. Inspect the volume of the connected earbuds or Bluetooth enabled device and adjust the volume as needed.</li> <li>2. The power of the battery is insufficient, please recharge the earbuds.</li> </ol>
The Bluetooth indicator light remains OFF	<ol style="list-style-type: none"> <li>1. The power of the battery is insufficient, please recharge the earbuds.</li> <li>2. Restart the earbuds.</li> </ol>

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by The Gem Group is under license. Other trademarks and trade names are those of their respective owners.

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

ISED Statement

- English: This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B).

French: Cet appareil contient des émetteurs/récepteurs exempts de licence qui sont conformes aux RSS exemptés de licence d'Innovation, Sciences et Développement économique Canada. L'exploitation est soumise aux deux conditions suivantes:

- (1) Cet appareil ne doit pas provoquer d'interférences.
- (2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.

L'appareil numérique conforme canadien peut émettre/recevoir de l'énergie radiofréquence et, s'il n'est pas installé et utilisé conformément aux instructions, peut causer des interférences nuisibles aux communications radio. Cependant, aucune garantie n'est donnée que des interférences ne se produiront pas dans une installation particulière. Si cet équipement provoque des interférences nuisibles à la réception radio ou télévision, ce qui peut être déterminé en éteignant et rallumant l'équipement, l'utilisateur est encouragé d'essayer de corriger l'interférence par l'une ou plusieurs des mesures suivantes:

- Réorienter ou déplacer l'antenne réceptrice.
- Augmenter la séparation entre l'équipement et le récepteur.
- Brancher l'équipement sur une prise d'un circuit différent de celui auquel le récepteur est branché.
- Consulter le revendeur ou un technicien expérimenté en radio/TV pour obtenir de l'aide.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

PMN: Brooks Bluetooth Earbuds

5

6

7

8

封底

76.2mm