

Bluetooth Headphone

BT86

User Manual

SPECIFICATIONS

Bluetooth version: Bluetooth V3.0+EDR

Support: HFPV1.5, A2DPV1.2, AVRCPV1.4, HSP1.2, GAVDP1.2, IOP

SNR: 96dB SNR stereo ADC and stereo DAC

Sensitivity: -80dBm<0.1%BER

Transmission distance: 10m

Frequency: 2.402 -2.480GHZ

Transmission power: CLASS2, 4dbm

Audio SNR: \geq 75dB

Audio performance: SBC decoding

Battery capacity: 3.7V/300mAH L

Charging voltage: DC5V

Charging time: about 1 hour

Working currency: \leq 40mA

Standby currency: <500uA

Working temperature: -40°C to +85°C

Play time: about 7 hours

Working time: about 8 hours

Standby time: about 400 hours

OPERATION GUIDE

Power On: Long press **►||** for 2 seconds, voice prompt Power On" .
Power Off : Long press **►||** for 2 seconds, voice prompt "Power Off" .
Answer/Hang up Calls: Single press **►||**
Re-dial Last Phone Call: Double press **►||**
Play/ Pause Music: Single press **►||**
Volume +/-: Long press **| <| /| >| +**
Previous/Next Song: Single press **| <| /| >| +**
Aux-in: The headset will switch to wired mode automatically once insert the audio cable to the Aux-in port and audio device, no need power.

PAIRING

1. Initial Pairing: Bluetooth headset will enter pairing mode automatically, voice prompts "Pairing" . Turn on Bluetooth function on device and select BT86, no PIN code needed. Voice prompts "connected" when pairing successfully.
2. Re-Pairing: Long press **►||** for about 2 seconds in power off mode, headset enter pairing mode when red and blue LED indicator lights flash quickly.
3. Bluetooth headset will pairing connected device automatically when power on.

LED INDICATOR LIGHT

1. Charging: Red light keeps on in charging mode, blue light on when fully charged.
2. Power on: Blue light flash for 1 time.
3. Pairing mode: Red and blue lights flashing alternately.
4. Paired mode: Blue light flash every 1.5 seconds.
5. Standby mode: Blue light flash every 1.5 seconds.
6. Play mode: Blue light flash every 1.5 seconds.
7. Power off: Red light keeps on for 3 seconds.

ATTENTION

1. The port at the button of headset is for audio input only, please DO NOT connect other headphones.
2. Please charge the Bluetooth headset when voice prompts "Battery Low" .
3. To prevent possible hearing damage, do not listen at high volume levels for long periods.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.