



User Manual

【Buttons and Ports】



1. Power button
2. Type-C port
3. USB port

4. Audio jack
5. DC port
6. HD port



7. Ethernet jack



to ensure safety and avoid hazards, we strongly recommend that you use the original power adapter for power supply.

*The specifications are subject to the actual product.

【VESA-mount Installation】



VESA-mount bracket



Fix the bracket to the mini PC with screws.



Fix the bracket to the back of the monitor with screws.


[Precautions for Use]

- In order to continuously improve the user experience, we may occasionally update applications and firmware
- Do not use strong chemical solvents to clean the product, and we recommend you wipe it with a soft cloth.
- Please keep this product away from fire.
- Please do not try to open the case or perform repairs yourself. If a failure occurs, please contact customer service.
- When cleaning the electronic product, please keep it dry and be cautious of electric shocks.
- Please check whether any cables or plugs are worn or damaged.
- Do not dispose of the product carelessly, be mindful to protect the environment.
- Ideal working environment temperature: 10°C-45°C; humidity: 30%-85%.
- Ideal storage environment temperature: -20-60°C; humidity: 10%-90%.

[RAM and SSD Installation (This operation should be performed when the power is disconnected)]



DDR SDRAM Installation (As shown in the figure)

1. Align the DDR SDRAM module with the RAM slot, then gently push the module into the slot at a 30° angle.
2. Press the module down until the DDR SDRAM is secured by the safety arms at both ends of the RAM slot.




SSD Installation(as illustrated in the picture)

- 1.Align the plug of the SSD and that of the M.2 slot on the motherboard, then gently push the SSD in.
- 2.Press the other end down and use screws to fix it in place.



[Steps for Connection]



1.Connect the mini PC to the power supply



2.Connect the mini PC to the monitor with an HD/DP cable



3.Connect the mini PC with a keyboard and a mouse


[Switching the Audio Playback Device in Windows]

If your PC is connected to multiple audio playback devices (eg. speakers, headphones, Bluetooth headset, monitors with built-in speakers, etc) simultaneously, you will need to choose one of them for audio playback.


1. Connect the mini PC to the power supply



2. Connect the mini PC to the monitor with an HD/DP cable




3. Connect the mini PC with a keyboard and a mouse




[HARD DISK INSTALLATION GUIDE]

[Remove the cover.]

1. Remove the 4 soft cushions



2. Unscrew the 4 screws



3. Remove bottom cover




4. The hard disc is inserted in the appropriate position



[put a lid on]


1. Installation of the rear cover



2. Put the screws in.



3. Put on the soft cushion.



FCC Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates,

uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference

to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.