
Double Sided



GETTING STARTED

Thank you for choosing the *Energizer*_® Smart Camera. This quick start guide will help you with setup and installation.



- Smart Indoor Camera Quick Start Guide
- USB Power Adapter • Camera Base
- **What You Need:**



6ft Micro USB Power

Mounting Equipment

Adhesive Non-Slip Disk

Cable

Reset Tool

and Drill Before setup, make sure your phone is connected to the 2.4GHz WiFi network that your device will be placed on. ou may also need to turn on location and luetooth to find nearby networks.

CONNECT THE DEVICE

STEP 1

WiFi network

Download the free *Energizer*_® Connect app from the App Store (for iPhones) or Google Play Store (for Android phones).



STEP 2 Make sure your mobile device is connected to your 2.4GHz

Open the app and click "Create Account" by following the



STEP 3

Plug the camera into a wall outlet using the provided 6 foot cable and USB power adapter

Please note, each time power is provided to the camera, it will pan and tilt to calibrate itself.

The indicator light on the camera should start blinking



If the LED is not blinking, then you are not in pairing, you need to manually rotate the camera and use the reset tool in the pinhole to push in and hold down the reset button for 5 seconds until you hear the camera make a chime sound



STEP 4

STEP 5

After logging in, click "+" on the top right of the screen and select "Add device".



Select the Camera category and confirm the indicator light is still blinking red. Click "Next Step".

> (2) Help: Switch between pairing modes. See troubleshooting page 16.



Click

STEP 6

Confirm that the displayed **WiFi** network is your **2.4GHz** WiFi network, enter your WiFi password and click "Confirm".

Enter Wi-Fi Password 2.4GHz 5GHz ×



Help: If you need information about 2.4GHz WiFi networks, click the link to go to our Connect FAOs on our website.

STEP 7

On the next screen, a QR Code will appear. Position your camera to scan this QR code on your phone.

Click "Continue" when you are ready.

Touch the lens of the camera directly against the QR code on your phone and




audible prompt from **Tip:** If you don't hear the prompt, the camera, click the try pairing using EZ mode. Take a "I Heard a Prompt" look at troubleshooting on page 16.

STEP 8

Your Smart Camera will now be connected to the network. Confirm the settings for your device and then Click "Done".

TIP: You can put your camera directly in a room by selecting one of the available rooms. Click the <a> button to change the name of the product






Your *Energizer* Smart Camera is now ready to use. You can now view the camera remotely and receive mobile alerts. We hope you enjoy using your *Energizer* Smart Camera. For frequently asked questions and instruction videos, please visit our website at www.energizerconnect.com.

INSTALLATION

The camera can be placed on a table, shelf, or can be mounted on a wall or ceiling. Select a location and height where you can get the desired view, and can reach a power outlet easily.


OPTION 1: Table Top, Shelf

Place your camera on a table, shelf or any flat surface




STEP 2

Connect the included micro USB cable connector to the camera's micro USB port and plug into the wall adapter




OPTION 2: Wall or Ceiling Mounting

Place the positioning card against the wall or ceiling and then mark the points at which drilling will be required



STEP 2


Drill holes with a 5/16" (8 mm) drill bit



Align the holes on the mounting plate with those in the wall or ceiling. Insert the anchors into the holes; anchors are necessary for walls that are made out of hard materials such as concrete, brick, or stucco. Fix the screws with a Phillips-head screwdriver to fasten the mounting plate to the ceiling

STEP 3


Position the camera's base at your desired location on the wall, and mark the screw hole positions on the wall through the mounting holes in the camera's base.




NOTE: When positioning the base take note of where you will connect the USB power cable to the power supply, and make sure that the cable slot in the base is facing your desired direction (up, down,

STEP 4

indoor camera clockwise until it clicks into place.




Align the grooves with the mounting plate and rotate the






STEP 5


Connect the included micro USB cable connector to the



*Depending on the orientation of the camera when installing, you may need to vertically flip the view. You can do this in the Device Settings --> Basic Function Settings.



camera's micro USB port and plug into the wall adapter




Tip: Test out moving the camera in the app

VOICE ACTIVATION

To enable voice access for your Smart Camera, you will need to link the **Energizer** Connect skill with your choice of voice assistant.

Voice Activation for Alexa

Make sure your Alexa device is installed and set up first.



STEP 4 Authorize your account with the Alexa skill using the username and password from your *Energizer*_® Connect app.

Ex: "Alexa, show me the kitchen camera".

Using the name you assigned your camera, you can ask Alexa to turn on/off your camera.

Voice Activation for the Google Assistant Make sure your Google Assistant device is installed and

STEP 3

Click "Set up device".

set up first. STEP 1

Open your Google Home app. STEP 2 Click the "+" to add a new device.



STEP 5 **Energizer** Connect. X Add devices Energizer Connect



Ex: "Ok Google, show me the kitchen camera".

Authorize your account with the Google Assistant skill using the username and password from your *Energizer*. Connect app. Using the name you assigned your camera, you can ask the Google Assistant to turn on/off your camera.

LEGAL & WARRANTY

To see Warranty information and Certification Legal warnings, please see our website.

©2023 Energizer. Energizer, Energizer Bunny design and certain graphic designs are trademarks of Energizer Brands, LLC and related subsidiaries and are used under license by Jem Connected IOT, Inc. All other brand names are trademarks of their respective owners. Neither Jem Connected IOT, Inc. nor Energizer Brands, LLC is affiliated with the respective owners of their trademarks

Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries.

App store is a service mark of Apple Inc. Google, Android and Google Play are trademarks of Google LLC

FCC Compliance

This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

LEGAL & WARRANTY

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules

> These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

HAVING TROUBLE WITH SETUP

TROUBLESHOOTING

Don't return this product to the retailer, we're here to help. Please call us at 888-693-4189 or visit www.energizerconnect.com

My device won't connect to my network!

1. Make sure you are connected to your 2.4 GHz network and your device is blinking red before you start trying to connect your device.

- 2. You may need to reset your device if you are having trouble. Check out page 2 for the location of your device's reset button. 3. To allow the app to locate the network, you may need to allow permissions for location and turn on your Bluetooth.
- 4. If you are not certain what type of network you have, contact your Internet Service Provider and ask them to create a separate, dedicated 2.4GHz network. You can also do this manually in your router's settings
- 5. Try moving to a spot closer to your router for connecting.
- **6.** You can also purchase a WiFi extender to increase your WiFi range and strength
- 7. In some cases, you can try using the secondary pairing mode by clicking "Net Pairing Mode" on the Add Device screen (see bottom of page 3). Follow the on-screen instructions.

My device says it's already bound when I try to connect it! 1. When you get the ALREADY BOUND screen, click the blue link to send us an Unbind Request. We can assist you further from the in-app Help Center.

When my camera is pointed at a window at night, I can't see through the glare!

1. At night, the camera's IR LEDs will turn on automatically to provide night vision when it gets dark. IR light reflects off of glass. So if you are trying to use your Indoor Camera through a window at night, go into the Device Settings->IR Night Vision and set it to OFF.

When I try to view live view, it says "Offline" or "Cannot establish for video tutorials, updated manuals and more FAQs for your device. encryption channel"

L Unplug your camera from power and plug it back in

2. Check to make sure you have the newest firmware for your camera. Go to the device settings and scroll down to Firmware Information

3. Contact us so we can assist you

Setting up Motion Detection and Recording 1. From the live view of the camera, click Notifications, or from

- the device settings click Detection Settings. -You can schedule when you want to receive notification of motion
- 2. To save recordings, you can purchase Cloud Recording or install a microSD card (max 128GB, not included) into the camera for LOCAL recordings.
- --Recordings can be based of motion or can be All Day. --Please note: All Day recording will fill up a microSD card much auicker
- **3**. Every time a motion is detected, a screenshot is saved for your review. They can be found in the Notification Center. From the Home page, click the three lines in the top left, and then click Notifications.
- 4. If you are using a microSD card, it will continue to record until the the microSD card fills up.
- -- If you are using Motion based recording: Separate files are recorded for each detection, so when the memory fills up, it will begin to record over the oldest detections, one at a time. ---If you are using All Day recording: One files is saved as the video is continuously recording. When the memory fills up, it will clear the entire recording and start fresh.

Two Way Audio

1. By default, the camera will only use the microphone OR the speaker. When you click the microphone on the live view, you will be able to speak through the camera, and when you click the microphone again to turn it off, the speaker will automatically turn on so you can hear whats being said at

2. For some cameras, you can turn on Full Two Way Audio by going to the Device Settings -> Basic Function Settings -> Talk Mode and click on Two-Way Talk.

Why Does It Need The Internet?

1. Our devices must connect to an internet server in order to be fully operational, otherwise they will not work as desired. Why Does The App Need Location Permission To Function?

1. The latest mobile phone operating systems require location permission to access your Wi-Fi and to detect your Wi-Fi name Why Does The App Ask For Permission To Use My Microphone? 1. Since the app can be used with camera(s) and it's 2-way talk

feature, Google's current Terms of Service requests microphone

permissions when initially creating the account for device setup

What's a Mixed Network?

2.4Ghz and 5.0Ghz network band. By default, they are setup to use the same Wi-Fi name and password for both. This combined dual network with the same name and password is referred to as a "Mixed Network."

1. Most newer routers are dual band and broadcast a separate

My "Live View" Isn't Working When I Access The App!

1. If 'Live View' is not working, leave the Energizer Connect app and go to your phone's settings. Go to the Apps settings, locate the Energizer Connect App, storage, and then clear cache.