

Single Side Print



Bluetooth® SOUND BAR

TAKE THE SOUND TO THE NEXT LEVEL



MANUAL

855.999.8041 | WWW.XTREMECABLES.COM

Your Bluetooth Speaker has a built in rechargeable battery. Be sure to fully charge the battery before initial use or when the speaker has not been used for an extended period of time.

WHAT'S INSIDE

Wireless Speaker
Charging Cable
3.5mm Audio Cable
User Manual



FUNCTION KEYS

- 1- Switch button:** Long Press for Power on/off
- 2- Mode button:** Short press to change the speaker mode. USB and TF Card mode will only be selected if a USB drive and TF card are installed.
- 3- Playing/Pause / Phone Control:** Short press to play or pause the song in Bluetooth/USB/TF card modes; and to answer or hang up a phone call. Long press to reject a phone call. Double Click to redial the last call.
- 4- Volume down/Previous Track:** Press and hold to reduce volume; Short press to skip to previous song or to skip back to the start of the current track. (Function depends on the operation of Bluetooth device).
- 5- Volume Up/Next Track:** Press and hold to increase volume; Short press to skip to next song
- 6- Micro USB Charging Port**
- 7- USB Port:** Insert a USB drive with music to play music in USB Mode. When inserted, the speaker will identify USB and automatically switch to USB input mode.
- 8- TF Card Reader:** Insert a TF Card with music to play music in TF Card mode.
- 9- Aux In Audio Input Mode:** Insert the 3.5mm audio cable to play music in Aux mode from an external audio source such as a mobile phone or computer. When inserted, the speaker will identify Aux and automatically switch to Aux input mode.

2

BLUETOOTH CONNECTION

Select Bluetooth mode with the Mode button. Enable Bluetooth on the phone or device, that you want to pair. Select "PBS9-1060 Sound Bar" from the list of available Bluetooth devices to pair and connect.

The unit prompt signal tone will confirm that you have paired successfully.

CHARGING YOUR SPEAKER

Connect the charging cable to speaker's Micro USB port. Insert the other end to a 5V USB wall adapter or other 5V USB power source (not included). The red charging light is illuminated when charging and will switch off when the speaker is fully charged.

SAFETY AND CARE INSTRUCTIONS

- Do not use abrasive cleaning solvents to clean the unit.
- Disconnect the USB cable once the product is fully charged.
- Do not expose to heat sources or leave in a location that is likely to get excessively hot.
- Do not let the product get wet.
- Do not disassemble.
- Performance can be affected by the environment or when the product become discharged.
- Interruption can be caused by obstacles between the product and the Bluetooth device, by Wi-Fi or other high frequency signals, or if the product are brought out of range of the Bluetooth device.
- Charge fully before storing for a long period.

SPECIFICATIONS:

Input: 5V/1A
Output Power: 3Wx2
Max Working Range: 10M
Music Play/Talk Time: 4Hrs
Battery Type: Built-in Lithium Battery(1200mAh)
Frequency Range: 100HZ-20KHZ

3

FCC CAUTION

Any changes or modifications not expressly approved by the part responsible for compliance could void this user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does not cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RADIATION EXPOSURE STATEMENT:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.



4