



EASY PLUG & PLAY INSTRUCTIONS:

1. The USB receiver dongle can be found inside the mouse. Insert the USB dongle into your computer's USB port.
2. Insert 2 "AAA" batteries into mouse.
3. On the back of your mouse, slide the ON/OFF switch into the ON position.
4. Software drivers will automatically install. mouse should begin working immediately.

Mouse

1. Unplug the USB receiver dongle from your computer and take the batteries out of the mouse.
2. Plug the USB receiver dongle back into the computer port and then insert batteries back into the mouse.
3. Right click on the mouse while scrolling the wheel together for 5 seconds.
4. A light on the bottom of the mouse means you have successfully reconnected.

FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.