

Double Sided Print, Black and White Copy

SAFETY INSTRUCTIONS

Please read and understand all instructions before using this product. If damage is caused by failure to follow the instructions, this warranty is null and void. Keep these instructions for future reference.

- Loud sounds can cause serious and permanent hearing loss, always use caution.
- Only use the Power Adapter that was supplied with the product.
- Do not stare at LED's.
- Do not operate the unit other than as stated in this manual.
- Do not leave the device unattended while in use.
- Do not drop, puncture, or disassemble this product.
- Do not expose this product to moisture of any kind including water or any other type of liquid.
- Do not expose this product to dirt, sand, or similar matter.
- Avoid long exposure to direct sunlight, which may cause damage.
- Do not expose this product to open flames.
- Do not use the product in a strong magnetic field.
- Use clean, soft cloth to clean. Do not use any corrosive cleaners/oils to clean.
- Do not attempt to repair the device or open the unit as this will void the warranty.
- Do not charge, or use, the product if it has been submerged in water, or if water has got inside the product.
- Do not expose product to heat sources, the sun, flames, fire or leave in a hot vehicle.
- Do not expose the product to extremely high or low temperatures.
- Use this product in a location with a temperature of 32°F - 95°F.
- Do not place anywhere where the product would become crushed or punctured.
- This product is not a toy. Keep out of reach of children or those that require supervision.
- Do not use abrasive cleaning solvents to clean the unit.

5

FCC CAUTION

Any changes or modifications not expressly approved by the part responsible for compliance could void this user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does not cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RADIATION EXPOSURE STATEMENT:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ONE YEAR WARRANTY

Xtreme warrants its products for one year against defects in manufacturing under regular consumer use with original receipt of retail purchase.

We believe in our products and want to provide you with a replacement, if needed, but we have to know about the problem while the product is still under warranty. If you discover a defect covered by this warranty, please contact us about receiving a replacement. In order to use the products warranty the customer must provide proof of the retailers receipt.

*Any customers outside of the U.S. will be responsible for shipping and handling charges if a replacement is required that is not due to a manufacturing defect. If there is not a manufacturing defect, shipping and handling will be applied.

Xtreme's warranty is limited to our products only. Our warranty does not cover the replacement or repair cost of any third-party accessory, electronic device or personal property.

For instructions about how to obtain warranty service for your product, please contact Customer Service: customerservice@xtremecables.com.

Content is subject to change without prior notice. Some content may differ from how the product works with your specific device.

FCC ID: 2AHAS-XBS91076

6



BLUETOOTH® HOME THEATER SOUNDBAR



MANUAL

XBS9-1076-BLK
V.1.0 0324

855.999.8041 | WWW.XTREMECABLES.COM

INTRODUCTION:

Please read this entire manual before use, including all warnings. Keep this manual for future reference.

FEATURES:

- Bluetooth® 32" soundbar for use with your home theater system
- Mount seamlessly to your wall with the built-in bracket or place on top of a console
- Built-in controls for power, mode, play/pause, and volume
- IR remote control included (requires 2xAAA batteries, not included)
- Compatible with all Bluetooth® enabled devices

WHAT'S INCLUDED:

- Bluetooth® Soundbar Speaker
- 12V Power Adapter
- Remote Control (2xAAA Batteries Required, Not Included)
- User Manual

SPECIFICATIONS:


- DC Power Input: 5VDC/2A
- Product size: 820*58*60MM
- Speaker: (x2) 2", 4 Ohm, 5W
- Digital Inputs: 24Bit/192kHz
- Power: (x2) 5W

- Bluetooth Range: >10M
- Recommended Operating Temperature: -20 C to +60 C

PRODUCT OVERVIEW & FUNCTIONS

Top of soundbar


- 1- Mode Selection
- 2- Play/Pause
- 3- Decrease Volume
- 4- Increase Volume



2


Rear of Soundbar

- 1- On/Off Switch
- 2- DC Power Input
- 3- Aux 3.5mm Input
- 4- Digital Optical Input
- 5- Digital Coaxial Input
- 6- Power LED



Remote Control

- 1- Power On/Off
- 2- Bluetooth Mode
- 3- 3.5mm Aux Mode
- 4- Coaxial Mode
- 5- S/PDIF Optical Mode
- 6- Mute Mode
- 7- Select Previous
- 8- Increase Volume
- 9- Select Next
- 10- Decrease Volume
- 11- Play & Pause



POWER ON/OFF

- Turn the unit on via the On/Off volume switch on the back of the unit or via the remote control.

PAIRING DEVICES TO THE SPEAKER:

- Power on the Soundbar.
- Keep the distance between your device and the speaker within 3 feet (for pairing only).
- Activate the Bluetooth function on your source device.
- Select "Xtreme XBS9-1076" from the devices list and follow the on-screen prompts to finish the pairing process.
- After successfully pairing the speaker to your device, a tone will sound.
- Once paired, audio will be received and will sound from the Soundbar.
- Adjust the volume on the top of the speaker, or via the wireless remote.

3

- Note: After successfully pairing once, the devices will remember each other. To manually enter pairing mode, press and hold the Play/Pause button on the top of the Soundbar until the Soundbar prompts you to pairing mode. Follow the above instructions to complete the pairing process.

MODE OPERATIONS:

Press the dedicated mode buttons on the remote control or the "M" button on the top of the speaker to change modes. The speaker will sound out what mode is selected. Depending on certain modes that require external devices to be connected, whilst switching modes, that mode may be skipped because nothing is connected and detected.

• Bluetooth Mode

- Stream audio from your smartphone, TV or other Bluetooth enabled device to the speaker. See Pairing instructions for more information on device pairing. Use the remote control or playback control on the speaker.

• Aux 3.5mm Input Mode

- Connect a 3.5mm cable between the input of the Soundbar and the output of the source device.

- The Soundbar should automatically switch to Aux Mode, if this does not happen, manually select Aux mode via the remote control or via the M button on the top of the Soundbar.

- Lower the volume on the Soundbar and begin audio playback from your source device.

- Once an ideal playback level from your source device has been set, control the overall volume from the Increase and Decrease buttons on the top of the Soundbar or the remote control.

• S/PDIF Optical Input Mode

- Connect an optical cable between the Soundbar and the source device.

- The Soundbar should automatically switch to S/PDIF Optical Mode, if this does not happen, manually select S/PDIF Optical mode via the remote control or via the M button on the top of the Soundbar.

- Lower the volume on the Soundbar and begin playback on the source device.

- Raise the volume of the Soundbar via the Increase and Decrease buttons on the top of the Soundbar.

• Digital Coaxial Input Mode

- Connect a Coaxial cable between the Soundbar and the source device.

- The Soundbar should automatically switch to Coaxial Mode, if this does not happen, manually select Coaxial mode via the remote control or via the M button on the top of the Soundbar.

- Lower the volume on the Soundbar and begin playback on the source device.

- Raise the volume of the Soundbar via the Increase and Decrease buttons on the top of the Soundbar.

4