





# The MeatStick



**Thank you for choosing The MeatStick!**

If you need help, contact support:  
[support@themeatstick.com](mailto:support@themeatstick.com)

 [thetruemeatstick](https://www.facebook.com/thetruemeatstick)

 [themeatstickig](https://www.instagram.com/themeatstickig)

 [truemeatstick](https://twitter.com/truemeatstick)

 [#mymeatstick](https://twitter.com/mymeatstick)

## QUICK START

1. Download the app and create an account.



2. Insert batteries, click the button to turn on and charge for 4 hours before first use.



(2 AAA batteries not included)

3. Press the button on the charger to activate the stick. Select the stick and choose your cook.



4. Remove the stick from the charger and insert completely up to the ceramic handle in the meat. The notch should be in the thickest part, away from fat and bones.



5. Get real-time data on your smartphone, we will let you know when it's ready. Remember, the stick will be sizzling hot after each cook, be careful when removing it.



6. After enjoying your meat, allow the stick to cool down and clean to look like new.



## ⚠ CAUTION ⚠



Charge the stick with the included battery-powered charger. Do not use the similar USB-powered version of the charger with the included probe.



If not being thrown into a heat source, the stick will turn off after 30 minutes of inactivity.



Position the probe completely into the meat. This allows the probe to withstand the high temperatures.



The internal and ambient sensors can measure and withstand up to 212°F/100°C and 572°F/300°C respectively. Temperatures above this may damage the stick.



Cooks over direct heat may cause fire flare-ups that can instantly exceed 900°F/500°C. Please be aware and remove the stick to avoid damaging.



We recommend the stick to be used with the Xtender or WiFi Bridge for better connectivity.



Do not use the stick in a microwave or pressure cooker.



The stick will be sizzling hot after each use. Do not touch with your bare hands.



The stick is fully waterproof, sous-vide, and dishwasher safe.



In an open grill you can be up to 33ft/10m away from your stick. The range will be reduced to 6ft/2m or less in enclosed cooking setups (i.e. oven).



All The MeatStick products are covered by a 1-year limited warranty. For more details: [themeatstick.com/warranty](http://themeatstick.com/warranty).



The MeatStick is modular, you create the set you want. Visit our website to add more probes or add-ons to your collection!



Protect our planet by recycling packaging and electronic devices at the designated facilities.

## STICK & CHARGER



Ambient temperature sensor (max: 572°F/300°C)

Ceramic handle

Notch for internal temperature sensor (max: 212°F/100°C)

Power indicator

Power button

Charger touchpoints



Stick lasts 24+ hours per charge.

## **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.