



BY-AU-BE-173  
FCC ID:2AHN6-AUBE173



# TRUE WIRELESS EARBUDS

## SPECIFICATIONS

- BT Version: 5.3
- Playtime: Up to 3 Hours per charge (dependent on volume level)
- Charging Interface: Type C USB
- Transmission Range: Up to 33 feet

## PACKAGE CONTENTS

- Charging case
- 2 True Wireless Earbuds
- Type C USB charging cable
- Instruction Manual

## PAIRING

- Once fully charged open the cover of the charge case and remove the earbuds. The indicator lights on both earbuds will flash. Wait until one of them stops flashing.
- Once only one earbud's indicator light is flashing you may now search for **BY-BE-173** on your device's Bluetooth® list and pair it.
- You can now listen to music or make/receive a call.
- Once you have successfully paired your earbuds to your device the first time as described above you only need to remove them from the charge case and they should connect automatically to your phone if your Bluetooth® is turned on.
- If you encounter any issues you can always unpair them from your device and begin this process again.

## MULTIFUNCTION BUTTON

- **SHORT PRESS 1 TIME:** Play/Pause/Answer call /End call
- **SHORT PRESS 2 TIMES:** Vol+ /Vol-
- **SHORT PRESS 3 TIMES:** Enable Siri/Google
- **LONG PRESS 1-2 seconds:** Prev/Next/Reject Call
- **LONG PRESS 3-5 seconds:** Power On/Off

MULTIFUNCTION  
BUTTON



## USAGE

### Phone call:

- When connected to a device capable of making and receiving phone calls you can short press either earbud button to answer an incoming call.

### Listening to music:

- When the earbuds are turned on and connected to the phone or Bluetooth® enabled device you can open the player and listen to music.
- In the process of listening to music, press the button once to pause the current music, and again to play paused music.

### Using Siri or Google Assistant:

On either earbud, short press the multifunction button three times, in quick succession, to activate your AI assistant. The AI assistant on your device must be activated prior to this operation.

## Power off:

Long press the function button to turn the earbuds off. Each one needs to be powered off individually. Or you can just place the earbuds into the charge case and they will automatically power off.

## CHARGING

- Replace the earbuds in the case.
- Connect the Type C USB charging cable to the charging port on the back of the case.
- Plug the cable into a standard USB 5V/1A or higher power output.
- The indicator lights on the front of the case will begin to flash. The indicator lights will show the charge level of the case while connected.
- When fully charged all LEDs will light on solid. Unplug the charging cable from the power source.
- If you want to charge the earbuds from the charge case internal battery, simply place them back in the charge case.

## PLEASE NOTE

- Do not abuse this product, and do not squeeze it between heavy objects.
- Keep this product far away from high temperature and humidity.
- Keep this product away from high frequency transmitter equipment, this will affect the local signal reception, resulting in sound breakup and distortion or disconnection.

If for any reason you move out of the range of the device you are listening to while using this product, the earbuds will disconnect. When you are back in range you may need to perform the pairing procedure again as this

depends on battery life. If the earbuds are powered on and are disconnected from a Bluetooth® device for more than 3 minutes they will power off.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**CAUTION: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.**

## WARRANTY- 12 MONTH

Please visit our website [Bytechintl.com/warranty](http://Bytechintl.com/warranty)

©2024 BYTECH NY INC.

BYTECH™ is a registered trademark of Bytech NY INC. Bluetooth® is a registered trademark of SIG.Inc

\*All Trademarks and copyrights are the property of the respective companies.  
\*Photos are for illustration purposes only.

**BYTECH**

CONTACT INFO:  
2585 WEST 13TH STREET,  
BROOKLYN, NY 11223  
[BYTECHINTL.COM](http://BYTECHINTL.COM)

© 2023 BYTECH NY INC.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The device has been evaluated to meet general RF exposure requirements, the device can be used in portable exposure condition without restriction