

A8 Subwoofer Mini speaker Bluetooth Speaker



Manufacture: Shenzhen Duntuo Electronics Co., Ltd

Dear customer:




Thank you for purchasing A8 Mini Wireless Speaker. Please read this user guide carefully before operation and save these instructions for future reference.

Packaging included:

- 1. A8 Mini Speaker ----- 1pcs
- 2. USB Cable ----- 1pcs
- 3. User Guide ----- 1pcs

Feature:

- Small, stylish, compact, and extremely portable; fits easily into your bag or pocket so you can use it on the go.
- Rechargeable 600mAh Li-battery lasts up to 4.5 hours of Talking Time / 2.5 hours of Music Playing Time and 20 hours of Standby Time per charge cycle.



Function Keys:

- 1. TF Card Slot
- 2. USB charging port
- 3. Mode key
- 4. Vol-/Previous Song
- 5. Vol+/Next Song
- 6. ON/OFF
- 7. MIC

Specifications:

- Output Power: 4W
- Battery: 600mAh/3.7V
- Charging Current: 300mA
- power input: DC 5V/500mA
- Unit size: Ø 40
- Product Size: Ø69 x 50mm
- Product Weight: 156g
- Music Play Time: Up to 2.5 hrs
- Calling Time: Up to 4.5 hrs
- Bluetooth distance: 10m

1. ON/OFF

- Long press ON/OFF for 2 seconds to power on.
- Long press ON/OFF for 2 seconds in any mode except call incoming, the speaker will power off. Long press "ON/OFF" 6~13 seconds to force shutdown.
- The speaker will power off automatically when the music pause or standby after 20 mins.

2. Bluetooth Connection

When pairing, the blue light will blink quickly; use cell phone or computer or other device search device name "A8", click to connect, when connection successful/playing music/music pause, blue light on.

3. When you play music

- Short press to play the previous song
- Long press to reduce speaker volume;
- Short press into the mode switch
- Short press to play the next song
- Long press to increase speaker volum
- Click, the music will pause, A second short press playing music again. Long press 2 seconds, enter the shutdown state, again long press 2 seconds power on

4. Hands free phone call operation

1. When a phone call is incoming, click the "☎" button to answer the phone, long press "☎" button to reject the phone;
2. When on an active call, short press the "☎" button to end the call;
3. When the Speaker is in standby / music mode, double-click the "☎" key to re-dial the last call.


5. Mode Switch(Bluetooth mode-TFcard mode)



When Speaker is on with TF Card inserted click " M " key to switch through different mode one by one in this order: TF Card--Bluetooth (only support within 32GB)

6. Charging

Connect the Micro 5P charging cable to speaker's Micro USB port, insert the other end to the USB port of a 5V charger. A red light is illuminated when charging, and will switch off when full charge is reached...(Please ensure the speaker is full of charge when first time use).



FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.