

USB Wireless Adapter Quick Installation Guide



802.11AC Dual-Band Wi-Fi USB Adapter
Model: EP-AC1619

Shenzhen EDUP Electronics Technology Co.,Ltd.
Note: This Manual based on Windows7



01. Put in the CD and find windows file "windows (xp,vista,win7,win8,win10)" and Setup.exe.



02. Double click Setup.exe file, Software begin to initialization, then click the "Next". There shows the installation progress.




03. Do not interrupt installation, Click "finish" to finish the driver installation. The computer automatically restart.





04. Plug the Wireless USB Adapter into the USB port of your PC
Wireless connection (two ways to realize Wireless connection 1):

05. Click icon in the Windows system tray, which locates in the bottom-right corner of your computer screen

or double click , and pops up a message and click "Available Network". Double-click the utility icon or right click the icon, and the Wireless Network Connection window appears then double click the SSID you preferred.




Type the encryption key that you wrote down earlier in both the Network key and Confirm network key boxes, and then click "ok".



Note: if there is no icon , please find it in the on right bottom, it has been hidden as following

06. Click icon which locates in the bottom-right corner of your computer screen, click the wireless network list and choose the SSID you preferred. and double click (Or click "Connect").

07. Type the encryption key and then click "ok".



Compliance Information
FCC/ISED Compliance Notice
This device complies with Part 15 of the FCC Rules and ISED licence-exempt RSS standard.
Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Cet appareil est conforme à la partie 15 des règles de la FCC et à la norme RSS exonérée de licence ISED.

L'opération est soumise aux deux conditions suivantes: (1) cet appareil ne peut pas causer d'interférences nuisibles, et (2) cet appareil doit accepter toute interférence reçue, y compris les interférences qui peuvent causer un fonctionnement indésirable.

Toute modification ou modification non expressément approuvée par la partie responsable de la conformité pourrait annuler l'autorisation de l'utilisateur d'utiliser l'équipement.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits

are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information

SAR tests are conducted using standard operating positions accepted by the FCC/ISED with the adapter transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the adapter while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output.

Before a new model adapter is available for sale to the public, it must be tested and certified to the FCC/ISED that it does not exceed the exposure limit established by the FCC/ISED. Tests for each adapter are performed in positions and locations as required by the FCC/ISED.

For body worn operation, this adapter has been tested and meets the FCC/ISED RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 5 mm from the body.

Les tests SAR sont effectués à l'aide de positions de fonctionnement standard acceptées par la FCC / ISED, l'appareil transmettant à son niveau de puissance certifié le plus élevé dans toutes les bandes de fréquences testées, bien que le SAR soit déterminé au niveau de puissance certifié le plus élevé, le niveau de fonctionnement peut être bien inférieur à la valeur maximale. En général, plus vous êtes proche d'une antenne de station de base sans fil, plus la puissance délivrée est faible.

Avant qu'un nouveau dispositif ne soit disponible à la vente au public, il doit être testé et certifié par la FCC / ISED qu'il ne dépasse pas la limite d'exposition fixée par la FCC / ISED. Des tests sont effectués pour chaque dispositif dans des requis par la FCC / ISED.

Pour un usage sur le corps, cet appareil a été testé et respecte les directives d'exposition RF de la FCC / ISED lorsqu'il est utilisé avec un accessoire conçu pour ce produit ou avec un accessoire ne contenant pas de métal et positionnant le combiné à 5 mm minimum du corps.