

# USB Wireless Adapter Quick Installation Guide

Note: This Manual based on Windows7

01. Put in the CD and find windows file "windows (xp,vista,win7,win8,win10)" and Setup.exe.

1

2

3

02. Double click Setup.exe file, Software begin to initialization,then click the "Next".There shows the installation progress.

REALTEK Wireless LAN Software - InstallShield Wizard

Preparing Setup  
Please wait while the InstallShield Wizard prepares the setup.  
REALTEK Wireless LAN Software Setup is preparing the InstallShield Wizard, which will guide you through the rest of the setup process. Please wait.

03. Do not interrupt installation, Click "finish" to finish the driver installation.The computer automatically restart.

REALTEK USB Wireless LAN Driver and Utility

Setup Status

REALTEK USB Wireless LAN Driver and Utility is configuring your new software installation.

Now installing REALTEK USB Wireless LAN Driver

04.Plug the Wireless USB Adapter into the USB port of your PC

Wireless connection (two ways to realize Wireless connection 1 :

REALTEK USB Wireless LAN Driver and Utility

InstallShield Wizard Complete

Yes, I want to restart my computer now.

No, I will restart my computer later.

Remove any disks from their drives, and then click Finish to complete setup.

05.Click Icon in the Windows system tray, which locates in the bottom-right corner of your computer screen or double click , and pops up a message and click"Available Network" Double-click the utility icon or right click the icon ,and the Wireless Network Connection window appears then double click the SSID you preferred.

REALTEK USB Wireless LAN Utility

Available Networks

SSID	Channel	Encryption	Network Authentication	Signal	Type
EDUPWIFI	1	WPA2-PSK	WPA2-PSK	100%	Infrastructure
EDUP-2.4G	1	WPA2-PSK	WPA2-PSK	100%	Infrastructure
WISSETIGER2G	1	WPA2-PSK	WPA2-PSK	100%	Infrastructure
RT2602	1	WPA2-PSK	WPA2-PSK	100%	Infrastructure
EDUP-5.8G	1	WPA2-PSK	WPA2-PSK	100%	Infrastructure

06. Click Icon which locates in the bottom-right corner of your computer screen,click the wireless network list and choose the SSID you preferred. and double click (Or click "Connect").

Type the encryption key that you wrote down earlier in both the Network key and Confirm network key boxes, and then click "ok".

REALTEK USB Wireless LAN Utility

Available Networks

EDUPWIFI

EDUP-2.4G

WISSETIGER2G

RT2602

EDUP-5.8G

EDUPWIFI

REALTEK USB Wireless LAN Utility

Available Networks

EDUPWIFI

EDUP-2.4G

WISSETIGER2G

RT2602

EDUP-5.8G

EDUPWIFI

Note:if there is no icon , please find it in the on right bottom,it have been hide as following

Connect to a Network

Type the network security key

Security key: \*\*\*\*\*

Hide characters

OK

Cancel

Not connected

Connections are available

Wireless Network Connection 2

EDUPWIFI

EDUP-2.4G

WISSETIGER2G

WISSETIGER24G

RT2602

EDUP-5.8G

EDUPWIFI

Open Network and Sharing Center

Type the encryption key and then click "ok".

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

SAR tests are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output.

Before a new model device is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, Tests for each device are performed in positions ( worn on the body)as required by the FCC. For body worn operation, this model device has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the device a minimum of 5 mm from the body. Noncompliance with the above restrictions may result in violation of RF exposure guidelines.