MONSTER®


SOUNDBAR WITH LED LIGHTS

2MNSK0866B0BL



IN THE BOX






SPECIFICATION

- Size: 940 x 101 x 79 mm
- · BT working distance: 10m
- .S/N:≥65db
- BT IC: 5.0
- Output power: 15W*2
- · Distortion : < 0.5%
- · Power DC : DC 15V 2A
- · Frequency Response: 120Hz~16KHz
- Driver Size: 52mmx58mmX2


LOCATION OF CONTROLS

TOP PANEL




- 1.[] Button: short press to decrease volume / long press to previous track
- 2.[+] Button: short press increase volume / long press skip to next track
- 3.[*] Button: Short press for Bluetooth mode / long press for repairing
- 4.[*] Button: Short press switch light effect / long press for ON/OFF
- 5.[M] Button: Short press switch AUX/OPT / long press for Power ON/OFF

BACK PANEL



- 6. Input DC/15V
- 7. Reset settings
- 8. Input AUX
- 9. Input OPTICAL


LOCATION OF CONTROLS



- 1.[M] Button: Standby Power ON/OFF
- 2.[\$] Button: Bluetooth pairing
- 3.f ∢×1 Button: Mute volume
- 4.[+] Button: Increase volume
- 5.[►II] Button: Play/pause track
- 6.[н ∢] Button: Skip to previous track
- 7.[►►] Button: Skip to next track
- 8. FOPT 1 Button: OPTICAL
- 9.f 1 Button: Decrease volume
- 10.[BT] Button: Bluetooth mode
- 11. FAUX 1 Button: AUX INPUT
- 12.[🔆]Button :Decrease Light intensity
- 13.[::]Button: Increase Light intensity
- 14.[*]Button: Light ON/OFF

MOUNTING THE SPEAKER

- 1. Measure a width of 23.6 inches on the wall.
- 2. Mark the position of the mounting screws on the wall using a pencil.
- 3. Drill the supplied screws directly into the marks that you have made on the wall and leave approximately 0.3 inch length to hook the Wireless Sound Bar.
- 4. Put the Wireless Sound Bar onto the mounting screws. Make sure they are firm and



OPERATION PROCESS

- 1. Connect the DC power cord into a wall socket.
- 2. Turn the speaker on by pressing the [M] button on the speaker or remote control.

3.1 BLUETOOTH MODE OPERATION

- 3.1.1 Press the [*] button on the speaker or the remote control. When indicator lights flash blue and a "drip" sound is heard, then go into bluetooth pairing mode.
- 3.1.2 During the pairing process, keep the speaker and bluetooth device within 10 meters of each other.
- 3.1.3 Set your phone or other bluetooth device to bluetooth status.

BLUETOOTH CONNECTION METHOD:

- 1. Go to SETTINGS > BLUETOOTH (make sure bluetooth is turned ON)
- 2. When your bluetooth enabled device finds the speaker, select "Monster Soundbar" from the list of found devices. When succeeding pairing, you will hear "beep beep". indicator light appears normally on. When play the music, the blue led indicator light appears normally on

3.2 BT MODE OPERATION

- 3.2.1 Make sure the product is Bluetooth connected to the media player
- 3.2.2 Press the (BT) button on the speaker or the remote control. When
- [BT] bluetooth indicator lights up blue light, then enter the bluetooth fibermode

Monster Soundbar

OPERATION PROCESS

3.3 OPTICAL MODE OPERATION

3.3.1 Please insert one connection port of OPTICAL fiber into the [OPTICAL] fiber input jack and then insert another connection port

into the socket of media playback device.

3.3.2 Press the (OPT) button on the speaker or the remote control. When [OPT] optical fiber indicator lights up red light, then enter the OPTICAL fibermode state.

3.4 AUX MODE OPERATION

3.4.1 Insert one of the connection ports of the audio cable into the [AUX] jack, and then insert another connection port into the socket of the media playback device.

3.4.2 Press the (AUX) button on the speaker or the remote control. When [AUX] indicator lights up Green light, enter LINE IN state.

3.5 VOLUME CONTROL OPERATION

3.5.1 Short press the [-] button on the speaker or the [-] button on the remote control to reduce the volume and Long press to previous track.
3.4.2 Short press the [+] button on the speaker or the [+] button on the remote control to increase the volume and long press skip to next track.

CAUTIONS AND WARNINGS:

- Do not use the bluetooth speaker near water or humid; do not use the device ne the bathtub, water tank, swimming pool and so on.
- 2. Do not install the bluetooth speaker in the hot or cold environment
- 3. Do not expose the device in the sunshine directly
- 4. Do not use the device near fire, such as, stove, candle or fireplace and so on.
- 5. Do not use abrasive cleaning solvents to clean the bluetooth speaker

FCC Requirement

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

5