


# ***PT-MAX***



Please read the instructions carefully before using the speaker


Please Keep this manual for future access problems

**Open the box**

Please make sure the following accessories are safe

- a. a bluetooth speaker
- b. a user manual
- c. a 3.5mm audio cable
- d. Micro USB
- e. a leather handle
- f. four screws

(a)



bluetooth speaker

(b)




user manual

(c)



external audio cable

(d)



Micro USB

(e)



a leather handle

(f)



four screws

**Technical parameters**

**Features:**

Audio input : bluetooth/Aux-in

USB output port

Built-in rechargeable Li-ion : 2200mAh\*2

Leather strap

Playing music time: 6 hours

With built-in passive bass

**Specifications:**

Power Output: RMS 5W\*2

Speaker full range unit: 2"X2 4Ω

S/N(1W/1m): 82dB ± 3dB SPL








THD≤0.5%

Separation: ≥45dB

Frequency response: 120Hz-20KHz

SIZE:200\*120\*42mm

## OPERATION


- I Button operation;
-  long press for power on or off
  -  short press for next song
  -  short press to volume up
  -  short press to volume down
  -  short press for last song
  -  short press for play/pause
  -  mode shift button AUX-Bluetooth

## II LED DESCRIPTION

1. The Indicator LED is Green in AUX mode
2. The Indicator LED is Blue in Bluetooth mode
  - a. During Bluetooth pairing, the LED indicator will flash rapidly; once paired, the LED indicator will begin flashing at a slower rate.
  - b. During Play mode, the LED indicator will be in constant Blue.
  - c. During Pause mode, the LED indicator will be flashing at a slow rate.

Mode	Status	LED Indicator
Aux	play,pause	Green
Bluetooth	waiting for pairing	Blue(Fast flashing)
	play	Blue
	pause	Blue(Short flashing)

## Product Operation Introduction



## AVOIDING WATER

The product should not be subjected to water or water splashing, should not be placed in some objects such as vases filled with liquid. Keep the product away from vases, buckets, wash bowls. If the liquid poured into the product,

## HIGH TEMPERATURE OR HUMIDITY

Do not use the product which be placed in high temperature environment (such as an ignition source, oven or similar environment)  
Do not use the product which be placed in very humid or steam filled environment  
When you move the product from a cold environment to a hot environment, if the product interior already with moisture, will not work. At this time, turn on the power to wait for about an hour, it can work normally after all moisture evaporation.

## **FCC WARNING STATEMENT**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.