

Js-x3说明书, 80P模造纸

JS-X3

Bluetooth Speaker

Quick Start Guide

TECHNICAL DETAILS

Power output	3W *1
Charging input	DC 5.0V/1A
Resistance	4 Ω
Frequency Response	90HZ-20KHZ
Bluetooth	CSR 4.0
Bluetooth Range	20m
Drivers	CSR 8615
Batteries	Built-in Lithium ion 500mAh/3.7V
Battery average life	4-6H
Item model number	JS-X3
Item weight	124g
Dimension	87.5*79*72.6mm

OPERATION

① Power On/Off

② Play/Pause

③ Volume Up

④ Volume Down

⑤ AUX In

⑥ Passive Radiator

⑦ DC In

⑧ Silicone Plug

⑨ Micro Phone

⑩ Hange Hook

⑪ LED Light

⑫ Loud Speaker

BUTTONS FUNCTION

Power On / Off.....

Play / Pause.....

Answer / End Call.....

Volume Up / Down.....

Skip Up / Down.....

Re-Call .....

Disconnect Device.....

Hold ⏻ for 3 seconds

Press ⏻

Press ⏻

Long press + or -

Press + or -

Press 2 times

Press ⏻ for 3 seconds

ITEMS ARE INCLUDED

CHARGING

Connect the included USB cable to the AC Adapter to charge your speaker's internal battery. A full charge takes approximately 2 hours.

AUX IN

You can also use the included 3.5mm Auxiliary cable to connect audio devices through the AUX in port on your speaker.

LED LIGHT

When charging, an orange LED light will illuminate. The orange light will turn off when your unit is fully charged.

CARABINER

You can use the included carabiner to attached the speaker to your Back pack or bicycle etc, to enjoy the music when your are outdoor.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.