Bluetooth speaker specification

CHARGE

Extrapolation for native 5V charging when the charging LED lights stay lit. Charging time: 5-6 hours

Attention: ensure that the battery is charged once a month if it is stored away

ON/OFF

Switch to " ON " position to turn on, dial to " OFF " position to turn off the machine.

The Key Operation

1, "M" Short press: Bluetooth/Self- timer/USB/TF/RADIO/AUX switch.

Long press: for the volume reduction.

Short press: for a station in radio mode, MP3 mode to the previous song. In the self timer mode, short press" M/V- "button for the self- timer function (only available for Apple Mobile Phones)

Long press: the volume increase.

Short press: Radio Mode for a console, MP3 mode for the next song. In the self-timer mode, short press" M/V+"button for the self-timer function (only for Android)

MP3/ Radio / Bluetooth short press PLAY / pause status. Long press for autoscan radio ;

Call, short press" Key for "Bluetooth speaker phone / answer " to switch between.

The Self-timer function

Press " M " key from the Bluetooth mode switch to the self-timer mode; Open the Bluetooth mobile phone, search for " shutter ", and click Connect; Open your phone's camera interface, then press" M/V- " or " M/V+"button to take pictures.

This device complies with part 15 of the FCC Rules. Operation is subject to the

following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.