

MINILOCATOR PRODUCT MANUAL

Apple, Apple Find My, Apple Watch, iPad, iPadOS, iPod touch, Mac, macOS and watchOS are trademarks ofApple Inc., registered in the U.S. and other countries, IOS is a trademark or registered trademark of Cisco in theU.S. and other countries and is used under license.

01.Turn on the device



 Press the button once, the device will rings and turn on.

02.Bind the device

- . Open the Find My app.
- Hold the device close to your iPhone, tap the items tab, tap + and then Add Other Item
- . Find the "OPD03", then tap connect,
- Type a name for your device, select a emoji.
- Tap Agree to acknowledge that this item will be linked to your Apple ID.
- Tap Finish. The device will rings when bind successful.

03.Enable Lost Mode

- Open the Find My app, tap the Items tab, then tap your item.
- Under Lost Mode, tap Enable.

- Read the instructions, tap Continue and enter a phone number or email address.
- Confirm the information, customize the lost message, and tap Activate to complete the setup.

04.Remove the device

- Open the Find My app, tap the Items tab, then tap your item.
- Tap remove Item and then tap Remove to complete the operation.
- The device will rings after removed.
- Note: After removing the device in the app, the device will beep. It will not power off and still in the pairing mode. If there is no re-pairing within 10 minutes, the device will leave the pairing mode and app cannot be paired at this time. If you need to pair the device, please click the device button twice, the device will ring. At this time, the device enters the pairing state and can be re-paired with the app.

05.Product Main Functions

- Play Sound
 - Click Play Sound in the Find My app, the device will rings and help you to find your item easily.
- · Locate your item

If your missing item is not nearby, the Find My app can still help you track it down using the Find My network – hundreds of millions of iPhone, iPad, and Mac devices around the world. Nearby devices securely send the location of your missing device to i Cloud, then you can see where it is in the Find My app. It is all anonymous and encrypted everyone's privacy.

06.Instructions for device button

- Power on
- Press the button once, the device will rings and turn on.
- · Power off

Press and hold the button for 3 seconds, release the button after hearing the rings.

Factory Reset

 Press the button five times, holding the last time for 3 seconds. Then release the button after you hear the bell. (Please press the button within 5 seconds).

07.FQA

When can the device be located?

- When an item is separated from its owner for a period of time, it can be found by other Apple devices that are part of the Find My network, and the owner can start to get the location of the device.
 How to confirm whether the device has been
- turned on?
- Click Play Sound in the Find My app, if the device rings that means it is turned on and work normal. How is my privacy protected?
- Only you can see where your item is. Your location data and history are never stored on the item itself.
 Devices that relay the location of your item also stay anonymous, and that location data is encrypted every step of the way. So not even Apple knows the location of your item or the identify of the device that helps find it.

08.How to replace the battery?





Open the cover

Install the new battery and close the cover

09.What is the Find My network? And how does it work?

The app Find My network provides an easy, secure way to locate compatible personal items on a map using the Find My app on your iPhone, iPad, iPod touch, Mac, or the Find Items app on Apple Watch. Simply pair your compatible product with the Apple Find My app to view it right alongside your Apple devices. If your item ever goes missing, you can put it in Lost Mode to display a message and your contact information to anyone who might find it. The Find My network is encrypted and anonymous, so no one else, not even Apple, can view its location.

10.FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device. pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television. reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- •Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

your authority to operate this equipment.
This device complies with part 15 of the FCC Rules.
Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

11.RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.