
HAVIT



TW931 TRUE WIRELESS STEREO EARBUDS

USER MANUAL

Product and accessories



Earbud *2



Charging Case *1



Type-C Charging Cable *1



User Manual *1



Description of product structure

- 1 Farbud Indicator
- 2 MEB (Multi-function button)
- LED Indicator
 Charging Port





Wearing method

Gently insert the earbuds into the ear then adjust the appropriate comfort.



Basic function

Power on, Bluetooth connection

- -Follow the steps (Please confirm that your phone is built-in Bluetooth function)
- 1. Power on

Method 1: Take out the earbuds from the charging case, the earbuds will turn on automatically.

- Method 2: Long press the MFB for 3s. The earbuds enter the pairing mode automatically while the indicator of one earbud flashes slowly.
- 2. Turn on Bluetooth on your device and select "HAVIT TW931" referring to your phone instructions. Pairing mode can just last 3 minutes. If you miss the pairing time, you need to restart the device and operate follow the procedural steps mentioned above.

lote:

 a). HAVIT TW931 remembers previously connected devices. When turned on, the earbuds attempts to reconnect to previously connected devices. b). HAVIT TW931 will disconnect when deviate the working range of Bluetooth. The earbuds will reconnect automatically if you come back to the range in 3 minutes.

Power off

Method 1: Put the earbuds into the charging case, they will automatically shut off.

Method 2: Long press the MFB for 5s.

Answer incoming calls

Double press the left or right MFB.

End the call

Double press the left or right MFB.

Decline incoming call Long press the left or right MFB for 1s.

One key for voice assistant

Triple tap the left or right MFB.

Triple tap the left or right MFB.

Music playing

Play/Pause: Double press the left or right MFB.

2. Previous song: Long press the left MFB for 1s.

Next song: Long press the right MFB for 1s.
 Note: If only one earbud works, long press the left or right MFB for 1s to switch the next song.

Charging

-Case

Charge the case using the Type-C cable connected to a computer or wall charger. When the case is charging, the LED indicator flashes, and turns steady after fully charged.

Mono mode (Take out any earbuds as a unilateral Bluetooth earbud.)

(Note: Single channel mode only needs to remove one of earbuds from the charging case, if two earbuds are removed before connection, the earbud will be used in TWS mode by default, and the TWS connection will be automatically realized.)

- Take out one earbud from charge case, the earbuds automatically turn on and reconnect to previous connected devices.
- 2. Switch from one earbud to the other earbud

.

back side 反面

front side

正面

when playing music, taking out the other earbud from the charging case and these two earbuds will connected automatically.Both earbuds will play music automatically and then put the earbud which do not need anymore into the charging case and the switching process completes.

(Note:Call mode is applicable.)

3.Please refer to the TWS mode for more functions

Restore factory settings

If the earbuds can't pair frequently, please restore the factory settings. Turn on the earbuds, press the left and right MFB four times at the same time while the earbuds indicator flashes white for 3 times, the earbuds will enter the pairing mode again, search the "HAVIT TW931" Bluetooth pairing name with the mobile phone and connect again.

Specifications

Bluetooth Version: V5.4
Wireless Working Range: 10M(without

obstacles) Earbuds Battery: 30mAh

Charging Case Battery: 300mAh
Play Time: about 6h (60% vol.)
Talk Time: about 4h
Case Charging Time: about 1.5h
Speaker Size: Ф10mm*2
Input Voltage/Current: DC 5V/1A
USB Port: Tvoe-C

Warnings

- Please follow the instruction to operate.
- 2. Please charge the earbuds with input power below 5V/1A, in order to protect the battery.
- 3. Please store or use the earbuds in a normal temperature environment.
- 4. Please do not use this product near the water. Do not immerse this product in any liquid or splash any liquid on this product.5. Please keep the earbuds from heat source,
- such as radiators, hot air regulators, stoves, or other heat generating instruments. As it is not anti high temperature.
- 6. Don't jam the ports of the earbuds, such as charger port, LED port and microphone etc..

- 7. In order to protect your hearing and extend the speaker service life, it is not recommended to adjust the volume to the maximum level for a long time.
- 8. Whatever reasons damage the earbuds, please feel free to contact our after-sales staff in time rather than repair by yourself. Otherwise, you will accept without after-sales service.

FCC ID: 2AI6I-TW931

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to

comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions. may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced

radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



10

材质: 128g双铜纸 双面印刷, 风琴折

印刷色号(Printing color number): C:0 M:0 Y:0 K:70

尺寸(Size): 55 X 77 mm