



*American by Design™*

**BLOW OUT THE LIGHTS™**  
**INSTRUCTION MANUAL**  
**MANUAL DE INSTRUCCIONES**  
**MANUEL DE L'UTILISATEUR**

**MODEL: 859537, 867296, 867963,  
867964, 867965**

## INSTRUCTION MANUAL



### **WARNING**

This product shall be connected directly to a GFCI outlet. The main plug of this product is used as the disconnect device and shall remain readily accessible and operable.

### **SAFETY RELATED GRAPHICAL SYMBOLS**



### **WARNING**

Intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.



### **ELECTRIC SHOCK HAZARD**

Intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

**THIS IS NOT A TOY!**

### **IMPORTANT SAFETY INSTRUCTIONS**

When using electrical products, basic precautions should always be followed and include the following:

#### **READ AND FOLLOW ALL SAFETY INSTRUCTIONS.**

1. Indoor use only, not suitable for outdoor use.
2. This seasonal use product is not intended for permanent installation or use.
3. Do not mount or place near gas or electric heaters, candles or other similar sources of heat. Keep it away from water.
4. Unplug the product when leaving the house, or when retiring for the night, or if left unattended.
5. This is an electric product - not a toy! To avoid risk of fire, burns, personal injury and electric shock the base unit should not be played with or placed where small children can reach it.
6. Do not use this product for other than its intended use.
7. Do not cover the product with cloth, paper or any material when in use.
8. Read and follow all instructions that are on the product or provided with the product.
9. When the product is placed on a live tree, the tree should be well maintained and fresh. Do not place on live tree in which the needles are brown or break easily. Keep the tree holder filled with water.
10. Place product on a well secured tree or a stable flat surface up to ten feet away.
11. When not in use, store neatly in a cool, dry location protected from sunlight.
12. This product has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not use with an extension cord unless plug can be fully inserted. Do not alter or replace the plug.


### **CONCEPT**

Your BLOW OUT THE LIGHTS will allow you to control your holiday lighting. Plug the unit into a GFCI equipped outlet, connect it with holiday lighting, and blow into the sensor located on the candle to trigger the light strings ON/OFF.

## INSTALLATION

Note: If you have not yet assembled your lighting, it may be useful to check your light strings before assembly to identify missing/faulty bulbs.

1. Plug the unit adaptor into a GFCI equipped outlet and your holiday lighting into the outlet provided on the unit.
2. Take battery cover under the ornament off by unscrewing silver screw with small screwdriver. Open the battery compartment, Insert 3 AA batteries into the battery compartment. Replace battery compartment, cover replace screw and tighten to close.
3. Turn to on position to activate the blow out mechanism.
4. Blow into the sensor located on the candle once. The candle light and holiday lighting will turn on. Blow into the sensor again to turn off the lights.
5. The best interactive distance between the sensor and your mouth is within 2 inches (5.0cm). The best interactive distance in the absence of barrier between the sensor to your holiday lighting is within 10 feet.



### Federal Communications Commission Code, Part 15:

**WARNING: Changes or modifications to this unit or expressly approved by the party responsible for compliance could void user authority to operate the item.**

**NOTE:** This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause

undesired operation. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

## RATINGS

- Model: 859537, 867296, 867963, 867964, 867965
- Input Rating: AC 120V~60Hz 3.5A
- Loading Rating: AC 120V~60Hz 3.5A 420W MAX RESISTIVE AND INDUCTIVE
- Wireless Operating Frequency: 315 MHz.
- Rated Impulse Voltage: 1500V
- Pollution Degree: 2
- Automatic Action: 20000 cycles
- Disconnection means: Unplug the unit from the GFCI equipped outlet to disconnect with the power, or blow into the sensor to turn off the lights.
- **The maximum capacity is: 420 watts.**
- **WARNING: DO NOT CONNECT LIGHTS STRINGS OR SETS IN EXCESS OF THE ABOVE CAPACITY.**



*American by Design™*

To register for the  
Lenox Breakage Replacement Program visit

**LENOX.COM**

©Lenox Corporation

1414 Radcliffe Street Bristol, PA 19007



Call Us: 1-800-223-4311