


USER INSTRUCTIONS FOR REMOTE



CONTROLLER

① ON/OFF

*The button is used to turn on or turn off the rope lights.

② STEADY ON

*When press this button, the rope light will just go to steady bright light.

③ DIMMER +/-

*The 2 buttons is used to increase or decrease the brightnees of rope lights.

④ FADING

*When press this button, the rope light will automaticly fade in and out.

⑤⑥⑦ TIMMER

*When press one of the 3 buttons, the rope light will flash three times and then it will be programmed with timer function.

*Timer function with 3 settings: Timers 2, 4, and 8.

--- Timer 2 will set the timer on for 2 hours and off for 22 hours.

--- Timer 4 will set the timer on for 4 hours on and off for 20 hours.

--- Timer 8 will set the timer on for 8 hours and off for 16 hours.

MEMORY FUNCTION

*This product has memory function, when turn on it will resume with the last function used.

NOTE: The RF-1 Remote Control and BC-9 Receiver can operate with the same LED Rope Lights sold.

ITM. / ART. 707988

MODEL:BT2EE

5.4M / 18 FT REMOTE CONTROL LED ROPE LIGHT

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.