
Fabric Clip Waterproof Bluetooth Speaker

Instruction Manual 26778



Functions: 1. ON/OFF Button

- 2. Vol-/Previous Track
- 3. Vol+/Next Track
- 4. Play/Pause 5. AUX Line Input
- 6. Type-C Input Port
- 7. LED Indicator

What's included:

- 1 x IP67 Dust & Waterproof Bluetooth Speaker
- 1 x USB to Type-C Charging Cable
- 1 x Instruction Manual

Tech Specifications

- . Playing Time: up to 5hrs at max volume
- Charge Time: 4hrs (from 0-100%)
- Pairing Name: "26778"
- . Battery Capacity: 1800mAh
- Input: DC 5V/500mA
- . Dust & Waterproof rating: IP67

Instructions

(Be sure to fully charge the speaker before using for the first time).

- 1 Charging the Speaker
- . Connect the provided Type-C charging cable to a power source and to the Type-C input port(6) on the speaker.
- . The LED indicator (7) will glow RED when charging, and will turn OFF when fully charged.
- 2. Bluetooth® Setup:
- Press and hold ON/OFF Button(1) to turn ON the speaker, LED indicator(7) will flash BLUE and speaker will tone when in
- bluetooth standby mode. Turn on the Bluetooth function on mobile device. Select "26778" pairing name.
- . Speaker will tone and LED will turn solid Blue if successfully paired.
- . Speaker will automatically pair if the mobile device has been paired before.
- . Press and hold ON/OFF Button(1) to turn off the device
- * If the speaker isn't connected to Bluetooth it will automatically power off after 5 minutes.
- 3. Using the Speaker:
- . Short press the Play/Pause Button(4) to pause or Play music.
- . "Vol+/Next track"(3): Short press - increase volume
- Long press next track. . "Vol-/Previous track"(2):
- Short press reduce volume
- Long press previous track
- 4. Calling:
- . Short press the Play/Pause Button(4) to answer or end the call.
- . Long press the Play/Pause Button(4) to

reject the call

- 5. AUX Connection:
- . Connect a AUX cable (NOT INCLUDED) to the 3.5mm Aux input port(5) of the speaker and mobile device to play music directly.
- 6. IP67 DustProof and Waterproof Rating::
- . The speaker can be submerged up to 1 meter of water for 30 minutes without causing any damage.

SAFFTY PRECAUTIONS:

- · WARNING-When using this product, basic precautions should always be followed: Read all the instructions before use.
- 2. Never store or use this product in temperatures below 32°F (0°C) or above 115°F (45°C).
- 3. The unit's full performance is achieved only after 2 or 3 completed charge and discharge cycles
- Keep out of reach of children.
- 5. Do not use the device in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury.
- 6. Do not use the device if damaged or modified.
- Damaged or modified batteries may exhibit unpredictable behavior resulting in fire. explosion or risk of injury.
- 8. Do not disassemble the device. For repairs, seek a qualified service professional. Incorrect reassembly may result in a risk of fire or injury.
- Do not expose the device to fire or temperatures above 104°F may cause explosion.
- 10. Ensure that qualified service professionals use only identical replacement parts to ensure product safety.

ECC Statement

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- This device may not cause harmful interference, and This device must accept any interference received, including interference that may cause undesired operation

approved by the party responsible for compliance could void the user's authority to operate the equipment

Changes or modifications not expressly

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the

limits for a Class B digital device. pursuant to part 15 of the ECC Rules. These limits are designed to provide reasonable protection

against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance

with the instructions may cause

harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful

interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to

correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



MADE IN CHINA

size:165 x 89mm 80G铜版纸 单黑印刷