


3-in-1 Light, Bluetooth Speaker, Power Bank

Instruction Manual
1226-61



1. Power ON/OFF Button
2. Volume +
3. Volume -
4. Bluetooth Speaker ON/OFF Button
5. USB output port
6. USB input port
7. Micro-USB input port

What's included:

- 1 x 3-in-1 Light, Bluetooth Speaker, Power Bank
- 1 x USB to Micro-USB charging cable
- 1 x Instruction Manual

Tech Specifications

- 2200mAh lithium-ion battery
- Bluetooth speaker
- Flashlight
- Output: 5V/1A
- Input: 5V/1A



How to pull off the torch

1. Left hand hold the body of power bank, right hand hold the torch part.
2. Right hand pushes down then pull toward right, the torch will be pulled off.

Instructions:

1. Charging the power bank (pull off the torch before charging):
With mobile phone USB adapter, connect the micro USB connector to the IN port on the portable charger. Connect the USB end of the cable to your phone's USB adapter and plug into the outlet to begin charging
Using a computer, connect the micro USB connector to the in port on the portable charger. And connect the USB end to your computer's USB port. Make sure the computer is turned on to begin charging.

2. Charging your devices (pull off the torch before charging):
Maximum output of portable power device is 1A. Connect USB cable to your mobile phone/device using the appropriate connector. Connect opposite end of cable the output of the portable power device. Your mobile phone/device should display the charging status. Remove the USB cable from your mobile phone/device when it is fully charged.
3. Bluetooth speaker:
Press Bluetooth speaker on/off button to open the Bluetooth speaker. Open your phone's Bluetooth and connects with Bluetooth speaker, and then the product can work as a normal Bluetooth speaker.
4. Flashlight:
Make sure the torch's USB port insert in the USB output port. Press the torch on/off button to turn on/off the torch.

SAFETY PRECAUTIONS:

- WARNING-When using this product, basic precautions should always be followed, including the following:
 1. Read all the instructions before using the product.
 2. Upon initial use or after a prolonged storage period, fully charge it once. The unit's full performance is achieved only after 2 or 3 completed charge and discharge cycles.
 3. Power banks are not allowed in checked luggage on commercial airline flights. Handle with care and dispose of in accordance to local regulations. Carry-on only.
- 4. To reduce the risk of injury, close supervision is necessary when the product is used near children.
- 5. Do not insert foreign objects into the product.
- 6. Do not expose power bank to moisture.
- 7. Use of a power supply or charger not recommended or sold by power bank manufacturer may result in a risk of fire or injury to persons.
- 8. Do not use the power bank in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury.
- 9. Do not use the power bank if damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- 10. Do not disassemble the power bank. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury.
- 11. Do not expose a power bank to fire or excessive temperature. Exposure to fire or temperatures above 212°F may cause explosion.
- 12. Have servicing performed by a qualified repair person using only identical replacement parts. This will ensure that the safety of the product is maintained.
- 13. Do not charge the power bank while using the power bank to charge another device. Do not charge the power bank for more than 4-6 hours and do not leave unattended.
- 14. Switch off the power bank when not in use.



MADE IN CHINA

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- a. Reorient or relocate the receiving antenna.
- b. Increase the separation between the equipment and receiver.
- c. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- d. Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.