

# Wireless Qi Charging Power Bank

## Instruction Manual

7121-02

PLACE Qi COMPATIBLE  
DEVICE HERE

### What's Inside:

1 x Wireless Qi Charging Power Bank  
1 x Micro-USB Charging Cable  
1 x Instruction Manual

### Tech Specifications

Battery Type: Lithium Polymer Battery

Capacity: 10000mAh/3.7V

### • Charging with the power bank:

- Using the Micro-USB cable: Insert the provided Micro-USB plug end of the cable into the device you wish to charge. Insert the opposite USB plug into the power bank. The LED indicator will illuminate and the device will begin to be charged as a normal power bank. *When the power bank is connected to external power via PC/AC adapter, the device enters Wireless Charging mode automatically.*
- Wireless Charging: Please first ensure the product is fit for Qi standard receiving equipment. Hold the power button in for less than 3 seconds or until LED flashes Red behind the Blue LED's. Release your hold on the Power Button and wait until all the LED indicators are all Red. This enables the Wireless Charging Mode. Set Qi-enabled device on platform with Qi symbol and begin charging automatically (launch distance:4-5mm).
- *Popular Compatible Models: Samsung Galaxy S7/S7 edge/S6/Note 5 / S6 edge / edge plus, Google Nexus 4/5/6/7 HD, Nokia Lumia 920/920T/928, Moto 360, LG G2 Verizon VS980, LG Optimus Vu II, LG D1L, LGLTE2, Aquos Phone f SH-13C, Aquos Phone Zeta SH-09D/SH-06E, Arrows Kiss F-03D/F-03D Girls, HTC Rzound, HTC Incredible 4G LTE, and any other Qi equipped devices.*

### • Charging the powerbank:

- Insert the provided USB charging cable into a certified USB AC adapter or the USB port on a computer to begin charging the Power Bank.
- While the Power Bank is charging, the LED status indicator will light Red, and then all four LED lights will turn Blue when power bank is fully charged.
- Press the power button once to view the remaining capacity.
- The power bank has a 30 second wireless charging function shut off, meaning the battery won't work to power a wireless charge.
- *If choosing to charge both the power bank and a personal device, place the personal device atop the power bank, or by using a USB connection (the LED indicator will flash until completely charged. Please note that*

### Important safety precautions

Please note the following precautions before initial use. Failure to comply may be dangerous and cause damage to your mobile devices.

- If the Power Bank does not respond once it is powered on, the battery capacity may be low. Follow the instructions for charging the Power Bank and check the LED battery capacity indicator. The indicator will flash as the Power Bank begins charging.
- Charge the power bank fully before initial use. The unit only achieves maximum performance after 2 or 3 full charging and discharging cycles.
- Always recharge the power bank in a well-ventilated area. Do not leave the power bank in hot or cold places.
- Do not immerse the power bank in water or expose it to moisture or weather conditions.
- Do not drop, knock, or shake the power bank. Rough handling can damage the internal precision component and its boards.
- Keep the powerbank away from children, this device is not a toy. While charging, the power bank's casing may become warm, which is normal as the charging and discharging processes generate heat.
- Keep the power bank away from fire or other sources of heat.
- Exposing the power bank to high temperatures may cause it to explode.
- Do not short-circuit the power bank, as this may cause damage to the unit.
- Unauthorized changed or modifications may void your right to use this product.
- While using the power bank, always comply with any special regulations that may apply to the area you are in and always turn off your mobile device when its use is prohibited. For example: do not use the power bank during flight, take-off or landing, near medical equipment, as it may cause interference or damage.

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:



- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

**CE** 1622



## Federal Communications Commission (FCC) Interference

### Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generate, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

### **RF exposure warning**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment must not be collocated or operating in conjunction with any other antenna or transmitter.